

[Manuals.plus](#) /

› [OVLUX](#) /

› OVLUX Full Metal Cordless Hair Clippers and Trimmer Professional Set User Manual

OVLUX LX-9909 / LX-9905

OVLUX Full Metal Cordless Hair Clippers and Trimmer Professional Set User Manual

Model: LX-9909 / LX-9905

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before use and retain for future reference.

- Always unplug the device before cleaning or changing attachments.
- Keep the device away from water. Do not use the device if the cord is damaged.
- Keep the device out of reach of children and pets. Always supervise children when using the device.
- Do not ingest or inhale small parts.
- Always follow the instructions provided with the device.

PRODUCT OVERVIEW

The OVLUX Full Metal Cordless Hair Clippers and Trimmer Professional Set provides a comprehensive solution for hair cutting and grooming. This set includes a main hair clipper and a T-blade trimmer, both designed for precision and ease of use.



Image: OVLUX Full Metal Cordless Hair Clippers and Trimmer Professional Set, showing both devices and various guide combs.

Key Features:

- **Full Metal Body:** Durable stainless steel construction for longevity.
- **Cordless Operation:** Built-in lithium-ion batteries for up to 120 minutes of use. USB rechargeable.
- **Precision Blades:** High-quality blades for sharp and clean cuts.
- **LCD Display:** Shows battery life and oil indicator.
- **Adjustable Taper Lever:** For clipper, adjusts cutting lengths from 0.8mm to 2.0mm.
- **Comprehensive Guide Combs:** 12 half metal guide combs (1.5-25mm, L&R) for the clipper and 4 detailed guide combs (1-4mm) for the trimmer.
- **Included Accessories:** Storage bags, brush, scissors, apron, oil, and comb.

PACKAGE CONTENTS

Your OVLUX Professional Set includes the following items:

- 1x OVLUX Hair Clipper (Model LX-9905)

- 1x OVLUX T-Blade Trimmer (Model LX-9909)
- 12x Half Metal Guide Combs for Clipper (1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm, Left Ear Taper, Right Ear Taper)
- 4x Detailed Guide Combs for Trimmer (1mm, 2mm, 3mm, 4mm)
- 2x USB Charging Cables
- 2x Storage Bags
- 1x Cleaning Brush
- 1x Hair Cutting Scissors
- 1x Hair Cutting Apron/Cape
- 1x Blade Oil
- 1x Hair Comb
- 1x User Manual



Image: All items included in the OVLUX Professional Hair Clippers and Trimmer Set, neatly arranged.

SETUP AND CHARGING

Initial Charge:

Before first use, fully charge both the hair clipper and the trimmer. Connect the provided USB charging cables to each device and a compatible USB power source (e.g., power bank, laptop, USB charger, computer). The LCD display will indicate charging progress. A full charge takes approximately 120 minutes.

USB QUICK CHARGE


Both products charge via USB



Powerbank



Laptop



Usb charger



Computer



WORLDWIDE VOLTAGE

✓ 110 V
USA



✓ 220 V
EUROPE



Image: Illustration showing USB charging options for the OVLUX clippers and trimmer, compatible with various USB power sources.

Attaching Guide Combs:

Select the desired guide comb for your intended hair length. Align the comb with the clipper/trimmer blade and push firmly until it clicks into place. Ensure the comb is securely attached before operating the device.

TRIMMER LENGTH IS NOT ADJUSTABLE



Image: Detailed view of the OVLUX hair clipper and trimmer with various guide combs, illustrating different cutting lengths.

OPERATING INSTRUCTIONS

General Use:

- Ensure hair is clean and dry before cutting.
- Turn on the device using the power button.
- For the clipper, use the taper lever to fine-tune cutting length between 0.8mm and 2.0mm.
- Move the clipper/trimmer against the direction of hair growth for an even cut.
- Use the T-blade trimmer for precise edging, detailing, and zero-gap cuts.

Your browser does not support the video tag.

Video: Official OVLUX video demonstrating the use of the cordless hair clippers for men, highlighting professional features and ease of use.

Achieving Fade Effects:

The adjustable taper lever on the clipper allows for seamless blending and fade effects. Start with a longer guide comb or a higher taper

setting, then gradually reduce the length as you move down the head.



Image: Illustration demonstrating the adjustable taper lever on the clipper for creating fade effects and achieving minimum hair length.

MAINTENANCE AND CLEANING

Cleaning the Blades:

- After each use, turn off and unplug the device.
- Use the provided cleaning brush to remove any loose hairs from the blades and guide combs.
- For thorough cleaning, detach the blades (refer to the detailed instructions in the printed manual for specific blade removal steps). Rinse the blades under running water if they are detachable and washable (check product specifications for water resistance). Ensure blades are completely dry before reattaching.

Oiling the Blades:

Regular oiling ensures optimal performance and extends blade life. Apply a few drops of the included blade oil to the teeth of the blades before or after every use. Turn on the device for a few seconds to distribute the oil evenly.

Storage:

Store the clippers and all accessories in the provided storage bags or case in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not turning on	Low battery; Device not charged.	Charge the device fully. Ensure charging cable is properly connected.
Blades pulling hair	Blades are dull or not oiled; Hair buildup between blades.	Clean and oil the blades. If problem persists, blades may need replacement.
Excessive noise/vibration	Blades not properly aligned or oiled.	Clean and oil the blades. Check blade alignment (refer to manual).
Uneven cut	Guide comb not properly attached; Incorrect technique.	Ensure guide comb is securely attached. Review operating instructions for proper technique.

SPECIFICATIONS

- **Model Numbers:** LX-9909 (Trimmer), LX-9905 (Clipper)
- **Power Source:** Lithium-Ion Battery
- **Charging Time:** Approximately 120 minutes
- **Operating Time:** Up to 120 minutes (per full charge)
- **Body Material:** Stainless Steel
- **Clipper Blade Adjustment:** 0.8mm - 2.0mm (via taper lever)
- **Input Voltage:** Worldwide Voltage (110V-220V compatible via USB)
- **Product Dimensions:** 4.06 x 6.89 x 9.53 inches; 3.15 Pounds (Set)

WARRANTY AND SUPPORT

The OVLUX Full Metal Cordless Hair Clippers and Trimmer Professional Set comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact OVLUX customer service. Contact information can typically be found on the product packaging or the official OVLUX website.