Soundcore A3936011

Soundcore Space A40 Adaptive Active Noise Cancelling Wireless Earbuds User Manual

Model: A3936011 | Brand: Soundcore

Overview | What's in the Box | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Product Overview

The Soundcore Space A40 Adaptive Active Noise Cancelling Wireless Earbuds are designed to provide an immersive audio experience with advanced noise reduction capabilities and extended battery life. These earbuds feature an upgraded noise cancelling system that can reduce external noise by up to 98%, adapting automatically to your environment. They deliver highly detailed sound through pioneering double-layer diaphragm drivers, supporting Hi-Res Audio Wireless via LDAC mode. With a lightweight and ergonomic design, they ensure comfortable wear for prolonged listening sessions.



Image: Soundcore Space A40 wireless earbuds and their charging case.

2. What's in the Box

Upon opening your Soundcore Space A40 package, you will find the following components:

- Soundcore Space A40 Noise Cancelling Earbuds (Left and Right)

- Charging Case
- XS/S/M/L/XL Ear Tips (Multiple sizes for optimal fit)
- USB-C Cable (for charging the case)

3. Setup Guide

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case provides up to 50 hours of total playtime, with the earbuds offering 10 hours on a single charge. A quick 10-minute charge can provide up to 4 hours of listening time.

1. Place both earbuds into the charging case.
2. Connect the provided USB-C cable to the charging port on the case and to a power source.
3. The LED indicators on the case will show charging status. Once fully charged, the indicators will remain solid or turn off depending on the model.



Image: Illustration of 50 hours total playtime and 10 hours single charge playtime.



Image: The Soundcore Space A40 charging case placed on a wireless charging pad.

3.2 Pairing with Your Device

The Soundcore Space A40 earbuds use Bluetooth 5.2 for wireless connectivity and are compatible with devices featuring a Bluetooth connection.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
3. Select "soundcore Space A40" from the list of available devices.
4. Once connected, you will hear an audible confirmation, and the earbuds' indicator lights will change.

The earbuds support multi-point connection, allowing them to be connected to two devices simultaneously.

3.3 Selecting the Right Ear Tips

For optimal sound quality and noise cancellation, it is crucial to choose the correct size ear tips. The package includes XS, S, M, L, and XL ear tips. Experiment with different sizes to find the most comfortable and secure fit that creates a good seal in your ear canal.



Image: Illustration highlighting the lightweight design of the Soundcore Space A40 earbuds, weighing 4.9g.

3.4 Soundcore App Installation

Download the Soundcore app from your device's app store (Google Play Store for Android, Apple App Store for iOS) to unlock full features and customization options, including:

- Customizable Equalizer (EQ) settings (up to 22 different presets).
- Noise Cancellation mode selection (Adaptive ANC, Normal, Transparency).
- Firmware updates.
- Touch control customization.



Image: Screenshots of the Soundcore app interface showing customization options.

4. Operating Instructions

4.1 Adaptive Active Noise Cancellation (ANC)

The Space A40 earbuds feature an advanced adaptive noise cancelling system that automatically detects external noises and adjusts the noise cancellation level to suit your surroundings. This ensures optimal noise reduction whether you are indoors, outdoors, commuting, or on a flight.

- **Adaptive ANC:** Automatically adjusts noise cancellation based on your environment.
- **Transparency Mode:** Allows you to hear your surroundings while still enjoying your audio.
- **Normal Mode:** Disables noise cancellation and transparency for standard listening.

You can switch between these modes using the touch controls on the earbuds or through the Soundcore app.



Image: Diagram illustrating how Soundcore Space A40 reduces noise by up to 98% with its upgraded noise cancelling system.



Image: A person wearing Soundcore Space A40 earbuds, with icons indicating adaptive noise cancelling for various environments like commuting, flying, outdoors, and indoors.

4.2 Audio Playback and Sound Quality

The Space A40 earbuds are equipped with pioneering double-layer diaphragm drivers that produce rich, detailed sound with strong bass, clear mids, and bright treble. They support Hi-Res Audio Wireless when using LDAC mode (compatible with Android devices), transferring 3 times more detail than standard Bluetooth codecs.



Image: Diagram showing the double-layer diaphragm drivers of the Soundcore Space A40, designed for clear mids, treble, and thumping bass, with Hi-Res Audio Wireless and LDAC logos.



Image: Graphic illustrating LDAC's capability to transfer 3x more detail compared to normal Bluetooth audio.

4.3 Call Functionality

The earbuds are equipped with 6 microphones and an AI algorithm to identify and block out background noise, ensuring ultra-clear calls. For best call quality, ensure the microphones are not obstructed.



Image: A person wearing Soundcore Space A40 earbuds, indicating clear call quality even in busy environments.

4.4 Touch Controls

The Soundcore Space A40 earbuds feature touch-sensitive controls. Default functions typically include:

- **Single Tap:** Play/Pause, Answer/End Call
- **Double Tap:** Skip Track Forward, Reject Call
- **Long Press:** Switch Noise Cancellation Modes, Activate Voice Assistant

These controls can be customized via the Soundcore app to suit your preferences.

5. Maintenance

5.1 Cleaning

Regular cleaning helps maintain optimal performance and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Gently remove any earwax or debris from the ear tips and speaker grilles using a small, clean brush or cotton swab.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

5.2 Storage

When not in use, always store the earbuds in their charging case to protect them and ensure they are charged for your next use. Store in a cool, dry place away from extreme temperatures.

5.3 Water Resistance

The Soundcore Space A40 earbuds are rated IPX4 waterproof, meaning they are resistant to water splashes from any direction. This makes them suitable for workouts and light rain. However, they are not designed for swimming or submersion in water. Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

6. Troubleshooting

Problem	Possible Solution
Earbuds not pairing.	Ensure earbuds are fully charged. Place earbuds back in the case, close it, then open it again to re-enter pairing mode. Disable and re-enable Bluetooth on your device. Forget "soundcore Space A40" from your device's Bluetooth list and re-pair.

Problem	Possible Solution
No sound or low volume.	Adjust volume on both your device and the earbuds. Ensure earbuds are properly seated in your ears and the ear tips provide a good seal. Check if the earbuds are connected to the correct device. Clean any debris from the speaker grilles.
Noise cancellation not effective.	Ensure you have selected the correct ear tip size for a snug fit. Verify that Active Noise Cancellation mode is enabled via the Soundcore app or touch controls. Update earbud firmware via the Soundcore app.
Microphone quality is poor during calls.	Ensure microphones are not covered or obstructed. Try making calls in a quieter environment. Ensure earbuds are fully charged.

7. Technical Specifications

Feature	Detail
Model Name	soundcore Space A40
Model Number	A3936011
Noise Control	Adaptive Active Noise Cancellation
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.2
Bluetooth Range	15 Meters
Earbud Battery Life	Up to 10 Hours (single charge)
Total Playtime (with case)	Up to 50 Hours
Fast Charging	10 min charge = 4 hours playtime
Audio Driver Type	DLC Driver (Double-Layer Diaphragm)
Supported Codecs	LDAC (Hi-Res Audio Wireless)
Microphones	6 (with AI algorithm for clear calls)
Water Resistance Level	IPX4 (Splash Resistant)
Earbud Weight	0.04 Pounds (approx. 4.9g per earbud)
Dimensions (Product)	2.67 x 1.74 x 1.12 inches
Included Components	Earbuds, Charging Case, XS/S/M/L/XL Ear Tips, USB-C Cable

8. Warranty and Support

Soundcore products are designed with high quality and performance in mind. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Soundcore website.
For technical support, troubleshooting assistance, or to register your product, please visit the Soundcore support page or contact their customer service team. You can often find user manuals and FAQs on their website.

- Official Soundcore Store: Soundcore Store on Amazon
- User Manual (PDF): Download PDF Manual
- User Guide (PDF): Download PDF Guide

© 2024 Soundcore. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question