

Generic GB. 4949

Galaxy Power Neckband in Ear Phone

USER MANUAL

Introduction

Thank you for choosing the Galaxy Power Neckband in Ear Phone, Model GB. 4949. This user manual provides essential information on how to set up, operate, and maintain your new neckband earphones. Designed for exceptional sound quality and convenience, these earphones offer a seamless audio experience with advanced features like Bluetooth v5.0 connectivity, integrated controls, and a lightweight, durable design.

Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.

Key Features

- **Extended Playback:** Enjoy up to 40 hours of continuous musical bliss on a single charge.
- **Fast Charging:** Fully charges in approximately 1.5 hours.
- **IPX5 Water Resistance:** Designed with an IPX5 rating, offering protection against sweat and water splashes, ideal for workouts and outdoor activities.
- **Magnetic Ear Tips:** Convenient magnetic earbuds prevent tangling and secure the earphones when not in use.
- **Integrated Controls:** Easily manage music playback (change tracks, adjust volume) and activate your device's voice assistant directly from the neckband.
- **Bluetooth v5.0 Connectivity:** Ensures stable and efficient wireless connection with compatible devices.
- **Lightweight Adaptive Fit:** Provides a secure and comfortable fit, designed to stay in place during movement.



Image: Front view of the Galaxy Power Neckband Earphones in their retail packaging, highlighting key features like 40 hours play time.

Setup

1. Charging the Earphones

Before first use, fully charge your Galaxy Power Neckband Earphones.

1. Locate the charging port on the neckband (usually covered by a rubber flap).
2. Connect the provided USB charging cable to the neckband and the other end to a USB power source (e.g., computer USB port, wall adapter).
3. The LED indicator will illuminate during charging and turn off or change color once fully charged.

4. Charging time is approximately 1.5 hours.

2. Bluetooth Pairing

Pair your earphones with your device (smartphone, tablet, laptop) for wireless audio.

1. Ensure the earphones are charged and turned off.
2. Press and hold the Multi-function button (usually the power button) on the neckband until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. You should see "GB. 4949" or "Galaxy Power Neckband" in the list.
5. Select the earphone name to connect. Once connected, the LED indicator will typically flash blue slowly or turn solid blue.
6. If prompted for a password, enter "0000".



Image: Rear view of the Galaxy Power Neckband Earphones packaging, displaying technical parameters and usage instructions.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the Multi-function button for 3 seconds.
- **Power Off:** Press and hold the Multi-function button for 5 seconds.

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Long press the Volume Up (+) button.
- **Previous Track:** Long press the Volume Down (-) button.
- **Volume Up:** Short press the Volume Up (+) button.
- **Volume Down:** Short press the Volume Down (-) button.

Call Management

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Long press the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

Voice Assistant Activation

- **Activate Voice Assistant:** Triple-press the Multi-function button to activate Siri, Google Assistant, or other voice assistants on your connected device.

Your browser does not support the video tag.

Video: An overview of the Galaxy Power Neckband Earphones, demonstrating key features and usage. This video provides a visual guide to the product's design and functionality.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the earphones. Do not use abrasive cleaners or solvents.

- **Water Resistance:** While IPX5 rated for sweat and water splashes, do not submerge the earphones in water. Ensure the charging port cover is securely closed to maintain water resistance.
- **Storage:** Store the earphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the earphones regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Cannot power on	Low battery	Charge the earphones for 1.5 hours.
Cannot pair with device	Earphones not in pairing mode; Bluetooth off on device; too far from device	Ensure earphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Keep devices within 10 meters.
No sound	Volume too low; not connected; incorrect audio output selected	Increase volume on earphones and device. Re-pair the earphones. Check device's audio output settings.
Intermittent connection	Interference; too far from device; low battery	Move closer to your device. Avoid strong Wi-Fi or other wireless signals. Charge the earphones.

Specifications

Feature	Detail
Model Name	GB 4949
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth v5.0
Included Components	Ear Cushions
Material	Plastic
Specific Uses For Product	Music, Sport, Travel
Charging Time	1.5 Hours
Compatible Devices	Laptops, Desktops, Cellphones, Tablets, Smart Speaker, Television
Water Resistance Level	IPX5 Water Resistant
Battery Life	40 Hours (Playback)
Special Features	Sweatproof, Microphone Included, Fast Charging
Microphone Format	In Ear
Form Factor	In Ear

Feature	Detail
Brand	Generic
Color	Black

Warranty and Support

The Galaxy Power Neckband in Ear Phone comes with a **6 Months warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For further information, technical support, or warranty service, please refer to the product detail page on Amazon.in or contact the manufacturer, A M Enterprise, directly.

Manufacturer: A M Enterprise