

[Manuals.plus](#) /

› [VTech](#) /

› VTech Nougat, My Magic Paws Friend: Interactive Plush Toy User Manual

VTech 615085

VTech Nougat, My Magic Paws Friend

Interactive Plush Toy User Manual - Model: 615085

1. IMPORTANT SAFETY INFORMATION

WARNING: Not suitable for children under 12 months.

Please read all instructions before using the VTech Nougat, My Magic Paws Friend interactive plush toy. Keep this manual for future reference. Ensure all packaging materials are removed before giving the toy to a child.

2. PRODUCT OVERVIEW

Nougat, My Magic Paws Friend is a soft, interactive plush dog designed to accompany children aged 1 to 5 years in their early learning journey. This toy helps children learn first words, colors, numbers, and explore emotions and breathing.

Key Features:

- **Interactive Paws:** Connectors on the front paws allow interactive music play.
- **Personalizable Content:** Customize with the child's name and preferences (food, animals, colors).
- **Learning Modes:** Teaches first words, colors, numbers, breathing, and emotions.
- **Multiple Play Modes:** Activity, Music, Night, and Off modes accessible via ear and paw buttons.
- **Musical Content:** Includes over 40 songs, melodies, and lullabies.
- **Lullaby Timer:** Offers 5, 10, or 15 minutes of continuous lullabies.



Figure 2.1: Front view of Nougat, My Magic Paws Friend.

3. SETUP

3.1 Battery Installation

The VTech Nougat toy requires 2 LR6 (AA) batteries. Batteries are included for demonstration purposes but may need replacement for extended use.

1. Locate the battery compartment on the back or bottom of the plush toy.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 2 new LR6 (AA) batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and tighten the screw securely.

Note: Always use new batteries of the same type. Do not mix old and new batteries or different types of batteries. Remove batteries if the toy will not be used for an extended period.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Mode Selection

The toy features buttons on its ears and paws to control power and switch between different play modes.

- **Power Button:** Located on one of the paws (often indicated by a power symbol). Press to turn the toy On or Off.
- **Mode Buttons:** Other buttons on the ears or paws allow you to switch between Activity, Music, and Night modes.

4.2 Interactive Play with Magic Paws

Nougat's front paws are equipped with special connectors that enable interactive music play. Children can touch these sensors to activate melodies and sounds.



Capteurs magiques pour jouer de la musique

Figure 4.1: Interacting with Nougat's magic paws.

The collar of the plush toy also lights up in rhythm with the music, enhancing the interactive experience.



Figure 4.2: Nougat's collar illuminates with music.

4.3 Personalizing Nougat

One of Nougat's unique features is its ability to be personalized. You can input the child's name and their preferences (such as favorite food, animals, or colors) to make the toy's responses more tailored.

Refer to the product packaging or VTech's official website for detailed instructions on how to personalize the toy, as this often involves a simple online process or connection to a device.



Peluche magique à personnaliser

Figure 4.3: Example of personalized interaction.

4.4 Night Mode and Lullabies

In Night Mode, Nougat can play soothing lullabies for 5, 10, or 15 minutes to help the child fall asleep. This mode is designed for quiet time and bedtime routines.



Disponible en 2 coloris

Figure 4.4: Nougat providing continuous lullabies.

5. MAINTENANCE

5.1 Cleaning Instructions

Nougat, My Magic Paws Friend is surface washable only. Do not immerse the toy in water or put it in a washing machine, as this can damage the electronic components.

- Dampen a soft cloth with mild soap and water.
- Gently wipe the surface of the plush toy to remove dirt or stains.
- Wipe again with a clean, damp cloth to remove any soap residue.
- Allow the toy to air dry completely before further use or storage.

5.2 Storage

Store the toy in a cool, dry place away from direct sunlight and moisture when not in use for extended periods. Remove batteries before long-term storage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Toy does not turn on or respond.	Low or dead batteries; Incorrect battery installation.	Replace batteries with new LR6 (AA) batteries. Ensure correct polarity.
Sound is distorted or too low.	Low batteries.	Replace batteries.
Interactive paws not responding.	Toy is in a different mode; Sensor obstruction.	Ensure toy is in an interactive mode. Check for any debris on the sensors.
Personalization not working.	Incorrect procedure followed.	Refer to VTech's official website or included personalization guide for detailed steps.

7. SPECIFICATIONS

Feature	Detail
Model Number	615085
Product Dimensions (L x W x H)	24.1 x 14 x 26.7 cm
Weight	470 grams
Recommended Age	12 months - 5 years
Educational Values	Word discovery, Number discovery, Sensory awakening, Color discovery, Fine motor skills
Number of Pieces	1
Self-assembly Required	No
Batteries Required	Yes
Batteries Included	Yes (for demonstration)
Battery Type	LR06 (AA)
Main Material	Fabric, Plastic
Color	Multicolored
Spare Parts Availability	Unavailable

8. WARRANTY AND SUPPORT

VTech products are manufactured to high quality standards. For information regarding warranty, product registration, or technical support, please visit the official VTech website or contact their customer service department.

VTech Official Website: www.vtech.com

Please retain your purchase receipt as proof of purchase.

© 2024 VTech. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question