

- Manuals.plus /
- › ELYKEN /
- › ELYKEN 5.9" Narrow Console Sofa Table with Power Outlets and USB Port Instruction Manual

ELYKEN HST02G1

ELYKEN 5.9" Narrow Console Sofa Table with Power Outlets and USB Port Instruction Manual

Brand: ELYKEN | Model: HST02G1

PRODUCT OVERVIEW

The ELYKEN 5.9" Narrow Console Sofa Table is designed to maximize space efficiency in compact areas. This versatile table features integrated power outlets and USB ports, providing convenient charging solutions. Its slim profile allows for placement behind sofas, in hallways, or other narrow gaps, offering both functional surface area and modern aesthetic appeal.



Image: The ELYKEN 5.9" Narrow Console Sofa Table in Rustic Brown, positioned behind a sofa, showcasing its slim design and integrated power outlets.

SAFETY INFORMATION

- Always assemble the table on a stable, flat surface.
- Tighten all screws securely.
- Use the anti-tipping strap and expansion screw to secure the table to the wall for enhanced stability.
- Do not place heavy items on the table that could cause it to tip over. The maximum weight recommendation is 110 pounds.
- Keep the table away from heat sources.
- Never leave flammable materials on or near the table.

PACKAGE CONTENTS

Before assembly, ensure all parts are present and undamaged. The package typically includes:

- Tabletop (with integrated power outlets and USB ports)
- Metal Frame Components (legs, support rods)
- Assembly Hardware (screws, adjustable feet pegs)
- Hexagonal Wrench
- Anti-tipping Strap and Expansion Screw
- Assembly Guide

If any parts are missing or damaged, please contact ELYKEN customer support.

ASSEMBLY INSTRUCTIONS

Assembly is straightforward and requires minimal tools. All necessary tools are included in the package. Follow these steps for proper assembly:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, flat surface. Refer to the included assembly guide to identify each part (e.g., top board, metal legs, support rods, screws).
2. **Attach Legs to Top Board:** Align the metal legs with the pre-drilled holes on the underside of the tabletop. Secure them using the provided screws and the hexagonal wrench. Ensure all connections are snug but do not overtighten.
3. **Install Support Rods:** Attach the horizontal support rods between the legs. These rods enhance the table's stability. Secure them with the appropriate screws.
4. **Adjust Feet Pegs:** Screw the 4 adjustable feet pegs into the bottom of the legs. Adjust them as needed to ensure the table is level and stable on uneven floors.
5. **Connect Power Outlet:** The integrated power outlet and USB ports are pre-installed in the tabletop. Ensure the 6.5-foot power cord is routed safely and connected to a standard 120VAC wall outlet.
6. **Install Anti-Tipping Strap:** For double stability, especially if placing the table freestanding or in areas with potential for tipping, attach the anti-tipping strap to the table frame and secure it to the wall using the expansion screw.

Your browser does not support the video tag.

Video: Official ELYKEN assembly guide for the 5.9" Slim Console Table with Power Outlet. This video demonstrates the step-by-step process of assembling the table, including attaching the legs, installing the power unit, and securing the anti-tip device.




Image: Detailed diagram illustrating the dimensions of the ELYKEN Narrow Console Sofa Table: 5.9"D x 39.4"W x 31.1"H, with a 6.5' extension cord.

OPERATING INSTRUCTIONS & FEATURES

Integrated Power Outlets and USB Ports

The console table is equipped with a convenient power strip featuring 2 standard 120VAC outlets and 2 USB ports. This allows you to easily charge electronic devices such as smartphones, tablets, or power small lamps directly from the tabletop.



120V/12A
(2 AC Outlets)



5V/2A
(2 USB Ports)



6.5-Foot
(Power Cord)

Image: A close-up view of the integrated power outlets and USB ports on the table, showing a smartphone connected for charging.

Space-Saving Design

With dimensions of 5.9"D x 39.4"W x 31.1"H, this narrow table is ideal for tight spaces. It can be placed behind a sofa, in a hallway, or against a wall without obstructing movement or blocking wall vents.

Adjustable Charging Station

On the side



In the middle



Image: The console table behind a sofa, demonstrating how the adjustable charging station can be positioned on the side or in the middle for convenience.

Stability and Durability

Constructed with a sturdy metal frame and quality particleboard, the table is designed for stability. Adjustable feet pegs help to prevent wobbling, and the anti-tipping strap provides additional security when anchored to a wall.



Image: A close-up showing the anti-tip device, a strap attached to the table leg, designed to be secured to the wall for enhanced stability.

MAINTENANCE

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Tighten Fasteners:** Periodically check and tighten all screws and bolts to ensure the table remains stable.
- **Avoid Excessive Weight:** Do not exceed the maximum weight recommendation of 110 pounds to prevent damage or instability.
- **Protect from Moisture:** While the table is durable, prolonged exposure to moisture can affect the particleboard. Wipe up spills immediately.

TROUBLESHOOTING

- **Table Wobbles:**
 - Ensure all screws are securely tightened.
 - Adjust the feet pegs on the bottom of the legs to level the table on uneven surfaces.
 - Verify the anti-tipping strap is properly installed and anchored to the wall.
- **Power Outlets/USB Ports Not Working:**
 - Check if the main power cord is securely plugged into a functional wall outlet.
 - Ensure the wall outlet itself is receiving power (test with another device).
 - Avoid overloading the outlets; check the power requirements of your devices.
- **Difficulty Assembling:**
 - Refer to the detailed assembly guide provided in the package.
 - Ensure you are using the correct screws for each step, as indicated by the labels.
 - Do not force parts together; if they don't fit, re-check the orientation and instructions.

SPECIFICATIONS

Brand	ELYKEN
Model Number	HST02G1
Product Dimensions (D x W x H)	5.9" x 39.4" x 31.1"
Item Weight	10.66 Pounds
Maximum Weight Recommendation	110 Pounds
Frame Material	Metal
Top Material Type	Engineered Wood
Color	Rustic Brown
Power Outlets	2 Standard 120VAC
USB Ports	2 (5V/2A)
Power Cord Length	6.5 feet

Assembly Required	Yes
Included Components	Assembly Guide, Installation Tool (Hexagonal Wrench)

WARRANTY AND SUPPORT

For warranty information, product support, or to report missing/damaged parts, please refer to the contact details provided in your product packaging or visit the official ELYKEN website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B1MN31C7>

More documents and user manuals: <https://manuals.plus/>