

Wenko 25459100

Wenko Classic Shower Bar with Hand Shower Holder - 70 cm, Black

Model: 25459100

1. INTRODUCTION

The Wenko Classic Shower Bar in black offers a practical and stylish solution for your bathroom. Crafted from high-quality stainless steel, it features an integrated, adjustable holder for your hand shower, allowing you to position it at your desired height for a comfortable showering experience. Its modern matte black finish complements various bathroom styles, from classic to industrial-chic.

2. PACKAGE CONTENTS

Please verify that all components are present before beginning installation:

- 1 x Wenko Classic Shower Bar (70 cm, Black, Stainless Steel)
- 1 x Integrated Adjustable Hand Shower Holder
- Mounting Screws and Dowels

3. SAFETY INSTRUCTIONS

Please read and understand these safety instructions before installation and use:

- Always wear appropriate safety gear (e.g., eye protection) during installation.
- Ensure the mounting surface is suitable and can support the weight of the shower bar and any attached accessories.
- Do not hang or apply excessive weight to the shower bar, as this may cause damage or injury.
- Keep small parts out of reach of children to prevent choking hazards.

4. SETUP AND INSTALLATION

The shower bar is designed for secure wall mounting. Follow these steps for installation:

1. **Mark Drilling Points:** Position the shower bar on the wall at the desired height. Mark the locations for the two wall brackets. One bracket is fixed, while the other is movable to accommodate existing drill holes or

cover them.

2. **Drill Holes:** Using an appropriate drill bit for your wall type, drill holes at the marked points. Insert the provided dowels into the drilled holes.
3. **Mount Brackets:** Secure the wall brackets to the wall using the provided screws. Ensure they are tightened firmly but do not overtighten.
4. **Attach Shower Bar:** Slide the shower bar into the mounted brackets. Secure it in place according to the bracket design, typically by tightening a small set screw on each bracket.
5. **Adjust Hand Shower Holder:** The hand shower holder can be adjusted along the bar. Loosen the holder, slide it to the desired height, and then tighten it to secure your hand shower.




Image: Diagram illustrating the flexible wall bracket for existing drill holes and the adjustable holder for hand showers.



Image: This image highlights the classic round shape, stainless steel material, and confirms the inclusion of screws and dowels for wall mounting.

5. OPERATING INSTRUCTIONS

Using the Wenko Classic Shower Bar is straightforward:

- **Adjusting Hand Shower Height:** To change the height of your hand shower, gently loosen the adjustable holder. Slide it up or down the shower bar to your preferred position. Once at the desired height, tighten the holder to secure the hand shower firmly in place.
- **Hand Shower Angle:** The holder also allows for minor angle adjustments of the hand shower for optimal spray direction.

6. MAINTENANCE

To ensure the longevity and appearance of your shower bar, follow these maintenance guidelines:

- **Cleaning:** Clean the shower bar regularly with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaning solution specifically designed for stainless steel or bathroom fixtures.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or harsh chemical detergents, as these can damage the matte black finish and the stainless steel surface.
- **Drying:** After cleaning, wipe the shower bar dry with a clean, soft cloth to prevent water spots and maintain its finish.

7. TROUBLESHOOTING

If you encounter any issues with your shower bar, refer to the following common problems and solutions:

- **Hand Shower Holder Slips:** Ensure the adjustable holder is tightened sufficiently. If it continues to slip, check for any debris or wear on the internal mechanism that might prevent a secure grip.
- **Shower Bar Feels Loose:** Verify that the wall mounting screws are securely fastened. If necessary, re-tighten them. Avoid overtightening, which can damage the wall or the brackets.
- **Difficulty Adjusting Holder:** If the holder is stiff, ensure it is fully loosened before attempting to slide it. A small amount of silicone spray (avoiding contact with the finish) might help if friction is an issue.

8. SPECIFICATIONS

Attribute	Detail
Brand	Wenko
Model Number	25459100
Material	Stainless Steel
Color	Black (Matte)
Dimensions (L/D x H)	Ø 2.2 x 70 cm (Ø 0.87 x 27.56 inches)
Weight	222 g (approx. 0.49 lbs)

Garantie-Zertifikat

Guarantee Certificate

Certificat de garantie

Certificado de garantía

Certificato di garanzia



Sehr geehrter Kunde,

auf dieses Produkt haben Sie 3 Jahre Garantie ab Kaufdatum. Die Garantie umfasst alle Material- und Herstellungsfehler, welche die Funktion beeinträchtigen. Ausgenommen sind Schäden, die durch unsachgemäße Handhabung oder natürlichen Verschleiß entstehen. Diese Garantie schränkt Ihre gesetzlichen Gewährleistungsschrechte nicht ein. Im Garantiefall schicken Sie den Artikel zusammen mit dem dazugehörigen Kassenbon kostenfrei und transportsicher verpackt an die folgende Anschrift:

Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“

Im Hülsenfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.com

Dear customer,

You have a 3-year guarantee on this product, beginning on the date of purchase. The guarantee comprises all material and manufacturing errors that impair the function. Any damage caused by improper handling or normal wear and tear is excluded. This guarantee does not restrict your statutory guarantee rights. In case of a guarantee claim, please send the article free of charge and properly packaged to the following address together with the corresponding receipt:

Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“

Im Hülsenfeld 10 · 40721 Hilden, Germany
service@wenko.de · www.wenko.com

Chère cliente, cher client,

Pour ce produit, vous bénéficierez d'une garantie de 3 ans à compter de la date d'achat. La garantie porte sur tous les vices de matière et de fabrication qui altèrent le bon fonctionnement. Sont exclus les dommages résultant d'un maniement incorrect ou de l'usure naturelle. La garantie ne restreint aucune vos droits à la garantie légale. En cas de garantie, veuillez renvoyer gratuitement l'article accompagné du ticket de caisse et convenablement emballé pour le transport à l'adresse suivante :

Wenko-Wenselaar GmbH & Co. KG - Abteilung « Retouren »

Im Hülsenfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.com

Estimado cliente:

Para este producto usted dispone de 3 años de garantía a partir de la fecha de compra. La garantía cubre todos los defectos de material y fabricación, que perturban el funcionamiento. Sont exclus los derechos legales de garantía. En caso de hacer uso de la garantía, envíe gratuitamente el producto junto con el recibo de pago correspondiente y empaquetado de forma segura para el transporte a la siguiente dirección:

Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“

Im Hülsenfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.com

Gentile cliente,

questo prodotto ha una garanzia di 3 anni a partire dalla data di acquisto. La garanzia copre tutti i difetti di materiali e fabbricazioni che pregiudicano la funzione. Sono esclusi dalla garanzia i danni causati da un uso improprio o dovuti a usura naturale. Questa garanzia non limita i Suoi diritti legali. In caso di garanzia l'articolo, opportunamente imballato, va spedito gratuitamente insieme al relativo scontrino al seguente indirizzo:

Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“ (Reparto „Resi“)

Im Hülsenfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.com

Geachte klant,

Op dit product heeft u 3 jaar garantie vanaf de datum van aankoop. Deze garantie omvat alle materiale- en productiefouten die van invloed zijn op de werking van het product. Schade als gevolg van verkeerd gebruik of natuurlijke slijtage valt niet onder de garantie. Deze garantie laat uw wettelijke garantierechten onverlet. Bij garantie kunt u het product gratis retourneren. Stuur het product in dat geval vóórverkocht naar het volgende adres:

Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“

Im Hülsenfeld 10 · D-40721 Hilden
service@wenko.de · www.wenko.com

Estimado Cliente,

Este producto tiene 3 años de garantía a contar de la data de compra. La garantía abrange defectos de material y de mano-de-obra que influencian el funcionamiento del producto. Excluyen-se danos devidos a um manuseamento incorrecto ou ao desgaste natural. A presente garantía não afecta os direitos de garantia reservados por lei. Para açãoamento da garantia, enviar o artigo, com os portes pagos e em transporte seguro, juntamente com o comprovativo de compra, para a seguinte morada:

Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“

Im Hülsenfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.com

Kære kunde

Vi giver 3 års garanti på dette produkt fra købsdatoen. Garantien omfatter alle materiale- og produktionsfejl, der har indflydelse på produkts funktion. Undtaget herfra er skader opstået ved ugensigtsmæssig brug af produktet eller almindelig slijtage. Denne garanti indskrænker ikke dinne lovmæssige rettigheder. I garantitilfælde skal du indsende varen samt den tilhørende kassebon omkostningsfrit og transportsikert emballeret til nedstendende adresse:

Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“

Im Hülsenfeld 10 · 40721 Hilden, Tyskland
service@wenko.de · www.wenko.com

Kär kund,

du har 3 års garanti på denna produkt från och med inköpsdatum. Garantin täcker alla material- och tillverkningsfel som inräktrar på funktionen. Undantagna är skador som beror på osäkurnig hantering eller naturligt slijtage. Denne garanti påverkar inte dinna lagstadgade garantirättigheter. I ett garantifall ska artikeln och det tillhörande kassakvitot skickas kostnadsfritt och i en transportsäker förpackning till följande adress:

Wenko-Wenselaar GmbH & Co. KG - Avdelning "Retouren"

Im Hülsenfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.com

Wenko-Wenselaar GmbH & Co. KG - Abteilung „Retouren“ - Im Hülsenfeld 10 · 40721 Hilden
service@wenko.de · www.wenko.com

Image: This image displays the overall length of the shower bar, which is 70 cm (27.56 inches).


9. WARRANTY AND SUPPORT

This Wenko product is covered by a **3-year warranty** from the date of purchase. The warranty covers all material and manufacturing defects that impair the product's function. Damages resulting from improper use, incorrect installation, or natural wear and tear are excluded. This warranty does not limit your statutory warranty rights.

To make a warranty claim, please send the item along with your proof of purchase, adequately stamped and protected for transport, to the following address:

Wenko-Wenselaar GmbH & Co. KG
Abteilung "Retouren"
Im Hülsenfeld 17
40721 Hilden, Germany

For support inquiries, you may also contact via email:service@wenko.de



**One sliding wall bracket to use
or cover existing drill holes**

*Eine verschiebbare
Wandhalterung zur*

*Verwendung oder Abdeckung
von vorhanden Bohrlöchern*



**Adjustable holder for hand
showers**

*Verstellbare Halterung für
Handbrausen*




Image: The Wenko 3-year warranty certificate, detailing terms and conditions in various languages.

