ASPOR A323

ASPOR A323 10000mAh Power Bank User Manual

Model: A323

1. Introduction

Thank you for choosing the ASPOR A323 10000mAh Power Bank. This portable power supply is designed to provide reliable and efficient charging for your mobile devices on the go. Please read this manual carefully before using the product to ensure safe and optimal performance.



Image 1.1: Front view of the ASPOR A323 10000mAh Power Bank.

2. Safety Instructions

To prevent injury or damage to your device, please observe the following safety precautions:

- Do not expose the power bank to extreme temperatures (above 60°C/140°F or below 0°C/32°F).
- Do not disassemble, modify, or attempt to repair the device.
- Keep away from water, moisture, and flammable materials.
- Avoid dropping, hitting, or subjecting the power bank to strong impacts.
- Do not use if the power bank is swollen, leaking, or shows any signs of damage.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations.

3. Package Contents

Please check the box for the following items:

- ASPOR A323 10000mAh Power Bank
- USB Charging Cable (Micro USB or USB-C, depending on model variant)
- User Manual (this document)

4. Product Overview

The ASPOR A323 Power Bank features a compact design with multiple input and output ports for versatile charging. It includes LED indicators to show the remaining battery level.



Image 4.1: ASPOR A323 Power Bank and its packaging, illustrating available color options.





Image 4.2: Detailed view of the ASPOR A323 Power Bank, showing Micro USB and Type-C inputs, and USB outputs.

4.1. Ports and Indicators

- **Micro USB Input:** For charging the power bank.
- **USB Type-C Input:** For charging the power bank.
- **USB Output 1 & 2:** For charging external devices.

- **LED Indicators:** Typically 4 small LED lights indicating the remaining battery capacity (e.g., 4 lights = 75-100%, 3 lights = 50-75%, 2 lights = 25-50%, 1 light = 0-25%).

5. Setup

5.1. Initial Charging of the Power Bank

Before first use, fully charge your ASPOR A323 Power Bank.

1. Connect the provided USB charging cable to either the Micro USB or USB Type-C input port on the power bank.
2. Connect the other end of the cable to a USB wall charger (not included) or a computer's USB port.
3. The LED indicators will light up, showing the charging progress. All four LEDs will be solid when fully charged.

6. Operating Instructions

6.1. Charging External Devices

To charge your mobile phone, tablet, or other USB-powered devices:

1. Connect your device's charging cable to one of the USB output ports on the power bank.
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The LED indicators will show the power bank's remaining charge.

6.2. Checking Battery Level

To check the remaining battery level of the power bank, briefly press the power button (if available, otherwise it will light up when a device is connected or when charging). The LED indicators will illuminate to show the current charge:

- **4 LEDs:** 75% - 100%
- **3 LEDs:** 50% - 75%
- **2 LEDs:** 25% - 50%
- **1 LED:** 0% - 25% (Recharge soon)

7. Maintenance

Proper care will extend the life of your power bank:

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery health, fully charge the power bank at least once every three months if not in regular use.

8. Troubleshooting

If you encounter issues with your ASPOR A323 Power Bank, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Power bank not charging	Loose cable connection, faulty cable, low power source, power bank fully charged.	Ensure cables are securely connected. Try a different cable or wall adapter. Check if the power bank is already full.
Device not charging from power bank	Power bank is depleted, faulty cable, device not compatible, loose connection.	Recharge the power bank. Try a different charging cable. Ensure your device is compatible with USB charging. Check connections.
Slow charging	Using a low-power charger/port, cable resistance, device's charging input limit.	Use a higher-output USB wall charger. Ensure the cable is not too long or thin. Some devices have limited charging speeds.
LED indicators not working	Power bank is completely depleted or damaged.	Try charging the power bank for an extended period. If still unresponsive, the unit may be faulty.

If the problem persists after trying these solutions, please contact customer support.

9. Specifications

Feature	Detail
Model Name	ASPOR A323
Battery Capacity	10000 Milliamp Hours (mAh)
Battery Cell Composition	Lithium
Input (Micro USB)	DC 5V/2A
Input (USB Type-C)	DC 5V/2A
Output (USB 1/2)	Total 5V/2.4A (IQ)
Special Features	Fast Charging
Product Dimensions	10 x 10 x 10 cm
Item Weight	260 Grams
Color	White
Recommended Uses	Phone
Power Source	Corded Electric
Manufacturer	Aspor

10. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the

official ASPOR website. Keep your purchase receipt as proof of purchase.

© 2024 ASPOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question