

[Manuals.plus](#) /

› [ELPHECO](#) /

› ELPHECO Kitchen Compost Bin with Lid, 1.8 Gallon, Hanging Trash Can - Instruction Manual

ELPHECO 1.8 Gallon

ELPHECO Kitchen Compost Bin with Lid (1.8 Gallon) - Instruction Manual

Model: 1.8 Gallon

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your ELPHECO 1.8 Gallon Kitchen Compost Bin with Lid. Designed for convenience and efficiency, this hanging trash can is suitable for various small spaces, including kitchens, bathrooms, and RVs.

SAFETY INFORMATION

- Ensure the bin is securely installed using the provided mounting options to prevent accidental falls.
- Do not overload the bin beyond its 1.8-gallon capacity to maintain stability and prevent damage.
- Keep the product away from open flames or extreme heat sources.
- This product is intended for household waste and compostable materials. Do not dispose of hazardous or sharp objects that could damage the bin or liner.

PACKAGE CONTENTS

Your ELPHECO Kitchen Compost Bin package includes:

- 1 x ELPHECO 1.8 Gallon Trash Can
- 1 x Hanging Hook Attachment
- 1 x Adhesive Strip Attachment

SETUP AND INSTALLATION

The ELPHECO Kitchen Compost Bin offers two installation methods: hanging over a cabinet door or wall-mounted with an adhesive strip.

Method 1: Hanging Installation

This method is suitable for cabinet doors not thicker than 1 inch (2.5 cm).

1. Attach the hanging hook component to the back of the trash can.
2. Hang the trash can over the top edge of your desired cabinet door. Ensure it is stable and does not obstruct the door's movement.




Image: The ELPHECO compost bin installed by hanging it over a cabinet door.



Image: Visual guide illustrating both hanging and adhesive strip installation methods.

Your browser does not support the video tag.

Video: Demonstrates the hanging installation of the ELPHECO trash can on a cabinet door.

Method 2: Wall-Mounted Installation

This method uses the adhesive strip for mounting on flat, clean vertical surfaces.

1. Clean and dry the desired wall surface thoroughly.
2. Peel off the protective backing from the adhesive strip.
3. Firmly press the adhesive strip onto the wall, ensuring good contact.
4. Attach the trash can to the mounted adhesive strip.

HANGING& WALL-MOUNTED TRASH CAN

with smooth Sliding Lid



Non-Drilling



Quick Packing



Horizontal
Large Diameter



Garbage Bag
Fixed Rubber Flaps



Lock
Special Smell



Multi-scene
Application



Image: The ELPHECO compost bin mounted on a kitchen wall.

Installing a Trash Bag

1. Open the lid of the compost bin.
2. Place a trash bag inside the bin, ensuring the edges are folded over the rim.
3. Secure the trash bag using the four rubber flaps located on the inner rim of the bin. These flaps prevent the bag from slipping.

BUILT-IN 4 RUBBER FLAPS

Fix garbage bags to prevent slippage



Image: Detail of the four rubber flaps designed to hold the trash bag in place.

OPERATING INSTRUCTIONS

Opening and Closing the Lid

The bin features a smooth-opening lid for easy access.

- To open, gently pull back the rubber pull ring on the lid. The lid will slide open smoothly.
- To close, push the lid back into its original position until it seals. This helps contain odors.



SMOOTH OPENING LID

Open the lid with a gentle slide

Image: A hand opening the lid with a gentle slide motion.

Your browser does not support the video tag.

Video: Shows the smooth operation of the sliding lid and how to open and close it.

Disposing of Waste

The wide opening allows for easy disposal of kitchen scraps and other waste without bending down.



Image: Demonstrates convenient waste disposal into the bin while standing.

Quick Bag Packing

The drawstring design facilitates quick and hygienic removal of full trash bags.

- Once the bag is full, pull the drawstring on both sides of the bag.
- Lift the bag out of the bin to avoid direct contact with the contents.



Image: Illustration of the quick packing feature using the bag's drawstring.

MAINTENANCE

Cleaning Instructions

- Regularly empty the bin to prevent odor buildup and maintain hygiene.
- Wipe the interior and exterior of the bin with a damp cloth and mild detergent.
- Rinse thoroughly and allow to air dry completely before re-inserting a trash bag.
- Avoid using abrasive cleaners or harsh chemicals, as these may damage the plastic.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bin falls off cabinet/wall.	Improper installation; cabinet door too thick; adhesive not strong enough.	Ensure cabinet door is not thicker than 1 inch for hanging. For adhesive, ensure surface is clean, dry, and flat before application. Apply firm pressure for 30 seconds. Do not overload the bin.
Trash bag slips down.	Bag not secured by rubber flaps.	Ensure all four rubber flaps are properly holding the edges of the trash bag.
Lid is stiff or stuck.	Debris in the sliding mechanism; lid misaligned.	Check for any obstructions in the lid's sliding track. Clean the track if necessary. Ensure the lid is aligned correctly.
Unpleasant odors persist.	Bin not cleaned regularly; lid not fully closed; highly odorous waste.	Clean the bin thoroughly. Ensure the lid is completely closed to utilize the odor seal feature. Consider emptying the bin more frequently for highly odorous waste.

SPECIFICATIONS

Feature	Detail
Brand	ELPHECO

Feature	Detail
Model	1.8 Gallon Hanging Trash Can
Capacity	1.8 gallons
Color	White
Material	Plastic
Dimensions (L x W x H)	10.5" x 6" x 8.5"
Opening Mechanism	Manual-Lift Sliding Lid
Special Features	Odor Seal, Sturdy, Four Rubber Flaps for Bag Security, Drawstring Design Compatibility
Recommended Use	Kitchen, Bathroom, Office, RV, Camper



WARRANTY AND SUPPORT

Warranty Information

ELPHECO products are manufactured with quality and durability in mind. For specific warranty details, please refer to the product packaging or contact ELPHECO customer service.

Customer Support

If you encounter any issues or have questions regarding your ELPHECO Kitchen Compost Bin, please contact our customer support team. Contact information can typically be found on the product packaging or the official ELPHECO website.

© 2026 ELPHECO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question