Deejoy 8035B

Deejoy Kids Tool Bench with Electric Drill - Instruction Manual

1. Important Safety Information

Please read all instructions before assembly and use. Keep this manual for future reference.

- **Recommended Age:** This toy is suitable for children aged 36 months to 12 years.
- **Material Safety:** The Deejoy Kids Tool Bench is constructed from high-quality ABS plastic, ensuring durability and environmental safety. It features a smooth surface with no sharp edges.
- **Adult Supervision:** Adult supervision is recommended during play, especially during initial assembly and when using the electric drill.
- **Battery Safety:** The electric drill requires 2 AA batteries (not included). Ensure batteries are inserted with correct polarity. Do not mix old and new batteries. Remove batteries if the toy is not used for extended periods.
- **Choking Hazard:** Contains small parts (screws, nuts, bolts). Not suitable for children under 3 years due to potential choking hazards.

2. Package Contents

Verify that all components listed below are present in your package:

- Workbench base and frame components
- Electric drill with interchangeable drill bits
- Hand tools: screwdriver, mechanical miter saw, claw hammer, various wrenches, pliers, hand saw
- Assorted screws, nuts, and bolts
- Decorative stickers
- Small accessory containers



Image: All components included in the Deejoy Kids Tool Bench set.

3. Setup and Assembly

The Deejoy Kids Tool Bench features a 2-in-1 design, allowing it to be assembled as a standing workbench or stored compactly as a toolbox. Follow these steps for assembly:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Base:** Connect the workbench base components. Ensure all parts click securely into place.

3. **Attach Legs:** Insert the four legs into the designated slots on the underside of the workbench base.
4. **Install Back Panel:** Secure the orange back panel (pegboard) to the upright supports.
5. **Add Side Trays:** Attach the small yellow screw boxes to the sides of the back panel.
6. **Place Tools:** Organize the various tools and accessories onto the workbench surface and into the storage trays.
7. **Apply Stickers:** Personalize your workbench by applying the provided decorative stickers to the designated areas.

Your browser does not support the video tag.

Video: Watch a demonstration of the Deejoy Kids Tool Bench assembly and transformation into a portable toolbox.

Your browser does not support the video tag.

Video: Detailed overview of the Deejoy Pretend Play Kids Workbench, including its electronic toy drill and various accessories.

4. Operating Instructions

Engage in imaginative play with the various tools provided:

- **Electric Drill:** Insert 2 AA batteries into the drill. Use the upper button for reverse extraction and the down button to rotate in. The drill is bidirectional and comes with two interchangeable drill bits.
- **Miter Saw:** The mechanical miter saw can be used to simulate cutting the included wooden block.
- **Hand Saw:** Use the hand saw to pretend to cut materials on the workbench surface.
- **Hammer:** Practice hammering the plastic nails into the designated holes on the workbench.
- **Wrenches and Pliers:** Use the various wrenches (socket wrench, adjustable wrench) and pliers to tighten or loosen the included nuts and bolts.
- **Screwdriver:** Utilize the screwdriver with the screws and nuts for assembly and disassembly activities.




Image: Demonstrating the use of various tools on the workbench.



Image: Close-up of the electric drill with battery and bit details.

5. Maintenance

- **Cleaning:** Wipe down the workbench and tools with a damp cloth as needed. Avoid harsh chemicals.
- **Storage:** The workbench can be disassembled and transformed back into a compact toolbox for easy storage and portability. Ensure all small parts are stored in the designated trays or the main toolbox compartment to prevent loss.

6. Troubleshooting

- **Electric Drill Not Working:** Check if the batteries are inserted correctly with the right polarity. Replace with fresh AA batteries if necessary.
- **Missing Parts:** Refer to the package contents list. If any parts are missing upon arrival, please contact customer support.
- **Difficulty Assembling:** Review the assembly instructions and accompanying video. Ensure all connections are firm.

7. Specifications

Feature	Detail
Product Dimensions	15.7 x 10.43 x 6.1 inches
Item Weight	3.89 pounds
Item Model Number	8035B
Manufacturer Recommended Age	36 months - 12 years
Material	High-quality ABS Plastic


TOOLS
GLUE
NO.1
TOOLS WORKBENCH
TOOLS
TOOLS
TOOLS
24.6in
10.4in
20in



TOOLS
TOOLS
9.8in
6.1in
15.7in

Image: Product dimensions for the Deejoy Kids Tool Bench.

8. Warranty and Support

Your satisfaction is important to us. If you encounter any issues or are not satisfied with your Deejoy Kids Tool Bench for any reason, please contact us immediately for assistance. We are committed to providing support and resolving any concerns you may have.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question