

[Manuals.plus](#) /

› [ZOWEETEK](#) /

› ZOWEETEK Charging Plug (Model ZOWEETEK-CP1-US) Instruction Manual

ZOWEETEK ZOWEETEK-CP1-US

ZOWEETEK Charging Plug (Model ZOWEETEK-CP1-US) Instruction Manual

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your ZOWEETEK Charging Plug, Model ZOWEETEK-CP1-US. Please read these instructions carefully before using the product and retain them for future reference.

2. PRODUCT OVERVIEW

The ZOWEETEK Charging Plug is a compact and reliable USB B wall charger designed to provide power to compatible electronic devices. It features a standard USB-A port for connecting charging cables.



Image 2.1: Front view of the ZOWEETEK Charging Plug, showing the USB-A port and US-style prongs.

Key Features:

- USB B Wall Charger
- DC 5V 500mAh output
- Constructed from durable ABS material
- Compatible with ZOWEETEK voice amplifiers (models Z258, S615)

3. SPECIFICATIONS

Feature	Detail
Model Number	ZOWEETEK-CP1-US
Input Voltage	100-240V AC, 50/60Hz
Output Voltage	5 Volts (DC)

Feature	Detail
Output Current	500mAh
Wattage	2.5 watts
Connector Type	USB-A
Total USB Ports	1
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Black
Item Weight	1.76 ounces
Package Dimensions	5.75 x 5.2 x 1.54 inches
Compatible Devices	Smartphones, Tablets, ZOWEETEK Voice Amplifiers (Z258, S615)



Image 3.1: ZOWEETEK Charging Plug with labeled dimensions (36.3mm height, 39.2mm width, 62mm length, 25.5mm prong height).

4. SETUP

The ZOWEETEK Charging Plug is designed for straightforward use. No complex assembly is required.

Steps for Initial Setup:

1. **Unpack:** Carefully remove the charging plug from its packaging.
2. **Inspect:** Check the charging plug for any visible damage. Do not use if damaged.
3. **Prepare:** Ensure you have a compatible USB charging cable for your device. The product includes two USB cables.



Image 4.1: Angled view of the ZOWEETEK Charging Plug, highlighting the USB-A output port.

5. OPERATING INSTRUCTIONS

Follow these steps to charge your compatible electronic devices using the ZOWEETEK Charging Plug.

Charging Procedure:

1. **Connect USB Cable:** Insert the USB-A end of your charging cable into the USB port on the ZOWEETEK Charging Plug.
2. **Plug into Wall Outlet:** Insert the charging plug firmly into a standard 100-240V AC wall outlet.
3. **Connect to Device:** Connect the other end of the USB charging cable to your electronic device (e.g., smartphone, tablet, ZOWEETEK voice amplifier).
4. **Verify Charging:** Confirm that your device indicates it is charging.

5. **Disconnect:** Once charging is complete, disconnect the cable from your device, then remove the charging plug from the wall outlet.

Important Safety Note:

- Do not force the plug into an outlet.
- Do not use the charger in wet conditions.
- Unplug the charger when not in use.

6. MAINTENANCE

Proper care and maintenance will ensure the longevity and safe operation of your ZOWEETEK Charging Plug.

Cleaning:

- Ensure the charging plug is disconnected from the power outlet before cleaning.
- Wipe the exterior with a soft, dry cloth.
- Do not use liquid cleaners, aerosols, or harsh chemicals.

Storage:

- Store the charging plug in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep out of reach of children and pets.

7. TROUBLESHOOTING

If you encounter issues with your ZOWEETEK Charging Plug, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging	Loose connection, faulty cable, power outlet issue, incompatible device.	Ensure all connections are secure. Try a different USB cable. Test the outlet with another device. Verify your device is compatible with 5V/500mAh charging.
Charger feels hot	Normal operation (slight warmth), excessive load, poor ventilation.	A slight warmth is normal. If it's excessively hot, unplug immediately. Ensure adequate ventilation around the charger. Do not cover it.
Slow charging	Cable quality, device's charging input limit, background apps on device.	Use a high-quality USB cable. Note that some devices may draw less than 500mAh or have specific charging requirements. Close unnecessary background applications on your device.

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your ZOWEETEK Charging Plug, please refer to the documentation included with your purchase or visit the official ZOWEETEK website. You may also contact ZOWEETEK customer service directly for assistance.

Manufacturer: ZOWEETEK

Contact Information: Please refer to the ZOWEETEK official website or product packaging for the most current support contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B1V8RCQJ>

More documents and user manuals: <https://manuals.plus/>