Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Yaheetech /
- > Yaheetech Rocking Living Room Chair (Model 35001415762152) Instruction Manual

Yaheetech 35001415762152

Yaheetech Rocking Living Room Chair (Model 35001415762152) - Instruction Manual

Your guide to assembly, operation, and maintenance.

1. Introduction

Thank you for choosing the Yaheetech Rocking Living Room Chair. This upholstered glider chair is designed to provide comfort and style to your living space, nursery, bedroom, or lounge area. Featuring a high back, comfy armrests, and a convenient side pocket, it offers a gentle rocking motion for relaxation. This manual provides essential information for safe assembly, proper use, and maintenance of your new chair.



Image 1: The Yaheetech Rocking Living Room Chair in Beige.

2. SAFETY INFORMATION

- Maximum Weight Capacity: Do not exceed the maximum weight capacity of 136 kg (300 lb).
- Stable Surface: Ensure the chair is placed on a stable and even surface to prevent tipping.
- Assembly: Always follow the assembly instructions carefully for safe and correct setup.
- Anti-Tipping Stoppers: The installed plastic stoppers at the ends of the chair legs are designed to prevent tipping backward. Do not remove or modify them.

3. PACKAGE CONTENTS

Before beginning assembly, please ensure all parts are present and undamaged. Refer to the illustrated manual provided in the package for a detailed list of components and hardware.



Image 2: Unpacked components including the seat, backrest, rocking base, and hardware.

4. SETUP AND ASSEMBLY INSTRUCTIONS

The Yaheetech Rocking Living Room Chair is designed for quick and easy assembly, typically within 20 minutes with one person. All necessary hardware and tools are included.

- 1. Attach the backrest to the seat frame using the provided bolts and Allen key. Ensure the connection is secure.
- 2. Assemble the wooden rocking base by connecting the horizontal rails to the curved rockers.
- 3. Attach the assembled rocking base to the bottom of the seat frame using the remaining bolts.
- 4. Verify all connections are tightened securely before using the chair.



Image 3: Visual guide for the chair's assembly steps.

Assembly Video Guide

Your browser does not support the video tag.

Video 1: Official Yaheetech Rocking Accent Chair Installation & Show. This video demonstrates the complete assembly process.

5. OPERATING INSTRUCTIONS

Once assembled, your rocking chair is ready for use. The gentle rocking motion is designed for relaxation and comfort.

- To rock, simply lean back and push off gently with your feet. The solid wood rocking base ensures a smooth and effortless motion.
- Utilize the integrated side pocket to keep small items like books, magazines, remote controls, or mobile phones conveniently within reach.
- The high back design provides ample support for your head and neck, making it ideal for extended periods of sitting, reading, or napping.



Image 4: Enjoying the comfort and rocking motion of the chair.

ULTIMATE RELAXATION





Image 5: The convenient side pocket for storage.

6. MAINTENANCE

To ensure the longevity and appearance of your Yaheetech Rocking Living Room Chair, follow these simple maintenance guidelines:

- Cleaning: Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the fabric or wood finish.
- Spills: For spills, blot immediately with a clean, dry cloth. Do not rub.
- **Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary.
- Sunlight Exposure: Avoid prolonged exposure to direct sunlight to prevent fading of the fabric.

7. TROUBLESHOOTING

If you encounter any issues with your rocking chair, consider the following:

• Unstable Rocking: Ensure the chair is on a flat, even surface. Check that all assembly bolts are

securely tightened.

- **Squeaking Noise:** Inspect the connections of the rocking base. Apply a small amount of lubricant (e.g., silicone spray) to the joints if necessary, ensuring it does not come into contact with the fabric.
- Loose Parts: Re-tighten any loose bolts or screws immediately to maintain stability and safety.

8. SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model Number	35001415762152
Color	Beige
Product Dimensions	39"D x 28"W x 41"H
Material	Polyester Fabric, Rubber Wood Legs, High-Density Foam
Maximum Weight Capacity	300 Pounds (136 kg)
Special Features	Arm Rest, Side Pocket, Anti-Tipping Stoppers
Product Care Instructions	Wipe Clean
Assembly Time	Approx. 20 minutes (1 person)




Image 6: Key dimensions of the rocking chair.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your Yaheetech Rocking Living Room Chair, please contact Yaheetech customer service. Refer to your purchase documentation for specific warranty details and contact information.

You can also visit the official Yaheetech Store for more product information and support.

© 2025 Yaheetech. All rights reserved.





Yaheetech 592506 Black Office Chair Assembly Instructions

Comprehensive guide for assembling the Yaheetech 592506 Black ergonomic office chair, including parts identification, step-by-step instructions, and maintenance tips.