Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Braun /
- > Braun Silk-épil 3 3-176 Epilator User Manual

Braun 3-176

Braun Silk-épil 3 3-176 Epilator User Manual

Model: 3-176

INTRODUCTION

The Braun Silk-épil 3 3-176 epilator is designed for effective and gentle hair removal, ideal for beginners. Its 20-tweezer system removes hair from the root, providing smooth skin for weeks. The integrated massage rollers help stimulate the skin, making the epilation process more comfortable. This corded device ensures consistent power without the need for recharging.



Image: Front view of the Braun Silk-épil 3 3-176 epilator, showcasing its ergonomic design and epilation head.

SETUP

Follow these steps to prepare your Braun Silk-épil 3 3-176 epilator for first use:

- 1. Unpack the Device: Carefully remove the epilator and all accessories from its packaging.
- 2. **Connect to Power:** Use the provided special cable to connect the epilator to an electrical outlet. Ensure the voltage matches the specifications printed on the cable.
- 3. Inspect the Head: Verify that the epilator head is securely attached.



Image: The Braun Silk-épil 3 3-176 epilator with its power cord connected, ready for use.

OPERATING INSTRUCTIONS

For optimal results and comfort, follow these operating guidelines:

- 1. **Prepare Your Skin:** Ensure your skin is clean and dry before epilation. Exfoliating beforehand can help prevent ingrown hairs.
- 2. **Select Speed:** Turn the power switch to select your desired epilation speed. The device typically offers two speed settings for different areas and hair types.
- 3. **Activate Smartlight:** The integrated Smartlight illuminates even the finest hairs, ensuring thorough removal.

- 4. **Epilate:** Gently glide the epilator over your skin against the direction of hair growth. Hold the skin taut with your free hand to minimize discomfort. Do not press too hard.
- 5. **Target Areas:** The epilator is suitable for legs, arms, underarms, and bikini line. Its design adapts to body contours for efficient hair removal.
- 6. **Post-Epilation Care:** After epilation, apply a soothing lotion to moisturize your skin.




Image: A user demonstrating epilation on the leg, holding the skin taut for effective hair removal.



Image: A user demonstrating epilation on the thigh, showing the device's maneuverability.



Image: A close-up view of the epilator's power switch and the illuminated Smartlight feature.

MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your epilator:

- 1. Disconnect from Power: Always unplug the epilator from the electrical outlet before cleaning.
- 2. Clean the Epilation Head: Use the cleaning brush provided to remove any trapped hairs from the tweezer system. For thorough cleaning, the epilator head can often be detached and rinsed under running water (refer to the full manual for specific water-resistance details).
- 3. Dry Thoroughly: Ensure all parts are completely dry before reassembling or storing the device.
- 4. **Storage:** Store the epilator in a dry, safe place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

If you encounter issues with your Braun Silk-épil 3 3-176, consider the following:

• Device Not Turning On: Ensure the epilator is properly connected to a functioning electrical outlet. Check

the power cable for any damage.

- **Reduced Performance:** Clean the epilation head thoroughly to remove any accumulated hair or debris that might be affecting the tweezers. Ensure the head is correctly attached.
- **Discomfort During Use:** Ensure your skin is taut and the epilator is glided gently against hair growth. If discomfort persists, try a slower speed setting.
- **Skin Irritation:** Always epilate on clean, dry skin. Apply a soothing lotion after use. If irritation is severe or persistent, discontinue use and consult a dermatologist.

For more complex issues, please refer to the full manufacturer's manual or contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Braun
Model Name	3 3-176
Item Model Number	4210201423522
Color	Rose/White
Power Source	Corded Electric
Included Components	Charger
Recommended Uses	Long-lasting epilation on legs, arms, underarms, and bikini line
Package Dimensions	14.2 x 11.8 x 5.8 cm; 310 grams
Country of Origin	Germany
International Article Number (EAN)	04210201423522

WARRANTY INFORMATION

For detailed warranty information regarding your Braun Silk-épil 3 3-176 epilator, please refer to the warranty card included in the product packaging or visit the official Braun website. Warranty terms and conditions may vary by region.

CUSTOMER SUPPORT

If you require further assistance, have questions about your device, or need to report an issue, please contact Braun customer support. Contact details can typically be found on the official Braun website or in the product documentation.

Online Resources: Visit the official Braun website for FAQs, product registration, and additional support materials.

Related Documents - 3-176



Braun Silk-expert Pro 3 IPL Hair Removal Device - User Manual and Guide

Comprehensive user manual for the Braun Silk-expert Pro 3 IPL hair removal device. Learn about its features, how to use it safely, contraindications, treatment methods, troubleshooting, and technical specifications.



Braun Silk-expert Pro 5 IPL Hair Removal Device User Manual

Comprehensive user manual for the Braun Silk-expert Pro 5 Intense Pulsed Light (IPL) hair removal device. Learn about its features, how to use it safely, contraindications, troubleshooting, and maintenance for effective and comfortable home hair removal.



Braun Silk-épil 3 User Manual

Comprehensive user manual for the Braun Silk-épil 3 epilator, covering operation, cleaning, and maintenance for effective hair removal.



Braun Silk-épil 3 Epilator User Manual and Guide

Detailed user manual for the Braun Silk-épil 3 epilator (models 5320, 3270). Provides comprehensive instructions on epilation techniques, shaver head usage, cleaning, safety precautions, and product care for effective hair removal.



Braun Silk&Soft LS 5560 Bedienungsanleitung

Entdecken Sie den Braun Silk&Soft LS 5560 Damenrasierer für eine sanfte und gründliche Rasur von Beinen, Achseln und der Bikini-Zone. Enthält Anleitungen zur Verwendung, Reinigung, Pflege und Garantieinformationen.



Braun Silk-épil 7 User Manual

Comprehensive user manual for the Braun Silk-épil 7 epilator, covering features, operation, safety precautions, and maintenance.