XTREME DIGITAL LIFESTYLE ACCESSORIES MTH9-1002-BLK

Monster Wireless Headset Kit User Manual

Model: MTH9-1002-BLK

Introduction

The Monster Wireless Headset Kit provides a seamless audio experience for your TV and gaming consoles. Designed for convenience and superior sound quality, this kit allows you to enjoy your entertainment without disturbing others, thanks to its noise isolation features and wireless connectivity.
This manual provides detailed instructions for setting up, operating, and maintaining your new wireless headset kit.

What's Included

Your Monster Wireless Headset Kit package should contain the following items:

- Wireless Neckband Headset
- Bluetooth Audio Transceiver
- USB Wall Adapter
- 3 Pairs of Ear Cushions (different sizes)
- Ear Fins
- Auxiliary Audio Cable (3.5mm)
- Optical Audio Cable



Image: Contents of the Monster Wireless Headset Kit, including the neckband headset, transceiver, and packaging.

Setup and Installation

Follow these steps to set up your Monster Wireless Headset Kit:

1. **Prepare the Transceiver:**

   The audio transceiver is designed for easy installation. Remove the protective tape from the back of the transceiver to expose the self-adhesive surface. Attach the transceiver to a flat, clean surface near your TV or gaming console. Ensure it is placed in a location that allows for easy access to its ports and a clear line of sight for optimal wireless performance.



Image: The compact audio transceiver discreetly mounted on the back of a television, demonstrating its easy installation.

2. **Power Connection:**

   Connect the provided USB Wall Adapter to the DC 5V port on the transceiver. Plug the USB Wall Adapter into a standard wall outlet. Alternatively, if your TV or gaming console has a powered USB port, you can connect the transceiver directly to it for instant power.



Image: A detailed view of the transceiver's ports, including AUX IN/OUT, Optical IN, and DC 5V for power connection.

3. **Audio Connection:**

   Connect the transceiver to your audio source (TV, gaming console, etc.) using either the Auxiliary (3.5mm) cable or the Optical cable, depending on the available output ports on your device. For optimal digital audio quality, the Optical connection is recommended if supported by your device.



Image: The wireless headset and transceiver shown with the auxiliary and optical audio cables connected, ready for use.

4. **Headset Preparation:**

   Select the ear cushions and ear fins that best fit your ears for comfort and secure placement. The kit includes three different sizes of ear cushions to ensure a proper fit. Gently attach the chosen ear cushions and fins to the headset earbuds.

5. **Pairing:**

   The headset and transceiver are designed to pair automatically upon power-up. Ensure both devices are powered on. The light indicator on the transceiver will show its pairing status. Once paired, you will hear an audible confirmation in the headset.



Image: The transceiver's power button illuminates to indicate its operational status and pairing activity.

Operating Instructions

Once set up, your Monster Wireless Headset Kit is ready for use.

- **Audio Streaming:**

  The system allows you to stream audio from your TV or gaming console directly to the headset. This is ideal for watching movies or playing games without disturbing others in the room.



Image: A man enjoying television with the wireless headset, allowing others nearby to sleep undisturbed.

- **Noise Isolation:**

  The headset features noise isolation technology to block out distracting background sounds, ensuring a clear and immersive audio experience. This enhances sound quality and allows you to focus on your content.

- **Controls:**

  The headset incorporates media control functions, typically accessible via touch controls on the neckband or earbuds. These controls allow you to manage playback, adjust volume, and potentially answer calls if connected to a mobile device (though primarily designed for TV/gaming audio).

- **Wireless Range:**

  The Bluetooth connectivity provides a wireless range of up to 33 feet (approximately 10 meters) from the transceiver, offering flexibility in your viewing or gaming setup.

Maintenance and Care

Proper care will extend the life of your Monster Wireless Headset Kit:

- **Cleaning:** Use a soft, dry cloth to clean the headset and transceiver. Do not use abrasive cleaners or solvents. For ear cushions, a slightly damp cloth can be used, ensuring they are completely dry before reattaching.
- **Storage:** When not in use, store the headset and transceiver in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the headset frequently. Recharge the headset regularly, especially if it will not be used for an extended period.
- **Handling:** Handle the headset and transceiver with care. Avoid dropping them or exposing them to excessive force, as this can damage internal components.

Troubleshooting

If you encounter issues with your Monster Wireless Headset Kit, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No audio from headset	Headset not powered on. Headset not paired with transceiver. Transceiver not connected to audio source. Audio source volume too low or muted. Incorrect audio output selected on TV/console.	Ensure headset is charged and powered on. Verify pairing status (check transceiver light indicator). Re-pair if necessary. Check audio cables (Aux or Optical) are securely connected to both transceiver and audio source. Increase volume on the headset and the audio source. Confirm your TV or console's audio output is set to the correct port (e.g., Optical Out, Headphone Out).
Low volume or poor sound quality	Volume settings too low. Headset not properly seated in ears. Interference or distance from transceiver. Ear cushions not providing proper seal.	Adjust volume on both headset and audio source. Ensure earbuds are correctly inserted and ear fins are providing a secure fit. Move closer to the transceiver (within 33ft) and minimize obstacles. Try different sized ear cushions to achieve a better seal for noise isolation.
Headset not charging	Charging cable not connected properly. Faulty USB port or wall adapter.	Ensure the charging cable is securely connected to the headset and power source. Try a different USB port or wall adapter.
Ear cushions frequently detach	Incorrect size or improper attachment.	Ensure ear cushions are firmly attached to the earbuds. Try a different size if they consistently fall off.

Specifications

Model Name	MTH9-1002-BLK
Brand	XTREME DIGITAL LIFESTYLE ACCESSORIES

Connectivity Technology	Wireless (Bluetooth 4.0)
Bluetooth Range	33 Feet
Noise Control	Sound Isolation
Form Factor	In Ear (Neckband)
Compatible Devices	Televisions, Gaming Consoles
Power Source	USB-Powered (via USB Wall Adapter or TV USB port)
Included Components	USB Wall Adapter, 3 Ear Cushions, Fins
Material	Plastic
Item Weight	5.3 ounces
Package Dimensions	8.39 x 6.14 x 1.26 inches
UPC	805106894955

Warranty Information

For specific warranty details regarding your Monster Wireless Headset Kit, please refer to the warranty card included in your product packaging or visit the official XTREME DIGITAL LIFESTYLE ACCESSORIES website. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

Customer Support

If you require further assistance or have questions not covered in this manual, please contact XTREME DIGITAL LIFESTYLE ACCESSORIES customer support. Contact information can typically be found on the product packaging, the brand's official website, or through your retailer's support channels.
Please have your product model number (MTH9-1002-BLK) and purchase details ready when contacting support.

© 2024 XTREME DIGITAL LIFESTYLE ACCESSORIES. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question