

Rico FP1806

Rico FP1806 700W Mixer Grinder Food Processor

Instruction Manual

1. INTRODUCTION

Thank you for choosing the Rico FP1806 700W Mixer Grinder Food Processor. This appliance is designed to simplify your kitchen tasks with its versatile functions, including grinding, blending, mixing, coconut grating, atta kneading, and juicing. Equipped with a durable 100% copper motor, it offers efficient performance for various culinary needs. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Image: Rico Food Processor in a kitchen setting, showcasing its ability to transform ingredients.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the appliance.
- Do not immerse the motor unit in water or any other liquid.
- Keep hands and utensils away from moving blades during operation to prevent injury.
- Ensure the appliance is switched off and unplugged before assembling, disassembling, or cleaning.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Always ensure the lid is securely locked before operating.
- Do not overload the appliance. Refer to capacity guidelines for each jar.
- Keep out of reach of children.

3. PRODUCT COMPONENTS

The Rico FP1806 Food Processor comes with various attachments to perform multiple functions. Familiarize yourself with each component:



Image: All components of the Rico FP1806 Food Processor, including the main unit, jars, and blades.

- **Main Motor Unit:** The base unit housing the 700W copper motor with a 3-speed switch and pulse function.
- **1.5 Litre BPA-Free Blender Jar:** For blending liquids, smoothies, and purees.
- **1 Litre Dry Grinding Jar:** For grinding dry spices, coffee beans, and nuts.
- **400 ml Chutney Jar:** Ideal for preparing small quantities of chutneys and pastes.
- **1.7 Litre Atta Kneader:** For kneading dough for rotis, bread, etc.
- **Processing Bowl:** Large capacity bowl for chopping, slicing, shredding, and other food processing tasks.
- **Coconut Scraper:** Specialized attachment for grating fresh coconut.
- **Citrus Juicer:** For extracting juice from citrus fruits.
- **Centrifugal Juicer:** For extracting juice from various fruits and vegetables.
- **Multi-functional Blades/Discs:** Includes chopping blade, whipping blade, slicing disc, thick shredding disc, thin shredding disc, and French fry disc.



Image: A closer look at the various jars, blades, and the main unit of the food processor.

4. SETUP AND ASSEMBLY

Before first use, wash all removable parts (jars, blades, lids) with warm soapy water, rinse thoroughly, and dry. Wipe the motor unit with a damp cloth.

1. Place the motor unit on a stable, flat, and dry surface.
2. Select the appropriate jar or processing bowl for your task.
3. Insert the required blade or disc onto the spindle inside the jar/bowl. Ensure it is securely seated.
4. Add your ingredients to the jar/bowl. Do not exceed the maximum fill line.
5. Secure the lid onto the jar/bowl. Ensure it is properly locked into place.
6. Place the assembled jar/bowl onto the motor unit. Twist clockwise until it locks securely.
7. Plug the appliance into a suitable power outlet.

5. OPERATING INSTRUCTIONS

The Rico FP1806 offers 13 functions for diverse kitchen tasks. Always ensure the appliance is properly assembled and locked before starting.

Get 13 Function

Making Different Ingredient For You



Image: Visual representation of the 13 functions available with the Rico Food Processor.

5.1. Grinding (Dry/Wet)

- Use the 1 Litre Dry Grinding Jar for dry ingredients like spices, nuts, or coffee beans.
- For wet grinding (e.g., idli/dosa batter), use the Blender Jar or Dry Grinding Jar depending on quantity. Add a small amount of water if needed.
- Do not overfill. Operate in short bursts using the pulse function or low speed.

5.2. Blending

- Attach the 1.5 Litre Blender Jar with its blade.
- Add liquids and soft ingredients for smoothies, purees, or milkshakes.
- Start at a low speed and gradually increase if necessary. Use the pulse function for controlled blending.

5.3. Chopping, Slicing, Shredding

- Use the Processing Bowl with the appropriate blade (chopping blade) or disc (slicing, thick/thin shredding, French fry).
- For chopping, add ingredients to the bowl and use the pulse function for desired consistency.

- For slicing/shredding, place the disc on the spindle, secure the lid, and feed ingredients through the feeder tube.

5.4. Kneading Dough

- Attach the 1.7 Litre Atta Kneader to the motor unit.
- Add flour and water in the recommended proportions (refer to recipes for best results).
- Operate at a low speed until a smooth dough is formed.

5.5. Juicing (Citrus & Centrifugal)

- **Citrus Juicer:** Attach the citrus juicer cone and bowl. Press halved citrus fruits onto the cone while operating.
- **Centrifugal Juicer:** Assemble the centrifugal juicer attachment. Feed fruits/vegetables through the chute.



Game-Changer

Coconut Scraping

No One Else Has This Feature!

Image: The juicer attachment in action, extracting fresh juice.

5.6. Coconut Scraping

- Attach the coconut scraper attachment to the motor unit.
- Hold a halved coconut firmly against the rotating scraper blade.
- Ensure stable grip and caution during operation.



13 Functions in One Food Processor

Image: The coconut scraper attachment efficiently processing coconut.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance ensure the longevity and hygiene of your appliance.

- Always unplug the appliance before cleaning.
- Disassemble all removable parts (jars, blades, lids).
- Wash these parts with warm, soapy water. Rinse thoroughly and dry immediately.
- The jars and bowls are generally dishwasher safe, but hand washing is recommended for blades to maintain sharpness.
- Wipe the motor unit with a damp cloth. Never immerse the motor unit in water.
- Do not use abrasive cleaners or scouring pads, as they may scratch surfaces.
- Store the appliance and its accessories in a clean, dry place.

7. TROUBLESHOOTING

If you encounter issues with your Rico FP1806, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not start	Not plugged in; Jar/lid not locked correctly; Overload protection activated.	Check power connection; Ensure all parts are securely locked; Unplug, wait 15 minutes, reduce load, then restart.
Poor grinding/blending performance	Insufficient liquid; Overloaded jar; Dull blade.	Add more liquid; Reduce ingredient quantity; Check blade for damage/dullness.
Loud noise/Vibration	Improper assembly; Unstable surface; Hard ingredients.	Reassemble parts correctly; Place on a stable surface; Cut hard ingredients into smaller pieces.
Leakage from jar	Lid not sealed properly; Gasket missing/damaged; Overfilled jar.	Ensure lid is tight; Check and replace gasket if necessary; Do not exceed max fill line.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

- **Brand:** Rico
- **Model Name:** FP1806
- **Wattage:** 700 Watts
- **Motor:** 100% Copper Motor
- **Number of Speeds:** 3 + Pulse
- **Product Dimensions:** 37D x 37W x 40H Centimeters
- **Item Weight:** 7000 Grams
- **Material:** Acrylonitrile Butadiene Styrene (ABS)

- **Bowl Capacity:** 2.3 Liters
- **Blender Jar Capacity:** 1.5 Liters (BPA-Free)
- **Dry Grinding Jar Capacity:** 1 Liter
- **Chutney Jar Capacity:** 400 ml
- **Included Components:** Coconut Scrapper, 1 Food Processor, 3 Jars, 1 Processing Bowl
- **Product Care Instructions:** Hand Wash (Dishwasher safe for some parts)

700 Watts Copper Motor With 3-Speed Switch with Pulse



Image: Illustration of the 700 Watts Copper Motor and 3-speed switch with pulse function.

9. WARRANTY AND SUPPORT

Your Rico FP1806 Mixer Grinder Food Processor comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable after-sales service across India.

Customer Support:

- **Email:** service@rico.in
- **Phone:** +91 88794 44877
- **Service Center No:** +91 8879444877

- **Operating Hours:** 9 AM - 7 PM, Monday - Sunday

For product demonstrations, warranty registration, or any other queries, please contact our dedicated customer care team.

DEDICATED CUSTOMER SUPPORT

✉ service@rico.in

📞 (+91) 887 944 4877



Quality Product Exported World Wide



Please speak to our Customer Care Team For
Product Demo, Warranty Registration & Other Query

9AM - 7PM
Mon-Sun

Image: Information regarding Rico's dedicated customer support and service promise.