

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Freezimer](#) /

› [Freezimer Countertop Ice Maker Instruction Manual](#)

## Freezimer HIM-35B

# Freezimer Countertop Ice Maker Instruction Manual

Model: HIM-35B

Brand: Freezimer

## PRODUCT OVERVIEW

---

The Freezimer Countertop Ice Maker is designed for convenience and efficiency, producing up to 33 pounds of ice per day. It features fast ice making, a user-friendly control panel, and a self-cleaning function, making it ideal for home kitchens, offices, parties, and bars.



The Freezimer Countertop Ice Maker, showcasing its sleek black design and compact size.

## WHAT'S INCLUDED

---

Your Freezimer Ice Maker package contains the following items:

- 1 x Ice Maker Machine
- 1 x Ice Scoop
- 1 x Ice Basket

# Electric ice maker features



An exploded view of the ice maker, highlighting the ice basket and scoop.

## IMPORTANT SAFEGUARDS

To ensure safe operation and prolong the life of your ice maker, please observe the following:

- Always place the ice maker upright for at least 24 hours before initial use. This allows the refrigerant to settle.
- Do not continuously switch the unit on and off to prevent damage to the compressor. If restarting, wait for 45 seconds.
- Use only potable water.
- Keep the appliance away from heat sources and direct sunlight.
- Ensure proper ventilation around the unit.

## SETUP GUIDE

---

### 1. Unpacking

Carefully remove the ice maker and all accessories from the packaging. Inspect the unit for any damage.

### 2. Initial Placement

Place the ice maker on a stable, level surface. Allow the unit to stand upright for at least 24 hours before plugging it in. This is crucial for the compressor's longevity.

### 3. Adding Water

Open the top lid and remove the ice basket. Fill the water reservoir with clean, potable water up to the 'MAX' water line indicated inside the reservoir. Do not overfill.



Step 1: Pour water into the water tank, ensuring it does not exceed the Max line.

## OPERATING INSTRUCTIONS

---

### 1. Powering On and Selecting Ice Size

After adding water and replacing the ice basket, plug the unit into a grounded electrical outlet. Press the 'ON/OFF' button to power on the ice maker. Use the 'SELECT' button to choose your desired ice cube size: 'LARGE' or 'SMALL'. The indicator light will illuminate next to your selection.

## Step 1

Pull water into the water tank, please don't exceed the Max line



## Step 2

Press the ON/OFF button, select ice tubes size to make ice( 6-9 minutes)



## Step 3

Use the ice scoop to fetch the cubes when ice is ready




Step 2: Press the ON/OFF button, then select the ice cube size (LARGE or SMALL).

## 2. Ice Making Process

The ice maker will begin producing ice cubes. For small cubes, a batch is ready in approximately 6 minutes. For large cubes, it takes slightly longer. The unit can produce up to 33 pounds of ice in 24 hours.

# 9 ICE CUBES READY IN 6 MINS



The ice making process: 9 cubes are ready in 6 minutes.

Video demonstrating the steps for making ice with the Freezimer ice maker.

## 3. Indicators

- **"ADD WATER" Indicator:** This light will turn on when the water reservoir is low. Refill the reservoir to continue ice production.
- **"ICE FULL" Indicator:** This light will turn on when the ice basket is full. The ice maker will automatically pause production until ice is removed.



The control panel with indicator lights for various functions and statuses.

## CLEANING AND MAINTENANCE

---

### 1. Self-Cleaning Function

The Freezimer ice maker is equipped with a convenient self-cleaning system:

1. Ensure the water reservoir is filled with clean water.
2. Long-press the 'ON/OFF' button for 5 seconds. The machine will enter self-cleaning mode.
3. Once cleaning is complete, open the small rubber stopper at the bottom of the unit to drain the dirty water.

# Convenient Self-Cleaning Function



Button #1  
**Ice Full**



Button #2  
**Add water**



Button #3  
**Claen**



Button #4  
**Large**



Button #5  
**Small**



The convenient self-cleaning function, activated by long-pressing the ON/OFF button.

## 2. Draining Water

To drain water from the unit, locate the rubber stopper at the bottom of the ice maker. Place a container underneath and remove the stopper to allow water to drain completely.

Video demonstrating the use of the Freezimer ice maker for blending drinks, highlighting its versatility.

## 3. General Cleaning

Regularly wipe down the exterior with a soft, damp cloth. For the interior, use a mild detergent and water, then rinse thoroughly. Ensure all parts are dry before reassembling.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
"ADD WATER" light is on, but reservoir is full.	Water sensor malfunction or obstruction.	Ensure the water sensor is clean and unobstructed. Try restarting the unit.
Ice is not forming or is too small.	Insufficient water, low ambient temperature, or compressor issue.	Check water level. Ensure room temperature is within operating range. If problem persists, contact support.
Ice maker is noisy.	Normal operation sounds (compressor, fan, ice dropping) or unit not level.	Ensure the unit is on a stable, level surface. Some operational noise is normal.
Ice cubes are sticking together.	Ice is melting and refreezing, or too much ice in the basket.	Empty the ice basket regularly. Consider transferring ice to a freezer for long-term storage.

## PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	Ice Maker Machine for Countertop
Product Dimensions	11"D x 9.4"W x 13.9"H
Capacity	33 Pounds (per 24 hours)
Wattage	98 watts
Voltage	120.0 Volts
Manufacturer	Freezimer
First Available	May 23, 2022

## WARRANTY AND SUPPORT

Freezimer offers a 12-month warranty for this self-cleaning ice maker. If you encounter any problems or have questions regarding your product, please feel free to contact Freezimer customer support for assistance.