



Manuals.plus /

› megacom /

› megacom DuoMon 2ID Auto Catcher User Manual

megacom DUOMON

megacom DuoMon 2ID Auto Catcher User Manual

Model: DUOMON

1. INTRODUCTION AND OVERVIEW

The megacom DuoMon 2ID is an automatic catch and spin accessory designed for Pokémon Go players. It allows for hands-free collection of items from PokéStops and automatic catching of Pokémon, enhancing your gameplay experience. This device supports simultaneous connection for two player accounts and features a voice broadcast function for real-time notifications. Its compact design and long battery life make it ideal for on-the-go use.

Connect to Two Phones Simultaneously

Simply connect to POGO via Bluetooth



Easy Pairing



Auto Catch



Auto Spin



No APP Needed

Image 1.1: The megacom DuoMon 2ID device, illustrating its compact size and connectivity with a smartphone running Pokémon Go.

2. SETUP

2.1. Battery Installation

1. Locate the battery compartment on the back of the DuoMon 2ID device.
2. Open the battery compartment cover.
3. Insert two new AAA alkaline batteries (not included), ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2.2. Powering On/Off

To power on the device, slide the 'ON/OFF' switch to the 'ON' position. To power off, slide the switch to 'OFF'.

2.3. Initial Bluetooth Pairing

1. Ensure your smartphone's Bluetooth is enabled.
2. Open the Pokémon Go application on your smartphone.

3. In the Pokémon Go app, navigate to the Main Menu > Settings > Pokémon Go Plus.
4. Press the 1P or 2P button on the DuoMon 2ID device to activate it for pairing. The corresponding LED will flash.
5. Tap the flashing Pokémon Go Plus icon on your phone screen to connect. Once connected, the icon will turn solid, and the DuoMon 2ID LED will stop flashing.
6. Repeat for the second player if using dual accounts.



Image 2.1: Visual guide for connecting the DuoMon 2ID to the Pokémon Go application via Bluetooth.

3. OPERATING INSTRUCTIONS

3.1. Auto-Catch and Auto-Spin Functions

Once connected, the DuoMon 2ID will automatically attempt to catch nearby Pokémon and spin PokéStops. Ensure that the 'Nearby Pokémon' and 'Nearby PokéStops' options are enabled within your Pokémon Go Plus settings in the app.

3.2. Voice Broadcast Function

The device features a voice broadcast function that provides audible updates on your gameplay, such as:

- Quantity of Pokémon caught or PokéStops spun.
- Notification of lost connection.
- Alerts when your item bag is full.
- Alerts when your Pokémon storage is full.



Image 3.1: The DuoMon 2ID provides voice notifications for various in-game events, keeping you informed without needing to check your phone.

3.3. Customizing Notifications (LED, Beeping, Vibration)

The DuoMon 2ID offers customizable notification modes:

- **Yellow LED:** Indicates sound settings.
- **Purple LED:** Indicates vibration settings.
- **White LED:** Indicates new Pokémon alert settings.

Refer to the device's specific button press combinations (usually a long press or multiple presses on the 1P/2P buttons) to cycle through or toggle these notification modes. This allows you to adjust the device's feedback to your preference.



Image 3.2: Detailed view of the DuoMon 2ID's buttons and LED indicators for customizing notification settings.

3.4. Dual Account Connection

The DuoMon 2ID supports connecting two separate Pokémon Go accounts simultaneously. Each account connects to a dedicated player slot (1P and 2P) on the device, allowing two users to benefit from auto-catching and spinning with a single device.



Image 3.3: The DuoMon 2ID facilitates simultaneous connection to two phones, enabling dual account usage for Pokémon Go.

3.5. One-Touch Reconnection

After an initial successful pairing, the DuoMon 2ID offers a one-touch reconnection feature. If the connection is lost, simply tap the Pokémon Go Plus icon within the Pokémon Go app on your phone to re-establish the connection quickly, without needing to re-pair the device.




Image 3.4: Reconnecting the DuoMon 2ID is simplified to a single tap on the smartphone screen, ensuring continuous gameplay.

4. FEATURES

- **Voice Broadcast:** Provides real-time audio notifications for caught Pokémon, spun PokéStops, full item bags, and full Pokémon storage.
- **Enhanced Catching and Item Collection Speed:** Optimized for faster connection and efficient replenishment of in-game items.
- **Stable Wireless Bluetooth Connection:** Maintains a reliable connection with your smartphone up to 20 meters (approximately 60 feet).
- **Dual Account Compatibility:** Connects to two Pokémon Go accounts simultaneously, allowing two players to use one device.
- **Long-Lasting Battery:** Operates for up to 600 hours on two AAA alkaline batteries, minimizing the need for frequent battery changes.
- **Compact and Lightweight Design:** Smaller than the palm of your hand, featuring a sturdy plastic casing and a lanyard keyring for easy portability.



Image 4.1: The DuoMon 2ID offers a wide and stable connection range, allowing for flexible use during outdoor activities.

5. SPECIFICATIONS

Feature	Detail
Model Name	DUOMON
Brand	megacom
Compatible Devices	Android, iPhone
Controller Type	Accessory
Connectivity Technology	Bluetooth
Additional Features	Wireless, Dual Account, Voice Broadcast
Button Quantity	1 (multi-function)
Hardware Platform	iOS, Android
Power Source	Battery Powered (2x AAA alkaline batteries)
Item Weight	26 Grams
Item Dimensions	2.36 x 2.36 x 0.51 inches
Manufacturer	SPERRY Corporation

6. TROUBLESHOOTING

6.1. Connection Issues

- **Device not connecting:** Ensure the DuoMon 2ID is powered on and within range of your smartphone. Clear all previous connection records for the Pokémon Go Plus in your phone's Bluetooth settings and the Pokémon Go app, then attempt to reconnect.
- **Frequent disconnections:** Check battery levels. Ensure there are no strong interferences from other Bluetooth devices. Keep the DuoMon 2ID and your phone in close proximity.



Image 6.1: If connection issues occur, clear existing Bluetooth pairings and reconnect the DuoMon 2ID.

6.2. Not Catching Pokémon or Spinning PokéStops

- **No activity:** Verify that the 'Nearby Pokémon' and 'Nearby PokéStops' options are enabled in your Pokémon Go Plus settings within the Pokémon Go app.
- **Full storage:** The device will stop catching or spinning if your Pokémon storage or item bag is full. Clear

space in your game inventory.

- **Out of Poké Balls:** The device only uses standard Poké Balls for auto-catching. Ensure you have a sufficient supply.




Image 6.2: Ensure 'Nearby Monster' and 'Pokestops' settings are active in the Pokémon Go app for the DuoMon 2ID to function correctly.

7. MAINTENANCE

7.1. Battery Replacement

When the device's performance declines or it fails to power on, replace the two AAA alkaline batteries as described in Section 2.1. Always use fresh, high-quality batteries for optimal performance.

7.2. Cleaning

Wipe the device with a soft, dry cloth to remove dust or smudges. Do not use liquid cleaners or abrasive materials, as these can damage the device.

8. WARRANTY AND SUPPORT

8.1. Warranty Information

The megacom DuoMon 2ID comes with a manufacturer warranty for 90 days from the date of purchase. Please retain your proof of purchase for any warranty claims.

8.2. Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official megacom website or contact their customer service department. Contact details can typically be found on the product packaging or the manufacturer's website.