Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kichler 310080NI

Kichler Tranquil 56-Inch 5-Blade LED Outdoor Ceiling Fan User Manual

Model: 310080NI

1. Product Overview

The Kichler Tranquil 56-Inch 5-Blade LED Outdoor Ceiling Fan is designed for covered outdoor spaces, offering both comfort and elegant design. It features an integrated, dimmable 3000K LED light and a brushed nickel finish with silver blades. The fan is controlled by a 65K CoolTouch Handheld Full Function Control System, allowing for light dimming, three-speed selection, and forward or reverse operation. Its steel body and lightweight ABS blades ensure maximum airflow and durability for long-term outdoor use.



Figure 1: Kichler Tranquil 56-Inch Outdoor Ceiling Fan. This image displays the complete ceiling fan assembly, highlighting its brushed nickel finish and five silver blades, along with the integrated LED light.

2. Safety Information

Before beginning installation, read all instructions carefully. Ensure the power is disconnected at the circuit breaker before wiring. All wiring must be in accordance with national and local electrical codes. This fan is suitable for damp locations, specifically covered outdoor patios and sunrooms. Do not use in direct exposure to water. Consult a qualified electrician if you are unsure about any part of the installation process. Always wear appropriate safety gear during installation.

3. What's in the Box

Verify that all components are present before beginning assembly:

- 5 Fan Blades
- 5 Blade Irons
- 1 4.5-inch Downrod
- 1 Canopy
- 1 Mounting Bracket
- 1 Motor/Housing
- 1 Glass Shade
- 1 Set of Mounting Hardware
- 1 Remote Control

4. Setup and Installation

Assembly is required for this ceiling fan. Follow the detailed instructions provided in the separate installation guide for proper setup. Ensure the mounting location can support the fan's weight (22.8 pounds). The fan is designed for down lighting mounting. Proper installation is crucial for safe and efficient operation.



Figure 2: Kichler Tranquil Ceiling Fan Dimensions. The fan has a total width of 56 inches, a height of 14.5 inches, and a canopy width of 6 inches.

5. Operating Instructions

The Kichler Tranquil ceiling fan is operated using the included 65K CoolTouch Handheld Full Function Control System. This remote allows you to:

- **Dim the integrated LED light:** Adjust the brightness of the 3000K LED light to your preference.
- **Select fan speed:** Choose from three distinct fan speeds for optimal air circulation.
- **Change fan direction:** Switch between forward and reverse modes to suit seasonal needs (forward for cooling, reverse for circulating warm air).

The fan provides an airflow capacity of 1981 Cubic Feet Per Minute, ideal for air circulation, cooling, drying, exhausting, and ventilating covered outdoor spaces.

6. Maintenance

To clean the Kichler Tranquil ceiling fan, simply wipe it with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish or components. Regular cleaning helps maintain the fan's appearance and performance.

7. Troubleshooting

If your fan is not operating as expected, consider the following:

- **Fan not turning on:** Check the circuit breaker and ensure all wiring connections are secure. Verify the remote control batteries are functional.
- **Fan making unusual noise:** Ensure all screws are tightened, especially those securing the fan blades and motor housing. Check for any obstructions.
- **Light not working:** Confirm the LED light is properly connected and not damaged. Check remote settings for light control.

For further assistance, refer to the complete installation manual or contact Kichler customer support.

8. Specifications

Feature	Detail
Brand	Kichler
Model Name	Tranquil
Item Model Number	310080NI
Color	Brushed Nickel
Electric Fan Design	Ceiling Fan
Power Source	Corded Electric
Product Dimensions	56"D x 56"W x 14.25"H
Room Type	Covered Patios, Sunrooms
Special Feature	Simple to install
Wattage	17 watts
Number of Blades	5
Air Flow Capacity	1981 Cubic Feet Per Minute
Blade Length	22.8 Inches
Voltage	120 Volts
Control Method	Remote
Item Weight	22.8 Pounds
Indoor/Outdoor Usage	Outdoor
Material	Steel
Mounting Type	Down Lighting

9. Warranty and Support

This Kichler product comes with a **1 Year Manufacturer Warranty**. For warranty claims or technical support, please contact Kichler customer service. Keep your purchase receipt for warranty validation.

10. Additional Resources

Kichler Brand Story Video

Your browser does not support the video tag.

This video provides an overview of the Kichler brand, showcasing their commitment to lighting and design. It highlights various lighting solutions and their impact on living spaces.

Kichler Brand Story

Your browser does not support the video tag.

A shorter video detailing the Kichler brand's philosophy and dedication to quality lighting products.

© 2024 Kichler. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B21QKCRS

More documents and user manuals: **https://manuals.plus/**