

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Singsation](#) /
- › [Singsation SPKA21 Portable Bluetooth Karaoke Machine User Manual](#)

Singsation SPKA21

Singsation SPKA21 Portable Bluetooth Karaoke Machine User Manual

Model: SPKA21

INTRODUCTION

This manual provides essential instructions for the safe and effective operation of your Singsation SPKA21 Portable Bluetooth Karaoke Machine. Please read this manual thoroughly before using the device and retain it for future reference.



Image: Front view of the Singstation SPKA21 Portable Bluetooth Karaoke Machine, showcasing its speaker with LED lights and the included wired microphone.

WHAT'S IN THE BOX

- Singstation SPKA21 Portable Bluetooth Karaoke Speaker

- Wired Microphone
- USB Charging Cable

PRODUCT FEATURES

- **Bluetooth 5.0 Connectivity:** Seamlessly connect to smartphones or tablets.
- **Integrated Phone/Tablet Stand:** Conveniently holds your device for lyric display.
- **Multi-Color LED Light Display:** Dynamic lighting effects for an enhanced experience.
- **Echo Voice Effect:** Enhances vocal performance.
- **Multiple Playback Options:** Supports USB, Micro SD card, and FM radio.
- **Rechargeable Battery:** Provides up to 4 hours of playtime.
- **Portable Design:** Features a built-in handle for easy transport.



Image: The Singstation SPKA21 with a smartphone securely placed in its integrated stand, displaying song lyrics.



Multi-color light display



Image: A close-up view of the SingSation SPKA21 speaker, illustrating its vibrant multi-color LED light display in various patterns.

SETUP INSTRUCTIONS

1. Charging the Device

1. Connect the provided USB charging cable to the charging port on the back of the karaoke machine.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Allow approximately 3-4 hours for a full charge.
4. A full charge provides up to 4 hours of playtime.

2. Connecting the Microphone

1. Locate the MIC INPUT port on the back of the karaoke machine.
2. Insert the plug of the wired microphone into the MIC INPUT port.
3. Ensure the microphone's ON/OFF switch is in the 'ON' position when in use.



1 LINE IN/AUX

2 MIC INPUT

3 POWER SUPPLY

4 ON/OFF

5 MICRO SD

6 USB

Image: The rear panel of the Singstation SPKA21, highlighting the various input ports including Line In/Aux, Mic Input, Power Supply, On/Off switch, Micro SD slot, and USB port.

OPERATING INSTRUCTIONS

1. Power On/Off

To power on the device, slide the ON/OFF switch located on the back panel to the 'ON' position. To power off, slide the switch to 'OFF'.

2. Bluetooth Connection

1. Ensure the karaoke machine is powered on. It will automatically enter Bluetooth pairing mode.
2. On your smartphone or tablet, navigate to the Bluetooth settings.
3. Select 'Singstation SPKA21' from the list of available devices.
4. Once connected, you will hear an audible confirmation. You can now stream audio from your device.

3. Using the Microphone and Echo Effect

1. Ensure the wired microphone is connected and its switch is 'ON'.
2. Speak or sing directly into the microphone.
3. To activate or adjust the echo effect, use the dedicated 'Echo' button or knob on the control panel

(refer to the device's physical controls for exact location).



ECHO EFFECT

Image: Two individuals enjoying karaoke with the Singsation SPKA21, illustrating the use of the microphone and the echo effect feature.

4. Media Playback (USB/Micro SD/FM Radio)

- **USB/Micro SD:** Insert a USB drive or Micro SD card (with compatible audio files) into the respective port on the back panel. The device will automatically detect and begin playing media.
- **FM Radio:** Press the 'Mode' button (if available) to switch to FM radio mode. Use the 'Previous' and 'Next' buttons to scan for stations.

5. LED Party Lights

The multi-color LED lights will activate automatically when the device is powered on. Use the dedicated 'Light Mode' button (if available) to cycle through different light patterns or turn them off.

6. Integrated Phone/Tablet Stand

Pull up the integrated stand located on the top of the unit to securely hold your smartphone or tablet for easy viewing of lyrics or videos.

Your browser does not support the video tag.

Video: An official Singsation product video demonstrating the features and usage of the Party Vibe karaoke system, including Bluetooth connectivity, microphone use, and LED lights.

MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the device away from water, moisture, and extreme temperatures.
- Store in a cool, dry place when not in use.

TROUBLESHOOTING

- **No Power:** Ensure the device is fully charged. Check the power switch.
- **No Sound:** Verify volume levels on both the karaoke machine and your connected device. Ensure Bluetooth is properly connected or media is playing from USB/SD.
- **Microphone Not Working:** Check if the microphone is securely plugged into the MIC INPUT port and its ON/OFF switch is in the 'ON' position.
- **Bluetooth Disconnection:** Move your connected device closer to the karaoke machine to ensure it's within range. Try re-pairing the device.

SPECIFICATIONS

Feature	Specification
Model Number	SPKA21
Brand	Singsation
Connectivity Technology	Bluetooth 5.0, USB
Power Source	Battery Powered (1 Lithium Polymer battery included)
Playtime	Up to 4 hours
Audio Input	Wired Microphone, AUX
Additional Features	FM Radio, SD/TF Card Reader, LED Party Lights, Echo Effect, Integrated Phone/Tablet Stand
Material	Plastic
Item Weight	2.31 pounds (1.05 Kilograms)
Package Dimensions	12.52 x 6.57 x 5.35 inches
UPC	044476151026



Image: Diagram showing the dimensions of the Singstation SPKA21: 9.84 inches (25 cm) in height, 6.3 inches (16 cm) in width, and 1.57 inches (4 cm) in depth.

WARRANTY AND SUPPORT



For warranty information or technical support, please refer to the contact details provided in the packaging or visit the official Singstation website. Keep your proof of purchase for any warranty claims.

Related Documents - SPKA21



[Singstation SPKA21 Karaoke System Safety and Warranty Information](#)

This document provides important safety instructions, regulatory information, and a 90-day limited warranty for the Singstation SPKA21 karaoke system.

	<p>Singsation Bravo Quick Start Guide: All-in-One Party System</p> <p>Get started quickly with the Singsation Bravo all-in-one party system. This guide covers setup, Bluetooth pairing, microphone use, and lighting effects.</p>
	<p>Singsation Performer Deluxe Quick Start Guide</p> <p>A quick start guide for the Singsation Performer Deluxe All-In-One Party System, covering setup, pairing, and basic operation.</p>
	<p>Singsation Star Burst Quick Start Guide</p> <p>A quick start guide for the Singsation Star Burst All-In-One Party System, covering setup, Bluetooth pairing, microphone usage, light effects, and warranty information.</p>
	<p>Singsation Aurora All-In-One Karaoke System Quick Start Guide</p> <p>Get started quickly with the Singsation Aurora All-In-One Karaoke System (SPKA28). This guide covers unpacking, charging, Bluetooth pairing, music playback, microphone use, TWS mode, light show, and other audio sources for your karaoke experience.</p>
	<p>Singsation Aria All-In-One Karaoke System Quick Start Guide</p> <p>A quick start guide for the Singsation Aria All-In-One Karaoke System, covering setup, Bluetooth pairing, microphone connection, music playback, and additional features.</p>