

[Manuals.plus](#) /

› [EverBrite](#) /

› EverBrite E007084 LED Puck Lights User Manual

EverBrite E007084

EverBrite E007084 LED Puck Lights User Manual

Model: E007084 | Brand: EverBrite

1. PRODUCT OVERVIEW

The EverBrite LED Puck Lights are wireless, remote-controlled lighting solutions designed for various indoor applications. They feature adjustable brightness, 12 RGB color options plus cool white, and multiple control methods for convenience.



Image 1.1: EverBrite LED Puck Light with dimensions (2.75"D x 2.75"W x 1.18"H) and key features like Cool White, 12 RGB Colors, 100 Lumens, AAA Batteries, Remote Control, and Touch Control.

2. WHAT'S IN THE BOX

Your EverBrite LED Puck Lights package includes:

- 6 x EverBrite LED Puck Lights
- 18 x AAA Batteries (3 per light)
- 2 x Remote Controls
- 6 x Metal Brackets with Adhesive Stickers

6 PACK WIRELESS RGB LED PUCK LIGHTS



Image 2.1: Visual guide to battery installation and the three available mounting methods for the EverBrite LED Puck Lights.

3. SETUP AND INSTALLATION

3.1 Battery Installation

1. Rotate the battery cover on the back of the puck light counter-clockwise to open.
2. Insert 3 AAA batteries, ensuring correct polarity (+/-).
3. Align the cover and rotate clockwise to secure.

3.2 Mounting Options

The EverBrite LED Puck Lights offer three versatile mounting methods:

- **Magnet Adsorption:** Each light has a built-in magnet on the back, allowing it to freely adsorb onto any ironwork surface.
- **Stick-on:** Attach the provided metal bracket with its adhesive sticker to a desired surface. The puck light can then be magnetically attached to the bracket.
- **Hanging:** A hook on the back of the light allows it to be hung for use.

Method 1:

Operating by press

Press the lamp shell to cycle through
White-Red-Green-Blue-Power Off



Method 2:

Operating by remote control

All puck lights can be controlled by the
remote, **13** kinds of RGB&White




Image 3.1: Detailed illustration of the three installation methods: magnetic attachment, adhesive mounting, and hanging.

Video 3.1: Demonstration of battery installation and various mounting options for the EverBrite Puck Lights, including magnetic and adhesive applications.

4. OPERATING INSTRUCTIONS

4.1 Touch Control

Press the lamp shell directly to cycle through the following preset colors and power states:

- Cool White
- Red
- Green
- Blue

- Power Off

4.2 Remote Control

The included remote control allows for comprehensive management of all puck lights within a 20-foot range. It offers 13 color options (cool white + 12 RGB colors) and additional functions.

3 METHODS TO USE



Image 4.1: Comparison of touch control and remote control functionalities, illustrating color options for each method.

Remote Control Functions:

- **ON/OFF:** Turn all puck lights on or off.
- **Brightness Adjustment:** Increase or decrease brightness in single color mode. The highest brightness can reach 100 lumens.
- **Color Selection:** Choose from 12 RGB colors or Cool White using dedicated buttons.
- **Timer Presets:** Set a 30-minute or 60-minute timer for automatic shut-off.
- **FADE:** Cycles through 7 colors gradually.
- **FLASH:** Flashes through 7 colors.



Image 4.2: Examples of EverBrite LED Puck Lights used in different home environments, demonstrating their adaptability.

Video 4.1: Demonstration of the EverBrite LED Puck Lights' color-changing capabilities and remote control functions, showcasing various lighting effects.

5. MAINTENANCE

5.1 Battery Replacement

When the lights dim or the remote control becomes unresponsive, it's time to replace the batteries. Follow the steps in Section 3.1 for proper battery installation.

5.2 Cleaning

To clean the puck lights, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish or electronic components.

6. TROUBLESHOOTING

- **Lights not turning on:** Ensure batteries are correctly installed and not depleted. Check if the remote control has a clear line of sight to the lights.
- **Remote control unresponsive:** Replace the remote's battery. Ensure you are within the 20-foot operating range and have a clear line of sight.
- **Lights falling off:** If using adhesive, ensure the surface is clean, dry, and smooth before application. For heavier items or high-traffic areas, consider additional adhesive or a more permanent mounting solution.
- **Remote interference:** In some rare cases, other infrared remote controls (e.g., TV remotes) may interfere with the puck lights. Try operating the lights from a different angle or distance if interference occurs.

7. SPECIFICATIONS

Feature	Detail
Model Number	E007084

Brand	EverBrite
Light Source Type	LED
Power Source	Battery Powered (3 x AAA per light)
Brightness	Up to 100 lumens
Colors	Cool White + 12 RGB Colors
Control Method	Remote Control, Touch Control
Remote Range	Up to 20FT
Timer Functions	30/60 minutes
Mounting Type	Magnet adsorption, Stick-on, Hanging
Product Dimensions	2.75"D x 2.75"W x 1.18"H
Item Weight	1.76 ounces (per light)
Material	Plastic
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact EverBrite customer service directly. Contact details can typically be found on the manufacturer's website or through your retailer.

© 2026 EverBrite. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question