

[Manuals.plus](#) /

› [SRJTEK](#) /

› SRJTEK Touch Screen Digitizer Replacement for Sky Devices Elite T8 Plus Instruction Manual

SRJTEK Elite T8 Plus

SRJTEK Touch Screen Digitizer Replacement for Sky Devices Elite T8 Plus

Official Instruction Manual

PRODUCT OVERVIEW

This document provides essential information for the installation and proper use of the SRJTEK Touch Screen Digitizer Replacement, specifically designed for the **Sky Devices Elite T8 Plus 8-inch tablet**. This component is intended to replace a broken, cracked, or malfunctioning touch screen panel, restoring the full touch functionality of your device.



Image: The SRJTEK touch screen digitizer panel shown alongside the included repair tools, such as screwdrivers, suction cup, and prying tools.

The replacement part is engineered to be a perfect fit for the Sky Devices Elite T8 Plus, ensuring compatibility and optimal performance. It is crucial to verify your device model before proceeding with the replacement.

PACKAGE CONTENTS

Upon opening the package, please verify that all components are present and undamaged. The standard package includes:

- 1 x Touch Screen Digitizer for Sky Devices Elite T8 Plus 8-inch Panel
- 1 x Opening Tool Kit (includes various prying tools and screwdrivers)
- 1 x Adhesive set for securing the new digitizer

Package Including



Image: A visual representation of the complete package contents, including the digitizer, disassembly tool card, adhesive strips, and various repair tools.

SETUP AND INSTALLATION

The installation of a touch screen digitizer requires precision and care. While the replacement part is designed for ease of installation, it is highly recommended that this procedure be performed by a professional technician to avoid damage to the device or the new component.

Important Considerations Before Installation:

- **Compatibility Check:** Ensure the part is specifically for the Sky Devices Elite T8 Plus. This part is **not compatible** with the Sky Devices Elite T8.
- **Power Off Device:** Completely power off your tablet and disconnect it from any power source before beginning the installation.
- **Static Electricity:** Take precautions against static electricity, which can damage electronic components. Use an anti-static wrist strap if available.
- **Flex Cable Connection:** The flex cable must be connected to the motherboard precisely and correctly. Improper connection is a common cause of non-functional screens.
- **LCD Display:** Note that this product is a touch screen digitizer panel only and does **not include the LCD display**. If your LCD is also damaged, a separate replacement will be required.

General Installation Steps (Professional Installation Recommended):

1. Carefully remove the damaged touch screen digitizer from your Sky Devices Elite T8 Plus tablet. This typically involves heating the edges to soften adhesive and using prying tools.
2. Disconnect the old digitizer's flex cable from the tablet's motherboard.
3. Clean any residual adhesive from the tablet frame.
4. Connect the new SRJTEK digitizer's flex cable to the motherboard, ensuring a secure and correct fit.
5. Test the new digitizer's functionality (touch response) before fully adhering it to the tablet frame.
6. Apply the provided adhesive to the tablet frame and carefully position the new digitizer, pressing firmly to secure it.
7. Reassemble any other components that were removed during disassembly.

Make your product tablet look like new as ever after replacing our Touch Screen




Before




After

Image: A visual comparison showing a tablet with a cracked screen ("Before") next to the same tablet with a newly replaced, pristine screen ("After"), illustrating the intended outcome of the replacement process.

OPERATING THE DIGITIZER

Once properly installed, the SRJTEK Touch Screen Digitizer will restore the touch functionality of your Sky Devices Elite T8 Plus tablet. It is designed to provide a smooth and responsive touch experience, similar to the original screen.

- **Touch Sensitivity:** The digitizer is manufactured to ensure high touch sensitivity and accuracy across the entire screen

surface.

- **Visual Clarity:** While this product does not include the LCD, it is designed to maintain the clarity and quality of your existing LCD display.
- **Durability Features:** The digitizer is designed with features such as HD effect, explosion-proof properties, smooth feel, and anti-fingerprint coating for enhanced user experience and longevity.




Image: A close-up of a tablet screen displaying vibrant graphics, with text indicating "Touch Feels Like Original Screen" and "Smooth Feel," highlighting the responsive and fluid interaction with the digitizer.

MAINTENANCE

To ensure the longevity and optimal performance of your new touch screen digitizer, follow these general maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth, slightly dampened with water or a screen-specific cleaning solution, to gently wipe the screen. Avoid harsh chemicals or abrasive materials.
- **Protection:** Consider using a screen protector to guard against scratches and minor impacts.
- **Handling:** Avoid dropping the device or subjecting it to excessive pressure, which can damage the digitizer and underlying LCD.
- **Temperature:** Do not expose the device to extreme temperatures, as this can affect the adhesive and screen components.

TROUBLESHOOTING

If you encounter issues after installing the SRJTEK Touch Screen Digitizer, consider the following common troubleshooting steps:

- **No Touch Response or Partial Response:**
 - Ensure the flex cable is securely and correctly connected to the motherboard. A loose or misaligned connection is a frequent cause.
 - Verify that the digitizer itself is not damaged (e.g., no visible cracks or pressure marks).
 - Restart the tablet.
- **Screen Flickering or Display Issues:**
 - This digitizer does not include the LCD. If you experience display issues, the problem might be with the LCD itself or its connection, not the digitizer.
- **Adhesive Not Holding:**
 - Ensure the tablet frame was thoroughly cleaned of old adhesive residue before applying the new adhesive.
 - Apply even pressure across the screen during adhesion.

If these steps do not resolve the issue, or if you suspect a defect with the product, please refer to the "Warranty and Support" section for assistance.

SPECIFICATIONS

Attribute	Detail
Product Type	Touch Screen Digitizer Panel (Glass only, does not include LCD)
Compatibility	Sky Devices Elite T8 Plus 8-inch Tablet (Not compatible with Elite T8)
Manufacturer	SRJTEK
ASIN	B0B24GR3XD
Package Dimensions	10.63 x 5.91 x 1.26 inches
Item Weight	5.6 ounces
Date First Available	May 24, 2022

WARRANTY AND SUPPORT

SRJTEK provides a **6-month after-sale service** for this product. If you encounter any problems with the item received, or if it does

not function as expected, please contact SRJTEK customer service for assistance.

Our customer service team is committed to providing a satisfactory solution, which may include a new replacement or other appropriate resolution.

For support, please visit the [SRJTEK Store on Amazon](#) or contact us through the Amazon platform where the purchase was made.

© 2025 SRJTEK. All rights reserved.

This manual is for informational purposes only. SRJTEK is not responsible for any damage caused by improper installation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question