Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Olakids TY327798

OLAKIDS 12V Kids Ride On ATV Instruction Manual

Model: TY327798 | Brand: Olakids

Introduction

This manual provides essential instructions for the safe assembly, operation, and maintenance of your OLAKIDS 12V Kids Ride On ATV, Model TY327798. Please read this manual thoroughly before initial use and retain it for future reference.



Image: The OLAKIDS 12V Kids Ride On ATV, featuring a blue and black design with large wheels and headlights.

Safety Information

WARNING: To reduce the risk of injury, adult supervision is required. Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water. Always wear shoes, and never allow more than one rider.

- Recommended for children over 3 years old.
- Maximum weight capacity: 77 lbs (35 kg).
- Ensure all assembly steps are completed correctly before use.
- Regularly inspect the vehicle for damage or loose parts.
- This product complies with US. CPSIA & ASTM standards, made from non-toxic materials.
- Features a soft start function to prevent sudden acceleration.



Image: Diagram highlighting key safety and quality aspects: simple operation, stable structure, and quality materials, along with EN71 certification.

What's in the Box

Upon unpacking, please verify that all components are present:

- 1 x Kids Ride On ATV (main body)
- 1 x Instruction Manual
- 1 x 12V Battery (pre-installed or separate, refer to specific packaging)
- 1 x Charger
- Assembly hardware (screws, washers, etc.)

Setup and Assembly

Assembly typically involves attaching the wheels, handlebars, and connecting the battery. While specific steps may vary, the general process is designed for straightforward completion.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Wheels:** Securely attach all four wheels according to the diagrams provided in your specific packaging. Ensure all fasteners are tightened.
3. **Install Handlebars:** Mount the handlebars onto the steering column.
4. **Connect Battery:** Locate the battery compartment, typically under the seat. Connect the battery terminals (red to red, black to black). Ensure a secure connection.
5. **Final Checks:** Before first use, ensure all connections are secure and all parts are properly assembled.



Image: Close-up views of the ATV's handle, seat, foot pedal, car lights, and charging port, illustrating key components for assembly and operation.

Operating Instructions

Driving the ATV

- **Power On:** Locate the power switch, usually near the dashboard.
- **Foot Pedal Operation:** Press the foot pedal to engage the motor and move forward. Release the pedal to brake.
- **Forward/Reverse Switch:** Use the designated switch to select between forward and reverse gears.
- **Speed Selection:** A high/low speed switch allows adjustment of the vehicle's speed. Start with low speed for new riders.
- **Soft Start Technology:** The ATV is equipped with a soft start feature to ensure smooth acceleration and prevent sudden jolts.



Image: A visual guide to the foot pedal for driving and the covered charging port, emphasizing ease of use and rechargeable design.

Multimedia Functions

The ATV includes various entertainment features:

- **Built-in Music and Horn:** Activate these features using the designated buttons on the dashboard.
- **Bluetooth Connectivity:** Connect a compatible device via Bluetooth to play custom audio.
- **Radio:** Tune into FM radio stations.
- **USB Port:** Insert a USB drive with MP3 files for playback.
- **LED Headlights:** The headlights can be turned on/off, enhancing visibility and realism.



Image: Close-up of the ATV's multimedia control panel, detailing buttons for music playback (previous song/volume down, play/pause/auto-search, next song/volume up), mode switching (radio, Bluetooth, music), and the USB interface.

Charging Instructions

To ensure optimal battery life and performance, follow these charging guidelines:

- **Initial Charge:** Before first use, charge the battery for the recommended duration (typically 8-12 hours). Do not overcharge.
- **Regular Charging:** When the vehicle's speed decreases significantly, it's time to recharge. A full charge usually

takes 8-12 hours.

- **Charging Port:** Locate the charging port, typically on the side or front of the vehicle (refer to assembly diagrams). Insert the charger plug.
- **Indicator Light:** The charger may have an indicator light to show charging status (e.g., red for charging, green for fully charged).
- **Safety:** Always charge in a dry, well-ventilated area, away from flammable materials. Disconnect the charger once charging is complete.

Maintenance

- **Cleaning:** Wipe the ATV with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the ATV in a dry, cool place when not in use. If storing for extended periods, charge the battery fully every 30 days to maintain its health.
- **Inspection:** Periodically check all screws, nuts, and electrical connections to ensure they are secure. Inspect wheels and tires for wear.
- **Battery Care:** Do not allow the battery to fully discharge for prolonged periods. Replace the battery if it no longer holds a charge effectively.

Troubleshooting

Problem	Possible Cause	Solution
Vehicle does not move.	Battery not charged; battery connection loose; power switch off; foot pedal malfunction.	Charge battery; check battery terminals; ensure power switch is on; inspect foot pedal wiring.
Vehicle moves slowly.	Low battery charge; vehicle overloaded; high speed not selected.	Recharge battery; ensure rider weight is within limits (77 lbs); select high speed setting.
Lights or music not working.	Loose wiring; multimedia unit malfunction.	Check all visible wiring connections; ensure battery is charged.
Intermittent operation.	Loose electrical connections (e.g., forward/reverse switch wiring).	Carefully inspect all wiring, especially around switches, for secure connections.

Specifications

Feature	Detail
Product Dimensions	42 x 25.5 x 29 inches (L x W x H)
Item Weight	36.5 pounds
Model Number	TY327798
Recommended Age	36 months - 7 years
Battery	1 x 12V (included)
Maximum Capacity	77 lbs

Feature	Detail
Material	Durable PP and Iron



Image: A visual representation of the ATV with its key dimensions: 42 inches in length, 25.5 inches in width, and 29 inches in height.

Warranty and Support

For warranty information or technical support, please contact Olakids customer service. Retain your proof of purchase for any warranty claims.
Contact information can typically be found on the product packaging or the official Olakids website.
Online Support: You may visit the Olakids Brand Store on Amazon for additional product information and support resources.

© 2025 Olakids. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B25197LX

More documents and user manuals: **https://manuals.plus/**