

[Manuals.plus](#) /

› [YOWHICK](#) /

› YOWHICK DP02W Mini Projector User Manual

YOWHICK DP02W

YOWHICK DP02W Mini Projector User Manual

Model: DP02W

Brand: YOWHICK

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your YOWHICK DP02W Mini Projector. Please read it thoroughly before use and retain it for future reference. The DP02W is a portable, native 1080P Full HD projector designed for various applications, including home entertainment and gaming.



Figure 1: YOWHICK DP02W Mini Projector in use, projecting a movie scene.

2. WHAT'S IN THE BOX

Verify that all items are present upon unboxing:

- YOWHICK DP02W Mini Projector
- Remote Control
- HDMI Cable
- USB Cable
- Power Adapter
- User Manual

3. SETUP

3.1 Power Connection

1. Connect the power adapter to the projector's DC input port.
2. Plug the power adapter into a standard electrical outlet.
3. Press the power button on the projector or remote control to turn it on.

3.2 Connecting Devices

The DP02W projector offers multiple connectivity options:

- **HDMI:** Connect laptops, TV sticks, gaming consoles (e.g., PS5), or other HDMI-enabled devices using the provided HDMI cable.
- **USB:** Insert a USB disk to play media files directly.
- **AV:** Use the AV port for older devices.
- **Aux:** Connect external speakers or headphones via the 3.5mm audio jack.



Figure 2: Projector ports and compatible devices.

3.3 Focus and Keystone Adjustment

Adjust the image clarity and shape using the rings on the projector:

- **Focus Ring:** Rotate the focus ring near the lens until the projected image is sharp and clear.
- **Keystone Correction:** Use the keystone correction ring to adjust the image shape if it appears trapezoidal.

3.4 Projection Surface

The projector can display images on a blank wall or a dedicated projection screen. For optimal viewing, ensure the surface is smooth and light-colored.




Figure 3: Example of large screen home theater projection.

4. OPERATING INSTRUCTIONS

4.1 Basic Controls

The projector can be controlled using the buttons on the top panel or the included remote control.

- **Power Button:** Turns the projector on/off.
- **Navigation Buttons:** Used to navigate menus and select options.
- **OK Button:** Confirms selections.
- **Source Button:** Selects input source (HDMI, USB, AV).
- **Menu Button:** Accesses settings menu.
- **Volume Buttons:** Adjusts audio volume.

4.2 Source Selection

After connecting your device, press the 'Source' button on the remote or projector to select the corresponding input (e.g., HDMI, USB).

4.3 Picture Settings

Access the 'Picture' menu to adjust image quality:

- **Picture Mode:** Choose from Standard, Dynamic, etc.
- **Brightness/Contrast:** Adjust these to suit your viewing environment.
- **Color Temperature:** Select Medium, Warm, or Cool.
- **Noise Reduction:** Adjust to minimize visual noise.
- **Zoom:** Adjust the image size without moving the projector.




Figure 4: Enhanced clarity of Native 1080P HD projection.

4.4 Audio Settings

The projector has a built-in speaker. You can adjust the volume using the remote control. For enhanced audio, connect external speakers or headphones via the Aux port.

4.5 Wireless Connection (Smartphone/Tablet)

To connect your smartphone or tablet, an adapter cable or Miracast dongle (not included) is required. Follow the instructions provided with your adapter/dongle for connection. Note that some copyrighted content from streaming services may not be supported via screen mirroring.

IOS/Android Connection

Adapter Cable or Miracast Dongle are NOT included




Figure 5: Wireless connection setup for smartphones.

5. MAINTENANCE


5.1 Lens Cleaning

Use a soft, lint-free cloth and lens cleaning solution to gently wipe the projector lens. Avoid abrasive materials that could scratch the lens.

5.2 Dust Prevention

The DP02W features an airtight lens design to minimize dust accumulation and prevent black or defect spots on the projection. Regularly clean the projector's vents to ensure proper airflow and prevent overheating.

Airtight Lens, Dustproof, No Black or Defect Spot



 Lower Noise

 **60000h** Long Lifetime

Figure 6: Airtight lens design for dust prevention and extended lamp life.

5.3 Storage

When not in use, store the projector in a cool, dry place away from direct sunlight and extreme temperatures. Use the lens cap to protect the lens from dust and scratches.

6. TROUBLESHOOTING

• No Image:

- Ensure the power cable is securely connected and the projector is turned on.
- Verify the correct input source is selected (HDMI, USB, AV).
- Check the connection cable between the projector and the source device.

• Blurry Image:

- Adjust the focus ring until the image is clear.

- Adjust keystone correction if the image is distorted.
- Ensure the projection distance is within the recommended range.

- **No Sound:**

- Increase the volume on both the projector and the source device.
- Check if external speakers are properly connected to the Aux port.
- Ensure the source device's audio output is correctly configured.

- **Connectivity Issues:**

- For HDMI, try a different HDMI cable or port.
- For USB, ensure the USB drive is formatted correctly and contains compatible media files.
- For wireless connections, ensure your adapter/dongle is correctly set up and both devices are on the same network.

7. SPECIFICATIONS

Feature	Specification
Brand	YOWHICK
Model Number	DP02W
Display Resolution	1920 x 1080 (Native 1080P)
Connectivity Technology	HDMI, USB, AV
Item Weight	2.05 pounds
Product Dimensions	5.9 x 5.1 x 2.5 inches
Special Feature	Portable
Recommended Uses	Gaming, Home Theater

8. WARRANTY AND SUPPORT

YOWHICK is committed to providing quality products and customer satisfaction. For any technical assistance, warranty claims, or support inquiries, please contact YOWHICK customer service. YOWHICK offers 24/7 support in the United States to provide professional and considerate help.

Please refer to the contact information provided in your product packaging or visit the official YOWHICK website for the most up-to-date support details.

© 2023 YOWHICK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B257XCPG>

More documents and user manuals: **<https://manuals.plus/>**