

[Manuals.plus](#) /

› [TUMAKOU](#) /

› TUMAKOU 6-in-1 Argon High Frequency Facial Machine User Manual

TUMAKOU F10

TUMAKOU 6-in-1 Argon High Frequency Facial Machine

Model: F10

PRODUCT OVERVIEW

The TUMAKOU 6-in-1 Argon High Frequency Facial Machine is designed for comprehensive skin care. Utilizing safe and natural argon technology, this device helps address various skin concerns including wrinkles, acne, and skin firmness.

The kit includes a high-quality wand and six specialized glass tubes, each designed for different areas and purposes, ensuring a versatile and effective treatment experience.



Image: The TUMAKOU High Frequency Facial Machine, including the main device, its packaging, and the six distinct glass electrode tubes.

COMPONENTS

Your TUMAKOU High Frequency Facial Machine comes with the main wand and six interchangeable glass electrode tubes:

- **Mushroom Tube:** Ideal for broader areas of the face and body.
- **Y-shape Tube:** Designed for use on the arms and neck.
- **Comb Tube:** Specifically for hair and scalp treatments.
- **Tungsten Tube:** Suitable for the body, forehead, and other larger areas.
- **Tongue Tube:** Perfect for the delicate area around the eyes.
- **Bend Tube:** Shaped for precise application around the nasal fossa.




Image: A visual guide to the six glass electrode tubes, detailing their shapes and primary application areas.

SETUP INSTRUCTIONS

1. **Insert Tube:** Select the desired glass electrode tube. Gently insert the metal end of the tube fully into the opening of the main wand handle. Push firmly until it clicks securely into place.
2. **Connect Power:** Plug the power cord of the device into a suitable electrical outlet.
3. **Adjust Level:** Turn the knob on the device to the 'ON' position. You can then adjust the intensity level by rotating the knob.

How To Use



1. Fully place the tube.



2. Connect the power supply, turn it on and adjust level.



3. Place a finger onto the tube to ground the current.



4. Use it with some of your stuff for better results!



5. Then place the tube on your face or hair area circular motion for 5-10 minutes.

Note:

Please do not place on one part over 10 seconds.

Attention: The higher level will bring you better results! But before using it for the first time, we recommended to test the strength by hand, and then use it where you want to use it.

Image: A detailed visual instruction set demonstrating the proper way to insert the glass tube, connect power, adjust settings, and apply the device.

OPERATING INSTRUCTIONS

For optimal results and safe operation, follow these guidelines:

- **Pre-Application:** It is recommended to apply your preferred skin care products (e.g., serum, moisturizer) to the treatment area before using the high frequency device for enhanced absorption and better results.
- **Grounding the Current:** Before placing the tube on your skin, touch the glass tube with your finger to ground the current. This helps to prevent a sudden shock sensation when the tube first touches your skin.
- **Intensity Adjustment:** Start with the lowest intensity level and gradually increase it to a comfortable setting. The higher the level, the more pronounced the effect. Always test the strength on your hand before applying to your face or other sensitive areas.
- **Application Technique:** Move the glass tube in gentle, circular motions over the desired treatment area.
- **Treatment Duration:** Use the device for approximately 5-10 minutes per session.

- **Important Safety Note:** Do not keep the glass tube in one spot for more than 5 seconds to avoid over-stimulation or discomfort.
- **Frequency of Use:** For best results, use the device 2-3 times per week. Consistent use will yield noticeable improvements.



Image: A scientific diagram depicting the skin's condition before and after high frequency treatment, highlighting the benefits of Argon technology.

Solve Your Troubles For You!



Image: A visual representation of common skin problems that the TUMAKOU High Frequency Facial Machine aims to address, such as acne, wrinkles, and enlarged pores.

Witness The Different You Every Day!



Image: Before and after photographs demonstrating visible improvements in skin appearance, including reduced wrinkles and clearer skin, after using the device.

MAINTENANCE

- **Cleaning:** After each use, ensure the device is unplugged. Gently wipe the glass electrode tubes with a soft, dry cloth. For thorough cleaning, a cloth lightly dampened with rubbing alcohol can be used, ensuring the tubes are completely dry before storage or next use.
- **Storage:** Store the device and its glass tubes in a cool, dry place, away from direct sunlight and out of reach of children. Keep the tubes in their protective packaging to prevent breakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device does not turn on.	Not properly plugged in; glass tube not fully inserted.	Ensure the power cord is securely plugged into an outlet. Verify that the glass tube is fully inserted and clicked into place in the wand handle.
Weak or no sensation during use.	Intensity level too low; poor contact with skin.	Increase the intensity level gradually. Ensure the glass tube is making consistent contact with the skin. Remember to ground the current by touching the tube before applying to skin.
Skin irritation or discomfort.	Intensity level too high; staying in one spot for too long.	Reduce the intensity level. Move the glass tube continuously in circular motions; do not hold it in one spot for more than 5 seconds.

SPECIFICATIONS

Brand: TUMAKOU

Model Number: F10

Color: Purple 6pcs

Dimensions (L x W x H): 23.01 x 5.51 x 5.03 cm

Weight: 750 grams

Material: Plastic

Power Source: Corded Electric

Target Audience: Women, Men

Skin Type: All

Special Features: Anti-aging, Acne Treatment, Skin Firming, Wrinkle Reduction, Hair Growth Improvement

Components Included: 6 purple glass tubes, 1 wand

UPC: 735626282096

WARRANTY AND SUPPORT

The TUMAKOU High Frequency Facial Machine comes with a **1-year warranty** from the date of purchase.

Should you have any questions, concerns, or require assistance with your device, please do not hesitate to contact the TUMAKOU support team. Our team is dedicated to providing prompt and helpful assistance to ensure your satisfaction.

For support, please refer to the contact information provided on the product packaging or the official TUMAKOU website.

© 2024 TUMAKOU. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question