

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CITIZEN](#) /

› [Citizen Quartz Men's Watch BI5051-51A Instruction Manual](#)

CITIZEN BI5051-51A

Citizen Quartz Men's Watch BI5051-51A Instruction Manual


Model: BI5051-51A

INTRODUCTION

Thank you for choosing a Citizen Quartz watch. This manual provides essential information for the proper setup, operation, and maintenance of your BI5051-51A model. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.

PRODUCT OVERVIEW

The Citizen Quartz Men's Watch BI5051-51A features a classic design with a silver-tone stainless steel case and bracelet, complemented by a crisp white dial with black accents. It is powered by a reliable quartz movement and offers water resistance up to 100 meters.



CITIZEN

QUARTZ
WR 100

7

50

10

40

20

6

30

Image: Front view of the Citizen Quartz Men's Watch BI5051-51A, showcasing its silver-tone stainless steel bracelet and white dial with black hour markers and hands.

SETUP AND INITIAL ADJUSTMENT

Setting the Time

1. **Locate the Crown:** The crown is the small knob on the right side of the watch case.
2. **Pull Out the Crown:** Gently pull the crown out to the first click position. The second hand will stop.
3. **Set the Time:** Rotate the crown to move the hour and minute hands to the desired time.
4. **Push In the Crown:** Once the time is set, push the crown back into its normal position. The second hand will resume movement.



Image: Side view of the watch, highlighting the crown used for time adjustment.

Bracelet Adjustment

The stainless steel bracelet may require adjustment to fit your wrist comfortably. This typically involves adding or removing links. It is recommended to have this procedure performed by a qualified jeweler or watch technician to prevent damage to the bracelet or clasp mechanism.

OPERATING INSTRUCTIONS

Timekeeping

Your Citizen Quartz watch is equipped with a precise quartz movement, ensuring accurate timekeeping. The watch operates continuously once the time is set and the crown is pushed in.

Water Resistance

This watch is water resistant to 100 meters (10 BAR). This rating means the watch is suitable for swimming, showering, and snorkeling. It is **not** suitable for scuba diving or high-impact water sports. Ensure the crown is fully pushed in before any contact with water to maintain water resistance.



Image: Rear view of the watch case, displaying the "W.R. 10 BAR" water resistance engraving.

Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners or abrasive materials.

Battery Replacement

Your quartz watch is powered by a battery. When the watch stops or begins to lose time significantly, it indicates the battery needs replacement. It is highly recommended to have the battery replaced by an authorized Citizen service center or a professional watchmaker to ensure proper sealing and maintain water resistance.

TROUBLESHOOTING

- **Watch Not Running:**

- Check if the crown is fully pushed in.
- The battery may be depleted. Refer to the "Battery Replacement" section.

- **Incorrect Time:**

- Reset the time as described in the "Setting the Time" section.
- If the watch consistently loses or gains significant time, it may require professional inspection.

- **Condensation Inside Crystal:**

- This indicates a potential breach in water resistance. Seek immediate professional service to prevent further damage.

SPECIFICATIONS

Model Number	BI5051-51A
Movement Type	Quartz
Case Material	Stainless Steel
Band Material	Stainless Steel Bracelet
Case Diameter	42 Millimeters
Case Thickness	10 Millimeters
Band Width	20 Millimeters
Dial Color	White
Crystal Type	Mineral Crystal
Water Resistance	100 Meters (10 BAR)
Clasp Type	Push Button Foldover Clasp With Safety
Power Source	Battery Powered

WARRANTY INFORMATION

Your Citizen Quartz watch comes with a **5 Year Limited Warranty**. This warranty covers manufacturing defects under normal use. For full details regarding warranty coverage, terms, and conditions, please refer to the official warranty card included with your purchase or visit the official Citizen website.

CUSTOMER SUPPORT

For further assistance, service, or inquiries regarding your Citizen watch, please contact Citizen customer support. You can find contact information on the official Citizen website or through the documentation provided with your watch.

Official Citizen Website: www.citizenwatch.com

