

Samsung Galaxy Tab A8

Samsung Galaxy Tab A8 Android Tablet User Manual

1. INTRODUCTION AND OVERVIEW

This manual provides essential information for setting up, operating, and maintaining your Samsung Galaxy Tab A8 Android Tablet. The Galaxy Tab A8 features a 10.5-inch LCD screen, 64GB of internal storage, and a long-lasting battery, designed for a versatile user experience. This device is a renewed product, professionally inspected and tested to function and appear like new, backed by the Amazon Renewed Guarantee.

2. SETUP

2.1 What's in the Box

- Samsung Galaxy Tab A8 Tablet
- USB-C Charging Cable
- Wall Adapter

2.2 Initial Charging

Before first use, fully charge your Galaxy Tab A8. Connect the provided USB-C cable to the tablet's USB-C port and the wall adapter, then plug the adapter into a power outlet. The tablet supports fast charging.

2.3 Power On/Off

To power on the tablet, press and hold the Power button located on the top edge until the Samsung logo appears. To power off, press and hold the Power button, then select 'Power off' from the on-screen options.

2.4 Basic Navigation

The Galaxy Tab A8 features a touch-sensitive screen for navigation. Swipe up from the bottom of the screen to access the home screen. Use the on-screen navigation buttons (Home, Back, Recent Apps) at the bottom for quick actions.

2.5 Connecting to Wi-Fi

To connect to a Wi-Fi network:

1. Swipe down from the top of the screen to open the Quick Settings panel.
2. Tap and hold the Wi-Fi icon.
3. Select your desired network from the list and enter the password if prompted.

2.6 Bluetooth Pairing

To pair a Bluetooth device:

1. Swipe down from the top of the screen to open the Quick Settings panel.
2. Tap and hold the Bluetooth icon.
3. Turn on Bluetooth and select your device from the available list to pair.

2.7 Installing Applications

Applications can be downloaded and installed from the Google Play Store. Tap the Play Store icon on your home screen or app drawer, search for your desired app, and follow the on-screen instructions to install.

3. OPERATING INSTRUCTIONS

3.1 Screen Features

- **Eye Comfort Shield:** Reduces blue light emission to minimize eye strain, especially in low-light conditions. Activate it from the Quick Settings panel.
- **Dark Mode:** Changes the system's color scheme to a darker palette, which can reduce eye strain and save battery life on certain display types. Activate it from the Quick Settings panel.
- **Smart View (Mirror Screen):** Allows you to mirror your tablet's screen to a compatible smart TV or display. Access this feature from the Quick Settings panel.

3.2 Camera Usage

The tablet is equipped with both front and rear cameras. Open the Camera app to take photos or record videos. The rear camera is suitable for general photography, while the front camera is ideal for video calls and selfies.

3.3 Expandable Storage

The Galaxy Tab A8 supports expandable memory via a microSD card slot. Insert a compatible microSD card to increase your storage capacity for photos, videos, and other files.

3.4 Audio Features

The tablet features Dolby Atmos speakers, providing enhanced audio quality for an immersive listening experience. Adjust volume using the physical volume buttons on the side or through the on-screen controls.

4. KEY FEATURES

- **Immersive 10.5" LCD Screen:** Enjoy streaming and video chatting on a vibrant display.
- **Enhanced Performance & Storage:** Features an upgraded chipset and up to 128GB of storage, with expandable memory options.
- **Long-Lasting Battery with Fast Charging:** Go for hours on a single charge and quickly recharge via the USB-C port.
- **Galaxy Ecosystem Experience:** Seamless connectivity with other Samsung devices like phones and laptops.
- **Integrated Notes:** Sync to-do lists and school work across your tablet, phone, or watch.

- **Samsung Kids:** Access a library of safe, fun, and educational content for children.
- **Smart Switch:** Easily transfer data and files from any operating system to your new tablet.

5. MAINTENANCE

5.1 Cleaning Your Tablet

Use a soft, lint-free cloth to clean the screen and body of your tablet. Avoid using harsh chemicals or abrasive materials that could damage the device.

5.2 Software Updates

Regularly check for and install software updates to ensure optimal performance and security. Go to **Settings > Software update** to check for available updates.

5.3 Battery Care

To prolong battery life, avoid exposing the tablet to extreme temperatures. For long-term storage, charge the battery to about 50%.

6. TROUBLESHOOTING

6.1 Common Issues and Solutions

- **Tablet not turning on:** Ensure the battery is charged. Connect to the charger and wait a few minutes before attempting to power on again.
- **Screen unresponsive:** Perform a forced restart by pressing and holding the Power button and Volume Down button simultaneously for about 7-10 seconds.
- **Apps crashing:** Clear the cache of the problematic app (Settings > Apps > [App Name] > Storage > Clear cache) or reinstall the app.
- **Slow performance:** Close unnecessary background apps, clear storage space, or consider a factory reset as a last resort (back up data first).

7. SPECIFICATIONS

Feature	Specification
Standing screen display size	10.5 Inches
Screen Resolution	1920 X 1200 Pixel
Max Screen Resolution	1200 x 1920 Pixels
Processor	2 GHz
RAM	4 GB
Card Description	Integrated
Wireless Type	802.11ac
Number of USB 2.0 Ports	1

Average Battery Life (in hours)	13 Hours
Brand	Samsung
Series	Galaxy Tab A8
Item model number	Galaxy Tab A8
Hardware Platform	Android, Windows
Operating System	Android
Item Weight	1.12 pounds
Product Dimensions	9.72 x 6.37 x 0.27 inches
Color	Gray
Rear Webcam Resolution	8 MP
Processor Brand	Unisoc
Flash Memory Size	64 GB

8. WARRANTY AND SUPPORT


As an Amazon Renewed product, your Samsung Galaxy Tab A8 is eligible for replacement or refund under the Amazon Renewed Guarantee if you are not satisfied with your purchase. This guarantee ensures that the product has been professionally inspected and tested to work and look like new.

For further support, please refer to the official Samsung support website or contact Amazon customer service for assistance with your renewed device.

9. PRODUCT IMAGES

IMMERSIVE SCREEN EXPERIENCE

**A screen everyone
will love**



EXPANDABLE MEMORY

Room for everything



Front view of the Samsung Galaxy Tab A8, showcasing its 10.5-inch LCD screen.



7,040mAh

LONG-LASTING BATTERY
AND UNIVERSAL CHARGING

**Charge fast.
Power for hours.**

Processor

Octa-core

Battery


7,040mAh



PERFORMANCE

**Power and
storage for all**





Rear view of the Samsung Galaxy Tab A8, highlighting its sleek design and camera placement.

Amazon Renewed conditions

All Amazon Renewed products are fully functional, and come with generic or original accessories and packaging.

Example body scratches and dents – not actual products




Graphic illustrating the immersive screen experience of the Galaxy Tab A8.



What Renewed customers are saying

Graphic detailing the long-lasting battery and fast charging capabilities.

What Renewed customers are saying



Graphic highlighting expandable memory and overall performance of the tablet.