

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE 5-Drawer Fabric Dresser Instruction Manual

WLIVE ASNG068DHS2

WLIVE 5-Drawer Fabric Dresser Instruction Manual

Model: ASNG068DHS2 | Brand: WLIVE

INTRODUCTION

Thank you for choosing the WLIVE 5-Drawer Fabric Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage unit. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: Front view of the assembled WLIVE 5-drawer dresser in rustic brown wood grain print.

SAFETY INFORMATION

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload drawers. The maximum loading capacity for the top surface is 35 lbs.
- For safety, especially in households with children, consider securing the dresser to a wall using anti-tipping hardware (if provided or purchased separately) to prevent accidental tipping.
- Keep small parts and packaging materials away from children during assembly.

PARTS LIST

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact WLIVE customer support.

- Steel Frame Components (various sizes)
- Wood Top Panel
- Fabric Drawers (5 units: 3 medium, 2 large)

- Drawer Handles
- Adjustable Feet (4 units)
- Assembly Hardware (screws, Allen wrench)



Figure 2: Sturdy steel frame components for stable support.

SETUP AND ASSEMBLY

Assembly of the WLIVE dresser is designed to be straightforward. Follow these general steps. An assembly video may be available from the manufacturer for additional guidance.

1. Unpack all components and lay them out on a clean, soft surface.
2. Assemble the steel frame according to the provided diagrams, ensuring all connections are secure.
3. Attach the adjustable feet to the bottom of the frame.
4. Place the wood top panel onto the assembled frame, securing it with the appropriate hardware.
5. Unfold each fabric drawer and insert the rigid bottom panel to give it shape.

6. Attach the handles to the front of each fabric drawer.

7. Slide the assembled fabric drawers into their designated slots within the steel frame.



Figure 3: Detail of high-grade fabric drawers and adjustable feet.

OPERATING INSTRUCTIONS

Your WLIVE dresser is designed for versatile storage in various rooms. The fabric drawers are removable and foldable for convenience.

- **Drawer Use:** Gently pull the handles to open and close the drawers. Avoid forcing them.
- **Capacity:** The dresser is ideal for organizing clothes, linens, and daily necessities. Refer to the capacity diagram for estimated storage per drawer size.
- **Top Surface:** The sturdy wood top can be used to display decorative items, lamps, or as a TV stand for televisions up to 43 inches. Ensure the weight does not exceed 35 lbs.



3 MEDIUM DRAWERS

Each one can hold:



54 - 60 Socks

OR



12 -14 T-shirts

2 LARGE DRAWERS

Each one can hold:



19 -24 T-shirts

OR



12 -14 Jeans



The above data is for reference only

Figure 4: Drawer capacity guide for optimal organization.



Reference TV Size : 45 "

Figure 5: Dresser functioning as a TV stand.

MAINTENANCE

To keep your WLIVE dresser in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the wood top and steel frame with a dry cloth. For the fabric drawers, spot clean with a damp cloth and mild detergent if necessary, then air dry. Do not machine wash.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten as needed.
- **Placement:** Avoid placing the dresser in direct sunlight or near heat sources to prevent warping or fading of materials.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Dresser is wobbly.	Loose screws or uneven floor.	Tighten all assembly screws. Adjust the leveling feet on the bottom of the frame.
Drawers do not slide smoothly.	Drawer is not properly inserted or overloaded.	Ensure the drawer is fully unfolded and correctly placed on its support. Reduce contents if overloaded.
Missing parts.	Packaging error.	Contact WLIVE customer support with your purchase details.

SPECIFICATIONS

- **Brand:** WLIVE
- **Model Name:** ASNG068 Fabric 5 Drawer Tall Storage Cabinet / DHS2
- **Product Dimensions:** 39.4" L x 11.8" W x 26.6" H
- **Item Weight:** 23.9 pounds
- **Color:** Rustic Brown Wood Grain Print
- **Materials:** Steel frame, Wood top, Non-woven fabric drawers
- **Assembly Required:** Yes
- **Special Features:** Adjustable Feet
- **Mounting Type:** Floor Mount




Figure 6: Product dimensions and maximum loading capacity.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your WLIVE dresser, please contact WLIVE customer support directly. Refer to your purchase documentation for specific warranty terms and contact information.

No official product videos from the seller are available for this item.

© 2023 WLIVE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question