

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [AIRBOT](#) /

> [AIRBOT Cordless Vacuum Cleaner, 27Kpa Stick Vacuum with Strong Brushless Motor, 3 in 1 Lightweight Stick Cleaner 45 Min Runtime Detachable Battery for Hardfloor Carpet Pet Hair User Manual](#)

AIRBOT Hypersonics Pro

AIRBOT Cordless Vacuum Cleaner User Manual

Model: Hypersonics Pro | Brand: AIRBOT

INTRODUCTION

Thank you for choosing the AIRBOT Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

The AIRBOT Hypersonics Pro is a versatile 3-in-1 lightweight stick cleaner designed for effective cleaning on various surfaces, including hard floors, carpets, and pet hair. It features a powerful 27Kpa suction, a strong brushless motor, and a detachable battery for extended runtime.

SAFETY INSTRUCTIONS

- Always ensure the vacuum cleaner is switched off and unplugged before cleaning or performing maintenance.
- Do not use the appliance outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Supervise children and pets when the appliance is in use.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up flammable or combustible materials, hot ashes, or large, sharp objects.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- If the power adapter or cord is damaged, it must be replaced by the manufacturer or a qualified service agent to avoid hazards.

PACKAGE CONTENTS

Verify that all components are present and in good condition upon opening the package:

- Main motor (motor & dust cup)
- Motorized floor brush
- Storage Mount
- Power Adapter

- Bristle Roller Brush
- Crevice Nozzle
- 2-in-1 Brush
- User Manual
- Foldable Extension Rod



Foldable Vacuum Cleaner

Easily and quickly clean your house

≤ 180°

Figure 1: Included Components. This image displays all parts of the vacuum cleaner, including the main motor, various brushes, extension rod, and charging accessories.

SETUP AND ASSEMBLY

1. **Attach Extension Rod:** Insert the foldable extension rod into the main motor unit until it clicks securely into place.
2. **Connect Floor Brush:** Attach the motorized floor brush to the other end of the extension rod, ensuring a firm connection.
3. **Install Accessories:** For handheld use or specific cleaning tasks, attach the crevice nozzle or 2-in-1 brush directly

to the main motor unit or the extension rod as needed.

4. **Charging:** Before first use, fully charge the detachable battery using the provided power adapter. The LED smart touch display will indicate battery status.



Figure 2: Assembled Vacuum Cleaner. The main unit, extension rod, and floor brush are connected, demonstrating the full assembly.

Your browser does not support the video tag.

Video 1: AIRBOT Norvia Hypersonics Pro Cordless Vacuum Cleaner. This video demonstrates the assembly process and various features of the vacuum cleaner.

OPERATING INSTRUCTIONS

Power On/Off and Suction Modes

- **Power On:** Press the power button on the handle to turn on the vacuum cleaner.
- **Suction Modes:** The LED smart touch display allows you to switch between suction modes (Auto, Low, Medium, High) by touching the "MODE" button. The vacuum automatically adjusts suction based on dust detection in Auto mode.
- **Power Off:** Press the power button again to turn off the appliance.

Cleaning Tips

- For hard floors and wood floors, the vacuum's V-shaped rolling brush and LED lights ensure thorough cleaning, illuminating hidden dust.
- For short, thin carpets, the powerful suction effectively removes dirt and debris. Note that performance may vary on long or thick carpets.
- The 90-degree bendable hose allows for easy cleaning under furniture without excessive bending.



Figure 3: LED Smart Touch Display. The display provides real-time information on battery level, dust cup fullness, and current suction

mode.



Figure 4: Foldable Extension Rod in Use. This image demonstrates the flexibility of the vacuum for reaching difficult areas.

Your browser does not support the video tag.

Video 2: AIRBOT Norvia Aura Cordless Vacuum Cleaner. This video highlights the vacuum's features, including smart speed change and multi-purpose brush tools.

MAINTENANCE

Emptying the Dust Cup

The 0.8L large dust cup can be easily emptied with the push of a button. It is recommended to empty the dust cup after each use or when the dust cup fullness indicator on the LED display is active.

Cleaning the Filter System

The 5-stage high-efficiency filtration system includes a washable HEPA filter. Regularly clean the filter to maintain optimal

suction performance. Refer to the user manual for detailed instructions on disassembling and cleaning the filter components.

Brush Head Maintenance

The V-shaped rolling brush is designed to reduce hair entanglement. Periodically check the brush head for tangled hair or debris and remove it to ensure smooth operation.



Figure 5: High-Efficiency Filtration System. This diagram illustrates the various filter components, including the metal mesh filter, 5-cone cyclone separation, and HEPA filter.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Vacuum not turning on.	Battery is not charged or not properly installed.	Ensure battery is fully charged and securely clicked into place.
Reduced suction power.	Dust cup is full, filter is clogged, or brush head is tangled.	Empty dust cup, clean filters, and remove any obstructions from the brush head.
Vacuum stops unexpectedly.	Overheating due to prolonged use or blockage.	Turn off the vacuum, allow it to cool down, and check for blockages in the hose or brush head.
LED display shows fault alarm.	Specific error detected by the smart sensor panel.	Refer to the user manual's detailed troubleshooting section for specific error codes or contact customer support.

SPECIFICATIONS

- **Brand:** AIRBOT
- **Model Name:** Hypersonics Pro
- **Special Feature:** Lightweight
- **Filter Type:** HEPA Filter
- **Is Cordless?:** Yes
- **Capacity:** 0.8L Dust Cup
- **Wattage:** 250 watts
- **Runtime:** Up to 45 minutes (min suction)
- **Maximum Suction:** 27Kpa
- **Product Dimensions:** 11"L x 6"W x 28"H
- **Noise Level:** 65 Sones
- **Item Weight:** 10.6 ounces
- **Batteries:** 1 Lithium Ion battery required (included)
- **Control Method:** Touch (LED Smart Touch Display)

WARRANTY AND SUPPORT

The maintenance period for your AIRBOT Cordless Vacuum Cleaner is 12 months from the date of purchase. For any questions, technical assistance, or warranty claims, please contact our customer service team.

Customer Service Email: support@airbot-tech.com

Please have your model number (Hypersonics Pro) and purchase details ready when contacting support.