

[Manuals.plus](#) /

> [Sealy](#) /

> Sealy Electric Heated Throw Blanket User Manual - Model KTHT-BHVV-W

Sealy KTHT-BHVV-W

Sealy Electric Heated Throw Blanket User Manual

MODEL: KTHT-BHVV-W

1. Introduction

Thank you for choosing the Sealy Electric Heated Throw Blanket. This manual provides essential information for the safe and effective use of your new heated throw. Please read all instructions carefully before use and retain this manual for future reference.

The Sealy Electric Heated Throw Blanket is designed to provide warmth and comfort. It features soft flannel material, 6 heating settings, and an automatic shut-off timer for your convenience and safety.



2. Important Safety Instructions

To reduce the risk of burns, electric shock, fire, or injury, this product must be used in accordance with the following instructions:

- Do not use with an infant, child, incapacitated person, or anyone insensitive to heat.
- Do not use if the blanket is wet.
- Do not use with pets.
- Never use the blanket folded, bunched, or crumpled. Ensure it is spread flat during use.
- Regularly inspect the blanket, power cord, and controller for any signs of wear or damage. Discontinue use if any damage is found.
- Always unplug the blanket from the electrical outlet when not in use.
- Do not dry clean this product. Follow the cleaning instructions carefully.
- Keep the controller away from water or other liquids.
- This product operates at 120V AC.

3. Package Contents

Verify that all items are included in your package:

- 1 x Sealy Electric Heated Throw Blanket (Beige, 50" x 60")
- 1 x Controller
- 1 x User Manual

4. Product Features

- **Material:** Soft Flannel (100% Polyester) for comfort.
- **Dimensions:** Throw Size 50 inches x 60 inches.
- **Heat Settings:** 6 adjustable heat levels (up to 113°F at level 6).
- **Auto Shut-Off:** Programmable timer with 2, 4, 8, or 10-hour options.
- **Fast Heating:** Reaches 95°F in approximately 15 minutes.
- **Safety:** ETL & FCC certified with overheating protection.
- **Care:** Machine washable for easy maintenance.



Warmth & Comfort



Safety Assurance



LED Controller



Figure 2: Sealy's heating wire configuration ensures even heat distribution.

5. Setup

Follow these steps to set up your heated throw blanket:

1. **Unpack:** Carefully remove the heated throw blanket and controller from its packaging.
2. **Connect Controller:** Locate the connector on the blanket and the corresponding plug on the controller cord. Firmly push the plug into the connector until it clicks securely into place.
3. **Position Blanket:** Spread the heated throw blanket flat on a bed, couch, or other surface. Ensure there are no folds, bunches, or wrinkles that could trap heat.
4. **Plug In:** Insert the power cord from the controller into a standard 120V AC electrical outlet.

Your blanket is now ready for use.

6. Operating Instructions

Use the attached LED controller to operate your heated throw blanket.



Figure 3: Controller with LED screen, heat settings, time settings, and quick on-off button.

1. **Turning On:** Press the power button (usually marked with a circle and vertical line) on the controller. The LED display will illuminate.
2. **Adjusting Heat Settings:** Press the "HEAT" button to cycle through the 6 available heat settings. The display will show the current heat level (1-6). For optimal warmth, it is recommended to set the heating level between 3 and 6 when first turning on the blanket.
3. **Setting the Timer:** Press the "TIME" button to select an automatic shut-off duration. Options include 2, 4, 8, or 10 hours. The selected time will be displayed. The blanket will automatically turn off after the set time has elapsed.
4. **Pre-heating:** For maximum comfort, turn on the blanket approximately 15 minutes before use to allow it to reach your desired temperature.
5. **Turning Off:** Press the power button again to turn off the blanket. The LED display will turn off. Always unplug the blanket from the wall outlet when not in use.

Official Product Video: Controller Overview

Video 1: This video demonstrates the functions of the Sealy Heated Blanket Throw's built-in button controller, including heat and timer settings.

7. Maintenance and Care

Proper care ensures the longevity and performance of your heated throw blanket.

1. **Disconnect Power:** Always unplug the power cord from the wall outlet and detach the controller from the blanket before cleaning.
2. **Machine Washing:** Machine wash the blanket on a gentle cycle using cold water. Do not use bleach.
3. **Drying:** Tumble dry on a low heat setting or air dry. Ensure the blanket is completely dry before re-connecting the controller or plugging it back in. Do not iron the blanket.
4. **Storage:** When not in use, store the blanket loosely folded in a cool, dry place. Avoid tightly folding or placing heavy objects on it, which could damage the internal wiring.



Figure 4: The detachable connector allows for safe machine washing of the blanket.

8. Troubleshooting

If you experience issues with your heated throw blanket, please refer to the following common problems and solutions:

- **Blanket Not Heating:**

- Ensure the power cord is securely plugged into a functional 120V AC wall outlet.
- Verify that the controller is firmly connected to the blanket.
- Check that a heat setting has been selected on the controller.

- **Controller Display Not Working:**

- Confirm the blanket is plugged into a live electrical outlet.
- If the issue persists after checking connections, contact customer support.

- **Uneven Heating:**

- Ensure the blanket is spread out flat and not folded, bunched, or tucked in tightly.
- If you suspect damaged internal wiring, discontinue use immediately and contact customer support.

For any issues not listed here or if troubleshooting steps do not resolve the problem, please contact Sealy customer support.

9. Specifications

Feature	Detail
Brand	Sealy
Model Number	KTHT-BHVV-W
Material	100% Polyester Flannel
Color	Beige
Product Dimensions	50 inches (W) x 60 inches (L)
Heat Settings	6 Levels
Auto Shut-Off Timer	2, 4, 8, 10 Hours
Power Input	120V AC
Certifications	ETL & FCC Certified



Figure 5: Dimensions of the Sealy Electric Heated Throw Blanket.

10. Warranty and Support

Sealy is committed to providing quality products and support. This heated throw blanket is ETL & FCC certified, ensuring it meets high safety and quality standards.

If you have any questions, concerns, or require assistance with your Sealy Electric Heated Throw Blanket, please do not hesitate to reach out to our customer support team. We are here to provide the best support for you.

Contact information for support can typically be found on the product packaging or the official Sealy website.