

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Juskys](#) /
- › [Juskys Metal Garden Shed S \(Model 21057\) Instruction Manual](#)

Juskys 21057

Juskys Metal Garden Shed S (Model 21057) Instruction Manual

Brand: Juskys

Model: 21057

1. INTRODUCTION AND PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your Juskys Metal Garden Shed S, Model 21057. This compact and durable storage solution is designed for outdoor use, offering approximately 1 square meter of storage space for garden tools, equipment, and other outdoor items.

The shed features a robust galvanized steel construction with an anthracite finish, a practical lean-to roof for efficient water drainage, and a space-saving sliding door. A foundation frame is included to ensure stability and compensate for minor ground irregularities. An integrated tool holder assists in organizing smaller hand tools.



Front view of the Juskys Metal Garden Shed S with its sliding door partially open, showcasing the anthracite finish and lean-to roof design.

2. SAFETY INSTRUCTIONS

Read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Two-Person Assembly:** Assembly requires at least two adults. Some parts are large and heavy, and sharp edges may be present.
- **Protective Gear:** Wear appropriate protective gear, including work gloves, safety glasses, and sturdy footwear, during assembly to prevent cuts and other injuries.
- **Sharp Edges:** Metal panels may have sharp edges. Handle all components with care.
- **Level Surface:** Assemble the shed on a firm, level surface. Ensure the foundation frame is properly leveled before proceeding with wall and roof installation.
- **Secure Anchoring:** The shed must be securely anchored to the ground to prevent it from being moved

or damaged by strong winds. Use appropriate anchoring hardware (not included) for your specific ground type.

- **Ventilation:** Ensure adequate ventilation if storing items that may emit fumes.
- **Children and Pets:** Keep children and pets away from the assembly area. Do not allow them to play inside or around the shed unsupervised.
- **Weight Distribution:** Do not overload the shed. Distribute weight evenly.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. Refer to the included parts list (if provided in your packaging) to identify each component. Typical contents include:

- Galvanized steel wall panels
- Roof panels and support beams
- Foundation frame components
- Sliding door assembly (panels, runners, handle, latch)
- Integrated tool holder
- Fasteners (screws, bolts, nuts, washers)
- Instruction manual

If any parts are missing or damaged, contact Juskys customer support before proceeding with assembly.

4. SETUP AND ASSEMBLY

Assembly of the Juskys Metal Garden Shed S requires patience and careful attention to detail. It is highly recommended to have two people for the assembly process.

4.1 Site Preparation

- Choose a flat, level area for the shed. Uneven ground can lead to assembly difficulties and structural instability.
- Clear the area of any debris, rocks, or vegetation.
- Ensure there is sufficient space around the shed for assembly and future access.

4.2 Foundation Frame Assembly

- Assemble the foundation frame components according to the diagrams in your specific instruction booklet.
- Ensure all corners are square and the frame is level using a spirit level. Adjust as necessary.
- Secure the foundation frame to the ground using appropriate anchors (not supplied) for long-term stability.



Detailed view of the galvanized steel foundation frame, designed to provide stability and compensate for uneven ground.

4.3 Wall Panel Installation

- Attach the wall panels to the foundation frame and to each other using the provided fasteners.
- Work systematically, ensuring each panel is correctly aligned before tightening fasteners.
- Pay close attention to the orientation of panels, especially those with pre-drilled holes for the door frame.

4.4 Roof Assembly

- Install the roof support beams and then the roof panels.
- Ensure all roof panels overlap correctly to prevent water ingress.
- Secure all roof components firmly.

4.5 Sliding Door Installation

- Assemble the sliding door panels and attach the rollers.
- Carefully insert the door into its tracks.
- Install the handle and latch mechanism. Test the door's smooth operation.



Detail of the sliding door handle and latch mechanism on the Juskys Metal Garden Shed S, providing secure closure.

4.6 Tool Holder Installation

- Locate the designated mounting points for the tool holder inside the shed.
- Secure the tool holder using the provided fasteners.



Close-up view of the integrated tool holder inside the Juskys Metal Garden Shed S, designed for organizing small garden tools.

5. OPERATING INSTRUCTIONS

5.1 Sliding Door Operation

- To open the door, grasp the handle and slide the door along its track.
- To close the door, slide it back until it meets the frame. Engage the latch for security.
- Ensure the door track is kept clear of debris to allow smooth operation.

5.2 Tool Holder Use

- Utilize the integrated tool holder for hanging small garden tools such as trowels, rakes, or pruning shears.
- Avoid overloading the tool holder to prevent damage.

6. MAINTENANCE

Regular maintenance will extend the lifespan of your garden shed.

- **Cleaning:** Clean the shed periodically with mild soap and water. Rinse thoroughly and allow to air dry. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Fastener Check:** Periodically inspect all screws, bolts, and nuts. Tighten any loose fasteners to maintain structural integrity.
- **Roof Maintenance:** Clear the roof of any accumulated leaves, snow, or debris to ensure proper water drainage and prevent excessive weight buildup.
- **Door Tracks:** Keep the sliding door tracks clean and free of dirt or obstructions. Lubricate the rollers and tracks annually with a silicone-based lubricant for smooth operation.
- **Rust Prevention:** Although made of galvanized steel, inspect for any signs of rust, especially in areas where the coating might be scratched. Treat any rust spots promptly with a rust-inhibiting primer and paint.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your garden shed.

| Problem | Possible Cause | Solution |
|--------------------------------------|--|---|
| Door sticks or is difficult to slide | Debris in track, misaligned door, dry rollers/track | Clean tracks, check door alignment, lubricate rollers/track. |
| Shed feels unstable or wobbly | Uneven foundation, loose fasteners, insufficient anchoring | Ensure foundation is level, tighten all fasteners, securely anchor the shed to the ground. |
| Water leakage inside the shed | Improperly sealed roof/panels, damaged panels, clogged roof drainage | Check all panel overlaps and roof seals. Ensure roof drainage is clear. Inspect for any damage to panels. |
| Rust spots appearing | Scratches in protective coating, prolonged exposure to moisture | Clean affected area, apply rust-inhibiting primer, and touch-up paint. |

For issues not covered here or if problems persist, please contact Juskys customer support.

8. SPECIFICATIONS

Key technical specifications for the Juskys Metal Garden Shed S, Model 21057:



Technical diagram displaying the overall dimensions of the Jusky's Metal Garden Shed S: 161 cm width, 86 cm depth, and 181 cm height, along with door opening measurements.

| Feature | Detail |
|--------------------------------|--|
| Model Number | 21057 |
| Overall Dimensions (L x W x H) | 161 x 86 x 181 cm |
| Storage Area | Approx. 1 m ² |
| Door Opening (W x H) | 60 x 158 cm |
| Weight | 26.5 kg |
| Material | Galvanized Metal (Alloy Steel for top) |
| Color | Anthracite (Grey) |
| Water Resistance Level | Waterproof |

| Feature | Detail |
|--------------|--------------------|
| Manufacturer | Juskys Gruppe GmbH |

9. WARRANTY AND SUPPORT

Information regarding the specific warranty period and terms for the Juskys Metal Garden Shed S (Model 21057) is not provided within this document. Please refer to the warranty card included with your product packaging or visit the official Juskys website for detailed warranty information.

For technical assistance, missing parts, or any other product-related inquiries, please contact Juskys customer support directly. Contact details can typically be found on the product packaging or the manufacturer's website.