

[Manuals.plus](#) /

› [VGR](#) /

› VGR V-302 4-in-1 Rotary Electric Shaver User Manual

VGR V-302

VGR V-302 4-in-1 Rotary Electric Shaver User Manual

Model: V-302

INTRODUCTION

Thank you for choosing the VGR V-302 4-in-1 Rotary Electric Shaver. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new grooming device. Please read these instructions carefully before first use and retain them for future reference.

SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, injury, or damage, always follow these basic safety precautions.

- Always be cautious when using the shaver near your face and neck to avoid skin irritation or cuts.
- Do not immerse the charging adapter in water or other liquids.
- Keep the appliance away from children.
- Ensure the appliance is fully charged before use to maintain optimal performance.
- Do not use the appliance if it is damaged.
- Only use the provided USB charging cable.

PACKAGE CONTENTS

Verify that all items are present in your package:

- VGR V-302 Main Shaver Unit with Rotary Head
- Precision Trimmer Head
- Nose and Ear Trimmer Head
- Trimmer Guide Combs (various sizes)
- Cleaning Brush
- USB Charging Cable
- User Manual (this document)



Image: The VGR V-302 main shaver unit featuring a five-head rotary shaving system. The device is black with silver accents and the VGR logo in gold.



Image: The rear view of the VGR V-302 shaver, displaying the power button, model number (V-302), charging time (8H), input voltage (DC 5V), and "MADE IN P.R.C." markings.



Image: A set of black trimmer guide combs of various lengths and a small black cleaning brush, accessories for the VGR V-302 shaver.



Image: Two interchangeable heads for the VGR V-302 shaver: a precision trimmer head with a stainless steel blade and a nose/ear hair trimmer head with a conical design.

PRODUCT OVERVIEW

The VGR V-302 is a versatile 4-in-1 grooming tool designed for men. Key features include:

- **4-in-1 Functionality:** Includes rotary shaver, precision trimmer, and nose/ear trimmer heads.

- **Wet & Dry Shaving:** Suitable for both dry use and wet shaving with foam or gel.
- **Waterproof Design:** Allows for direct cleaning under running water.
- **Rechargeable Battery:** Cordless operation for convenience.
- **USB Charging:** Flexible charging options.
- **Automatic Grinding Technology:** Blades sharpen themselves during use for consistent performance.
- **LED Light Reminder:** Indicates charging status and battery level.
- **Global Universal Voltage:** Compatible with 100-240V power outlets.

SETUP AND CHARGING

Initial Charge

Before using your VGR V-302 shaver for the first time, fully charge the device. This typically takes approximately 8 hours.

Charging Instructions

1. Ensure the shaver is turned off.
2. Connect the USB charging cable to the shaver's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, wall adapter).
4. The LED light will indicate charging status. Refer to the LED indicator section for details.
5. A full charge provides approximately 60 minutes of cordless use.

OPERATION

Attaching and Detaching Accessories

To replace accessories (e.g., switching from rotary shaver head to trimmer head), gently pull the current head straight up to detach it. Do not rotate the head during removal. Align the new accessory head with the shaver body and press down until it clicks into place.

Rotary Shaving (Face)

The rotary shaver head is designed for a close and comfortable shave on the face.

- **Dry Shaving:** For a quick shave, ensure your skin is clean and dry. Move the shaver in small circular motions over your face.
- **Wet Shaving:** For a more comfortable shave, apply shaving cream or gel to your face. Move the shaver in small circular motions. The waterproof design allows for use in the shower.
- For optimal results, shave against the direction of hair growth.

Using the Precision Trimmer Head

The precision trimmer head is ideal for shaping sideburns, mustaches, and for pre-trimming longer beards before rotary shaving.

- Attach the precision trimmer head.
- For longer beards, use the trimmer head first to shorten the hair, as the electric rotary razor may not effectively cut very long beards.

- Attach the desired guide comb for specific hair lengths.
- Move the trimmer against the direction of hair growth for an even trim.

Using the Nose and Ear Trimmer Head

The nose and ear trimmer head is designed for safely removing unwanted hair from the nose and ears.

- Attach the nose and ear trimmer head.
- Gently insert the trimmer tip into your nostril or ear canal.
- Move the trimmer in a circular motion to cut hairs. Do not insert too deeply.

MAINTENANCE

Cleaning

Regular cleaning ensures optimal performance and hygiene.

1. Turn off and unplug the shaver before cleaning.
2. Detach the shaving head.
3. Rinse the shaving head directly under running water. The waterproof design allows for easy cleaning.
4. Use the provided cleaning brush to remove any stubborn hair clippings from the blades and inside the shaver head.
5. Allow all parts to air dry completely before reattaching or storing.

Automatic Grinding Technology

The VGR V-302 features automatic grinding technology, where the blades gently sharpen themselves during use. This helps maintain cutting efficiency over time.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for 8 hours.
Shaver performance is poor / pulling hair.	Blades are dirty or clogged with hair. / Battery is low. / Hair is too long for rotary shaver.	Clean the shaving head thoroughly. / Fully charge the shaver. / Use the precision trimmer head to shorten long hair before rotary shaving.
Shaver does not charge.	Charging cable or adapter is faulty. / Charging port is dirty.	Ensure the USB cable and power source are working correctly. Try a different USB port or adapter. Clean the charging port if necessary.

SPECIFICATIONS

- **Model:** V-302
- **Brand:** VGR

- **Power:** 5W
- **Voltage:** Global Universal (100-240V), 50/60Hz
- **Charging Time:** Approximately 8 hours
- **Operating Time:** Approximately 60 minutes (fully charged)
- **Battery:** Rechargeable
- **Blade Material:** Stainless Steel
- **Head Type:** Rotary
- **Special Features:** Waterproof, Wet/Dry Shaving, USB Charging, Automatic Grinding Technology, LED Light Reminder
- **Item Weight:** 500 Grams
- **Package Dimensions:** 21.4 x 15.7 x 9.1 cm
- **Country of Origin:** China

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact VGR customer service through their official website or the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0B29PQSQZ>

More documents and user manuals: <https://manuals.plus/>