

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iHome](#) /

› [iHome IHQI1006W-OD Airpad 10-Watt Qi Ultra Slim Wireless Charging Pad User Manual](#)

## iHome IHQI1006W-OD

# iHome IHQI1006W-OD Airpad 10-Watt Qi Ultra Slim Wireless Charging Pad User Manual

## INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your iHome IHQI1006W-OD Airpad 10-Watt Qi Ultra Slim Wireless Charging Pad. Please read this manual thoroughly before operating the device and retain it for future reference.

## SAFETY INFORMATION

- Do not expose the charging pad to liquids, moisture, or extreme temperatures.
- Avoid placing metal objects, credit cards, or other foreign materials on the charging pad during operation, as this may interfere with charging or cause damage.
- Do not disassemble, modify, or attempt to repair the device yourself. Contact qualified service personnel for assistance.
- Ensure the power adapter used is compatible with the charging pad's specifications (e.g., 9V input).
- Keep the charging pad away from strong magnetic fields.
- This product is designed for indoor use only.

## PACKAGE CONTENTS

Verify that all items are present in your package:

- iHome IHQI1006W-OD Airpad Wireless Charging Pad
- User Manual
- USB Cable (Power Adapter not included)

## SETUP INSTRUCTIONS

1. **Connect the Charging Pad:** Plug the provided USB cable into the charging pad's input port.

2. **Connect to Power:** Connect the other end of the USB cable to a compatible USB power adapter (not included) and then plug the adapter into a wall outlet. Ensure the power adapter supports 9V input for optimal performance.
3. **Placement:** Place the charging pad on a flat, stable surface, free from obstructions.



Figure 1: The iHome Airpad connected to a power source with a smartphone positioned for wireless charging.

The image above illustrates the iHome Airpad wireless charging pad with a smartphone placed on its surface. The charging pad is connected via a white USB cable to a power source, indicating readiness for operation. The smartphone screen displays a charging icon and "62% Charged," confirming active wireless power transfer. A white keyboard and mouse are visible in the background, suggesting a typical desktop setup.

## OPERATING INSTRUCTIONS

1. **Place Device:** Carefully place your Qi-compatible smartphone or other device onto the center of the charging pad. The anti-slip surface helps keep your device secure.
2. **Confirm Charging:** Your device should indicate that it is charging (e.g., a charging icon on the screen, an LED

indicator on the phone). The charging pad may also have an indicator light to confirm active charging.

3. **Optimal Charging:** For iPhones, the pad adjusts to 7.5 watts for optimal charging speed without overheating. For other compatible devices, it provides up to 10 watts.
4. **Remove Device:** Once your device is fully charged or you wish to stop charging, simply lift it from the pad.



Figure 2: A smartphone actively charging on the iHome Airpad, displaying its charge percentage.

This image provides a closer view of a smartphone resting on the iHome Airpad wireless charger. The phone's screen clearly shows "62% Charged" and a battery icon, confirming that the device is receiving power wirelessly. The slim design of the charging pad is evident, and the white charging cable is connected to the pad. This visual demonstrates the product's primary function of wirelessly charging compatible devices.

## MAINTENANCE

- **Cleaning:** Disconnect the charging pad from the power source before cleaning. Use a soft, dry cloth to wipe the surface. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the charging pad in a cool, dry place, away from direct sunlight and extreme

temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging.	Device not Qi-compatible. Device not properly aligned on the pad. Charging pad not powered. Foreign object on the pad. Thick phone case interfering.	Ensure your device supports Qi wireless charging. Reposition the device to the center of the pad. Check power connections and ensure the power adapter is working. Remove any metal objects or cards from the pad. Remove the phone case or use a thinner one.
Slow charging.	Incompatible power adapter. Device not optimally aligned.	Use a Quick Charge 2.0/3.0 or Power Delivery (PD) compatible adapter (9V output recommended). Adjust device position on the pad.
Overheating.	Foreign object on the pad. Poor ventilation. Device misalignment.	Remove any foreign objects. Ensure adequate airflow around the charging pad. Reposition the device.

## SPECIFICATIONS

Model Number	IHQI1006W-OD
Brand	iHome
Input Voltage	9 Volts (DC)
Output Wattage	Up to 10 Watts (7.5W for iPhone)
Connector Type	Wireless (Qi standard)
Compatible Devices	Qi-compatible smartphones and devices
Special Features	Fast Charging, Anti-slip, Overheat protection, Minimalist design
Product Dimensions	10.52 x 10.52 x 0.36 cm
Item Weight	155 g
Color	White

## WARRANTY INFORMATION

iHome products are designed and manufactured to the highest quality standards. For specific warranty terms and

conditions, please refer to the warranty card included with your purchase or visit the official iHome website. This warranty typically covers defects in materials and workmanship under normal use.

## CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your iHome IHQI1006W-OD Airpad, please contact iHome customer support:

- **Website:** Visit the official iHome website for FAQs, support resources, and contact information.
- **Email/Phone:** Refer to the iHome website or your product packaging for specific email addresses or phone numbers for technical support.

© 2024 iHome. All rights reserved. iHome is a registered trademark.