

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Olayks](#) /

› [Olayks 2L Electric Steamer and Multi-functional Cooker Instruction Manual](#)

## Olayks OLK-01-06zl

# Olayks 2L Electric Steamer and Multi-functional Cooker

Model: OLK-01-06zl

[Introduction](#) [Safety Instructions](#) [Product Components](#) [Setup](#) [Operating Instructions](#) [Maintenance & Cleaning](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. INTRODUCTION

The Olayks 2L Electric Steamer and Multi-functional Cooker is designed for versatile cooking, offering both steaming and cooking capabilities in a compact unit. Its ceramic glaze non-stick pot and dual power settings (350W and 700W) make it suitable for preparing a variety of meals, from pasta and ramen to steak and hot pot. This appliance is ideal for small kitchens, offices, dormitories, or for travel due to its portable design.



Image 1.1: Overview of the Olayks 2L Electric Pot's key features, including its capacity, multi-purpose functionality, rapid heating, overheating protection, dual power adjustments, and ease of cleaning.

## 2. IMPORTANT SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please read and follow all instructions carefully before using the appliance.

- **Electrical Safety:** Ensure the voltage matches your power supply. Do not immerse the main unit or power cord in water or other liquids.
- **Power Cord:** Use only the provided detachable power cord. Do not use if the cord is damaged.

- **Heat and Steam:** The appliance generates heat and steam during operation. Exercise caution to avoid burns. Do not touch hot surfaces.
- **Supervision:** Close supervision is necessary when the appliance is used by or near children.
- **Ventilation:** Ensure adequate ventilation around the appliance during use.
- **Non-stick Coating:** To protect the ceramic non-stick coating, use only wooden or silicone utensils. Avoid metal utensils.
- **Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning. Do not immerse the bottom of the pot in water.
- **Overheat Protection:** The cooker is equipped with overheat protection. If it overheats, it may temporarily shut off and resume operation once cooled.
- **Intended Use:** Use the appliance only for its intended purpose as described in this manual.

### 3. PRODUCT COMPONENTS

---

The Olayks Electric Steamer and Multi-functional Cooker includes the following parts:

- **Main Electric Pot:** Features a 2L ceramic glaze non-stick inner surface.
- **Steamer Basket:** Made from Food-Grade ABS material, designed for simultaneous cooking and steaming.
- **Glass Lid:** Transparent lid with a handle and ventilation holes.
- **Power Control Knob:** Located on the front, with OFF, LOW (350W), and HIGH (700W) settings.
- **Detachable Power Cord:** For easy storage and portability.



## NON-STICK COATING

With the ceramic glaze non-stick coating, which can keep food from sticking, provides safe and healthy cooking.



## EASY TO CLEAN

Just rinse the electric pot with water to make it easy to clean.

**Tips:** Do not use steel balls to wash the inner.  
Wipe the stain gently in the cleaning process.  
Do not immerse the bottom into the water.



Image 3.1: The Olayks 2L Electric Steamer and Multi-functional Cooker, shown with its main pot and the included steamer basket.



Image 3.2: Detailed views highlighting the control knob, the transparent glass lid, and the ergonomic side handles of the electric cooker.

## 4. SETUP FOR FIRST USE

Before using your Olayks Electric Steamer and Multi-functional Cooker for the first time, please follow these steps:

1. Unpack all components and remove any packaging materials.
2. Wipe the exterior of the main unit with a damp cloth.
3. Wash the inner pot, steamer basket, and glass lid with warm, soapy water. Rinse thoroughly and dry completely.
4. Ensure the power cord is securely connected to the appliance and then plug it into a suitable electrical outlet.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power Control

The cooker features a dual power regulation function, allowing you to select between two heat settings:

- **350W (LOW):** Suitable for gentle cooking, such as preparing pasta, ramen, pancakes, or eggs.
- **700W (HIGH):** Ideal for faster cooking, including steak, soup, or hot pot.

To select a power setting, rotate the control knob to the desired position (LOW or HIGH). The indicator light will illuminate when the appliance is active.



Image 5.1: The adjustable power control knob, illustrating the 350W and 700W settings and suggested cooking applications for each.

### 5.2 Cooking Functions

The Olayks Electric Cooker supports various cooking methods:

- **Boiling:** Fill the pot with water or broth, add ingredients, and select the desired power setting.
- **Steaming:** Place water in the main pot, position the steamer basket with food above the water, and cover with the lid.
- **Frying/Sautéing:** Add a small amount of oil to the non-stick pot, heat to the desired temperature, and cook ingredients.
- **Hot Pot:** Prepare broth and ingredients, then cook directly in the pot at the table.

Always ensure the liquid level does not exceed the "MAX" fill line indicated inside the pot.

Your browser does not support the video tag.

Video 5.2: An official demonstration video showcasing various cooking applications of the Olayks Electric Hot Pot with Steamer, including frying, hot pot, ramen, stewing, congee, and stir-frying.

## 6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your appliance.

- **Unplug and Cool:** Always unplug the power cord and allow the cooker to cool completely before cleaning.
- **Inner Pot Cleaning:** The ceramic glaze non-stick surface is easy to clean. Use a soft sponge or cloth with mild dish soap and water. Do not use abrasive scouring pads, metal brushes, or steel wool, as these can scratch and damage the coating.
- **Exterior Cleaning:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the entire unit or its electrical components in water.
- **Steamer Basket and Lid:** Wash the steamer basket and glass lid with warm, soapy water. Rinse and dry thoroughly.
- **Storage:** Ensure all parts are dry before storing. Store the appliance in a cool, dry place.




Image 6.1: Visual guide to the non-stick coating and recommended cleaning method using a soft brush and water.

## 7. TROUBLESHOOTING

If you encounter any issues with your Olayks Electric Steamer and Multi-functional Cooker, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Power cord not properly connected or no power from outlet.	Ensure power cord is securely plugged into both the appliance and a working electrical outlet. Check the outlet with another device.
Food sticks to the pot.	Insufficient oil, high heat for too long, or damaged non-stick coating.	Use a small amount of oil. Adjust heat setting. Avoid metal utensils to prevent damage to the coating.
Appliance stops heating during use.	Overheat protection activated.	Unplug the appliance and allow it to cool down for a few minutes. It should resume normal operation once cooled.
Steam leakage from lid.	Lid not properly seated or food blocking steam vents.	Ensure the lid is placed correctly and securely. Check that food items are not obstructing the lid's fit or steam vents.

## 8. SPECIFICATIONS

- **Model Number:** OLK-01-06zl
- **Capacity:** 2 Liters

- **Power Settings:** 350W (Low), 700W (High)
- **Material:** ABS, Ceramic Glaze (inner pot)
- **Color:** White
- **Product Dimensions:** 10.16"D x 10.15"W x 8.7"H
- **Item Weight:** 2.59 pounds (approx. 1.18 Kilograms)
- **Special Feature:** Lightweight, Dual Power Control, Non-stick Ceramic Glaze, Overheat Protection, Steamer Basket included.



Image 8.1: Illustration of the upgraded full heating plate, emphasizing even and fast heating with good heat retention.



Image 8.2: Key durable and practical features, including the tempered glass lid, heat-proof exterior, and efficient heat dissipation system.

## 9. WARRANTY AND SUPPORT

The Olayks 2L Electric Steamer and Multi-functional Cooker comes with a one-year warranty and a 30-day refund policy.

For any questions, concerns, or warranty claims, please contact the Olayks customer service team through the Amazon buyer center. Our team aims to provide a satisfactory solution within 24 hours.

