

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Toyota](#) /

› [2021 Toyota Camry Owners Manual](#)

Toyota 2021 Toyota Camry

2021 Toyota Camry Owner's Manual

Official Instruction Manual for the 2021 Toyota Camry

INTRODUCTION

This manual provides comprehensive instructions and important information for the safe and efficient operation, maintenance, and care of your 2021 Toyota Camry. Please read this manual thoroughly to familiarize yourself with your vehicle's features and capabilities. Keep this manual in your vehicle for quick reference.



Image showing the 2021 Toyota Camry Owner's Manual, along with the Quick Reference Guide and Warranty & Maintenance Guide. These documents provide essential information for vehicle operation and care.

For specific details regarding your vehicle's warranty and scheduled maintenance, refer to the accompanying Warranty & Maintenance Guide. For quick access to frequently used information, consult the Quick Reference Guide.

VEHICLE SETUP AND PREPARATION

Before operating your Toyota Camry, it is important to perform a few basic checks to ensure safe driving conditions.

- **Tire Pressure:** Verify that all tires are inflated to the recommended pressure levels as indicated on the tire placard located on the driver's side door jamb.
- **Fluid Levels:** Check engine oil, coolant, brake fluid, and windshield washer fluid levels regularly. Refer to the Maintenance section for detailed instructions.
- **Lighting:** Ensure all exterior lights (headlights, taillights, turn signals, brake lights) are functioning correctly.
- **Seat Adjustment:** Adjust the driver's seat and steering wheel for a comfortable and safe driving position.
- **Mirror Adjustment:** Adjust the rearview and side mirrors to provide clear visibility of the areas around the vehicle.

OPERATING THE VEHICLE

This section covers the fundamental operations of your 2021 Toyota Camry.

Starting and Stopping the Engine

1. Ensure the vehicle is in Park (P) or Neutral (N) and the parking brake is engaged.
2. Insert the key into the ignition or ensure the Smart Key is inside the vehicle.
3. Press the brake pedal firmly.
4. Turn the key to START or press the ENGINE START/STOP button.
5. To stop the engine, shift to Park (P) and turn the key to LOCK or press the ENGINE START/STOP button.

Dashboard Indicators and Warnings

Familiarize yourself with the various warning lights and indicators on your dashboard. Consult the detailed section in the full owner's manual for specific meanings and actions required for each indicator.

Transmission Operation

The 2021 Toyota Camry is equipped with an automatic transmission. Use the shift lever to select the desired gear:

- **P (Park):** Locks the transmission and prevents the wheels from turning. Use when parking.
- **R (Reverse):** For backing up the vehicle.
- **N (Neutral):** Disengages the transmission. Use when stopped for short periods or when towing.
- **D (Drive):** For normal forward driving.
- **S (Sport/Sequential Shiftmatic):** Allows for manual gear selection for a sportier driving experience.

MAINTENANCE

Regular maintenance is crucial for the longevity and optimal performance of your 2021 Toyota Camry. Adhere to the recommended service schedule outlined in the Warranty & Maintenance Guide.

Routine Checks

- **Engine Oil:** Check oil level and condition every 5,000 miles or every 6 months, whichever comes first.
- **Tire Rotation:** Rotate tires every 5,000 to 7,500 miles to ensure even wear.
- **Brake System:** Inspect brake pads, rotors, and fluid levels at every service interval.
- **Battery:** Check battery terminals for corrosion and ensure proper charge, especially in extreme temperatures.
- **Air Filters:** Inspect engine air filter and cabin air filter regularly and replace as needed.

For detailed instructions on performing these checks and more complex maintenance procedures, refer to the specific sections within your owner's manual.

TROUBLESHOOTING COMMON ISSUES

This section provides guidance on addressing common issues you might encounter with your 2021 Toyota Camry.

Problem	Possible Cause	Solution
Engine won't start	Dead battery, empty fuel tank, faulty starter.	Check battery terminals, add fuel, or consult a qualified technician.
Warning light illuminated	Indicates a system malfunction (e.g., Check Engine, ABS, Airbag).	Refer to the dashboard indicator section in the manual for specific light meanings. Seek professional diagnosis if necessary.

Problem	Possible Cause	Solution
Flat tire	Puncture, low pressure.	Safely pull over, engage parking brake, and use the spare tire and jack kit to replace the flat tire. Refer to the manual for detailed instructions on tire changing.

For more complex issues or if a problem persists, it is recommended to contact an authorized Toyota service center.

SPECIFICATIONS

This section outlines the general specifications of the 2021 Toyota Camry Owner's Manual itself, as provided by the publisher.

Publisher: Auto Manuals

Publication Date: January 1, 2021

Language: English

Print Length: Approximately 500 pages

Item Weight: 1.08 pounds (approx. 0.49 kg)

Dimensions: 8.4 x 5.45 x 0.85 inches (approx. 21.3 x 13.8 x 2.1 cm)

Note: Vehicle specifications such as engine type, fuel capacity, and dimensions are detailed within the manual itself.

WARRANTY AND SUPPORT

For detailed information regarding your vehicle's warranty coverage, including terms, conditions, and limitations, please refer to the separate Warranty & Maintenance Guide provided with your vehicle. This guide contains crucial information about your vehicle's protection plan.

Should you require technical assistance, have questions about your vehicle's operation, or need to schedule service, please contact your authorized Toyota dealership. They are equipped to provide expert support and genuine Toyota parts.

You can also find additional support and resources on the official Toyota website or by contacting Toyota customer service directly. Refer to the contact information provided in your vehicle's documentation.