

## INSPIRE

# Inspire 36" Large Surface Steam Press User Manual

Model: INSPIRE

Take the hassle out of ironing with the INSPIRE 36 large surface electronic deluxe steam press. This manual provides essential information for safe and effective use.

## 1. PRODUCT OVERVIEW

The Inspire 36" Large Surface Steam Press is designed to provide efficient and powerful garment pressing. It features a large pressing surface, steam and dry capabilities, and an LED temperature display for precise control.




Figure 1.1: Inspire 36" Large Surface Steam Press with included accessories (water tank, spray bottle).

### Key Components:

- **Pressing Plate:** The large heated surface for pressing garments.
- **Lower Pressing Board:** The padded surface where garments are placed.
- **Handle:** For raising and lowering the pressing plate.
- **Control Panel:** Features LED display and buttons for temperature and steam settings.
- **Water Tank:** Removable tank for steam generation.
- **Steam Burst Buttons:** Located on the handle for quick steam release.

## 2. SETUP AND INITIAL USE

### 2.1 Unpacking

1. Carefully remove the steam press and all accessories from the packaging.

2. Inspect the unit for any signs of damage. Do not use if damaged.
3. Retain packaging for future storage or transport.

## 2.2 Placement

Place the steam press on a stable, flat, heat-resistant surface. Ensure there is adequate space around the unit for safe operation and ventilation.

## 2.3 Filling the Water Tank (for Steam Function)

1. Ensure the steam press is unplugged and cool.
2. Remove the water tank from the unit.
3. Fill the tank with distilled or demineralized water. Do not overfill.
4. Securely reinsert the water tank into its designated slot.

**Note:** Using tap water may lead to mineral buildup and reduce the lifespan of the unit. Always use distilled or demineralized water.

# 3. OPERATING INSTRUCTIONS

## 3.1 Powering On and Temperature Selection

1. Plug the power cord into a suitable electrical outlet.
2. The LED display will illuminate. Use the temperature control buttons on the control panel to select the desired fabric setting (e.g., Nylon, Silk, Wool, Cotton, Linen).
3. Allow the press to preheat until the indicator light signals it has reached the set temperature.



Figure 3.1: Control panel with fabric type selections and LED display.

## 3.2 Pressing Garments

1. Place the garment flat on the lower pressing board, ensuring it is smooth and free of wrinkles.
2. Carefully lower the pressing plate using the handle until it rests on the garment. The press applies up to 100 lbs. of pressure.
3. For steam pressing, press the steam burst buttons located on the handle. Hold for a few seconds, then release.
4. For dry pressing, simply lower the plate without activating steam.
5. Lift the pressing plate and reposition the garment as needed.



Figure 3.2: Top view illustrating the large pressing surface and handle.

## 3.3 Safety Features

- **Auto-Off:** The unit features a timed safety auto shutoff for protection.
- **Audible Safety Alarm:** An alarm will sound if the press is left closed for too long, indicating the auto-off feature is about to activate.

## 4. MAINTENANCE

---

### 4.1 Cleaning the Pressing Plate

Ensure the unit is unplugged and completely cool before cleaning.

- Wipe the non-stick Teflon heating plate with a soft, damp cloth.
- For stubborn residue, use a mild, non-abrasive cleaner specifically designed for non-stick surfaces.
- Do not use abrasive pads or harsh chemicals, as they can damage the coating.

### 4.2 Draining the Water Tank

Regularly drain and clean the water tank to prevent mineral buildup.

1. Remove the water tank.
2. Empty any remaining water.
3. Rinse the tank with clean water.
4. Allow the tank to air dry before reinserting or storing.

### 4.3 Storage

The Inspire Steam Press is designed for vertical storage, allowing it to fit into tight spaces.

- Ensure the unit is cool and dry before storing.
- Store in a clean, dry place away from direct sunlight and extreme temperatures.

## 5. TROUBLESHOOTING

---

If you encounter issues with your Inspire Steam Press, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Press not heating	Not plugged in; Power outlet issue; Unit malfunction	Check power connection; Try a different outlet; Contact customer support
No steam production	Water tank empty; Tank not properly inserted; Unit not hot enough	Fill water tank; Reinsert tank correctly; Allow unit to preheat fully
Audible alarm sounds	Pressing plate held down too long; Auto-off activating	Lift the pressing plate to reset the timer; Reposition garment and continue pressing
Water leaking	Overfilled water tank; Tank not sealed properly; Mineral buildup	Do not overfill; Ensure tank is securely sealed; Clean tank and steam vents

## 6. SPECIFICATIONS

Feature	Detail
Model Name	INSPIRE
Pressing Plate Size	36" x 12"
Power	1600 Watts
Pressure	Up to 100 lbs.
Display	LED Temperature Display
Capabilities	Steam and Dry
Heating Plate	Non-stick Teflon
Special Features	Auto-Off, Audible Safety Alarm, Vertical Storage
Recommended Uses	T-Shirt, Hat, Cap, Socks, Pillow, Bag, Commercial