Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CODACE CODACE-XXX

CODACE Keyless Entry Door Lock with Double-Sided Keypad Handle

Model: CODACE-XXX

Brand: CODACE

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your CODACE Keyless Entry Door Lock. This 100% mechanical lock offers enhanced security and convenience with its double-sided keypad and durable construction. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your lock.

Product Features

- **100% Mechanical & Keyless:** No batteries, power, or wiring required. Eliminates concerns about lost keys or electronic malfunctions, providing a stable and robust locking system.
- **Double-Sided Keypads:** Unique design allows setting different passwords for the internal and external keypads. This feature is ideal for enhanced security, especially for households with children, preventing unauthorized exit.
- **Automatic Locking:** The lock automatically engages when the door is closed, ensuring your home's security without needing to remember to lock it manually.
- **Normal Open Mode:** A convenient feature that allows the lock to function as a regular door handle without requiring a password for entry or exit. This is useful for frequent access, such as during gatherings or for elderly users.
- **Enhanced Durability:** Constructed from #304 stainless steel with a reinforced anti-corrosion coating, making it waterproof, sun-resistant, and rust-proof. Suitable for outdoor use on entry doors, gates, and fences.
- **Easy Installation:** Designed for straightforward installation with a Phillips screwdriver. Includes templates and instructions to simplify the process.



Image: Overview of the CODACE Keyless Entry Door Lock's main features, including its mechanical nature, waterproof design, and ease of installation.

Important Safety Information

- Always ensure the door frame and door are structurally sound before installation.
- Do not use power tools for tightening screws, as this may damage the lock components.
- Keep children away from the installation area to prevent accidents.
- Test the lock's functionality thoroughly after installation to ensure it operates correctly.
- Regularly inspect the lock for any signs of wear or damage.

Package Contents

Please verify that all parts are present before beginning installation:

- Exterior Keypad Handle Assembly
- Interior Keypad Handle Assembly
- Latch Bolt (Backset: 60mm standard)
- Strike Plate
- Mounting Screws
- Installation Template
- User Manual

Setup and Installation

1. Pre-Installation Checks

- **Door Thickness:** This lock is suitable for door thicknesses between 35mm and 80mm (1-3/8" to 2-15/16").
- **Backset:** The standard latch bolt provided has a 60mm backset.
- **Hole Requirements:** Ensure your door has the necessary 10mm and 15mm holes as indicated in the diagram.



Image: Detailed dimensions for door thickness, backset, and required holes for installation.

2. Adjusting Handle Orientation

The lock works with both left and right-handed doors. The handle orientation can be adjusted during installation to match your door's swing direction.



Image: Illustration of how the handle orientation can be adjusted for both left and right-handed door installations.

3. Important: Triangle Mark Alignment

During installation, it is crucial to rotate the triangular marks on both the front and internal panels to point towards the door handle. This ensures correct mechanism alignment.



Image: Close-up view of the triangular marks on the lock mechanism, emphasizing their correct alignment during assembly.

4. General Installation Steps

1. Prepare the door according to the provided template, ensuring all holes are drilled correctly.
2. Install the latch bolt into the door edge.
3. Attach the exterior keypad handle, ensuring the spindle passes through the latch mechanism.
4. Align the triangular marks as instructed above.
5. Install the interior keypad handle, connecting it to the exterior unit.
6. Secure both units with the provided mounting screws.
7. Install the strike plate on the door frame.
8. Test the lock's functionality before closing the door completely.

If the accessories are too long for your door thickness, they can be shortened. Measure carefully before cutting.

Operating Instructions

1. Setting Passwords

- The lock supports passwords of 4-7 digits.
- Passwords can be entered in any order. For example, if your password is '1234', pressing '4321' will also unlock the door. This is a design feature.
- Refer to the detailed instructions included with your product for specific steps on how to set or change the password for both the internal and external keypads.

2. Double-Sided Keypad Operation

This lock features keypads on both the exterior and interior sides. This means a password is required to unlock the door from both directions. This is particularly useful for preventing young children from opening the door unsupervised.



Image: The double-sided keypad feature, designed to enhance security and protect children by requiring a password for exit.

3. Auto-Lock Function

The lock is designed to automatically engage and secure the door once it is closed. This provides peace of mind, ensuring

your door is always locked when shut.

4. Normal Open Mode

To activate the Normal Open Mode, follow the instructions provided in your product's specific guide. When this mode is active, the door lock functions as a standard handle, allowing free entry and exit without a password. This is convenient for periods of high traffic or when you do not require the door to be locked.



Image: Visual representation of the Auto-Lock feature and the Normal Open Mode, highlighting their benefits for security and convenience.

Maintenance

- **Cleaning:** Wipe the lock surface with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lubrication:** Periodically apply a small amount of graphite lubricant to the internal mechanisms (e.g., latch bolt) to ensure smooth operation. Do not use oil-based lubricants, as they can attract dust and grime.
- **Inspection:** Regularly check all screws and components for tightness. Ensure the lock operates smoothly without

excessive force.

- **Durability:** The lock is designed to be waterproof, sun-resistant, and rust-proof, making it suitable for various environmental conditions. However, extreme conditions may still affect its lifespan.

Troubleshooting

Problem	Possible Cause / Solution
Lock does not engage automatically.	Ensure the door is fully closed and the latch bolt aligns correctly with the strike plate. Check if Normal Open Mode is activated.
Keypad does not respond or unlock.	Verify the correct password is being entered. Remember that the order of digits does not matter. Ensure the lock mechanism is not jammed.
Handle feels loose or wobbly.	Check and tighten all mounting screws. Ensure the internal components are properly seated.
Difficulty in turning the handle.	Apply a small amount of graphite lubricant to the latch bolt and internal mechanisms. Check for any obstructions in the door frame or latch area.
Triangle marks not aligned during installation.	This can cause operational issues. Re-install the lock, carefully following the instructions to align the triangular marks towards the door handle.
Accessories (spindles/screws) are too long.	The accessories can be shortened to fit your door thickness. Measure carefully and cut to the appropriate length.

Specifications

Feature	Detail
Brand	CODACE
Model Number	CODACE-XXX
Material	Stainless Steel (#304)
Color	Silver
Lock Type	Keypad, Combination Lock
Special Features	Adjustable, Rust-resistant, Keyless
Applicable Door Thickness	35 mm - 80 mm (1-3/8" to 2-15/16")
Backset	Standard 60 mm
Password Length	4-7 digits (order does not matter)

Feature	Detail
Product Dimensions (Package)	23.29 x 19.71 x 10.59 cm; 1.79 kilograms
Recommended Uses	Home Security, Entry Doors, Gates, Fences

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or contact CODACE customer service directly. Details regarding warranty periods and claims procedures are typically provided at the point of purchase or on the manufacturer's official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question