

[Manuals.plus](#) /

› [MAS CARNEY](#) /

› MAS CARNEY F3 Portable Bluetooth Speaker User Manual

MAS CARNEY F3

MAS CARNEY F3 Portable Bluetooth Speaker User Manual

Model: F3

INTRODUCTION

Thank you for choosing the MAS CARNEY F3 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device.



Image: Front view of the MAS CARNEY F3 Portable Bluetooth Speaker, showcasing its compact design.

PACKAGE CONTENTS

Ensure all items are present in the package:

- MAS CARNEY F3 Portable Bluetooth Speaker
- Micro USB Charging Cable
- User Guide (this document)

PRODUCT OVERVIEW

The MAS CARNEY F3 is a compact and versatile portable Bluetooth speaker designed for various environments. It features a 52mm powerful speaker, integrated microphone, and multiple playback options.

- **Powerful Sound:** Equipped with a 3W driver and passive subwoofer for enhanced bass.
- **Multiple Audio Sources:** Supports Bluetooth 5.0, Micro SD card, USB disk, and AUX input.
- **Long Playtime:** Built-in 950mAh rechargeable battery provides up to 8 hours of playback.
- **Compact Design:** Lightweight (270g) and small (9.2cm x 9.2cm x 4.6cm) for portability.
- **Integrated Microphone:** Allows for hands-free calls.

TF Card and U Disk Support



Bluetooth
Connection



8 Hour
Playtime



Loud
Volume



TF Memory
Card



U Disk
Connection



USB
charging



Image: Top view of the MAS CARNEY F3 speaker showing the TF card slot, USB port, ON/OFF switch, and Micro USB charging port.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied Micro USB charging cable to the speaker's Micro USB port and the other end to a USB power adapter (not included) or a computer's USB port.

- Charging Time: Approximately 8 hours for a full charge.
- Battery Type: Lithium Ion.

2. Powering On/Off

Locate the ON/OFF switch on the speaker. Slide the switch to the "ON" position to power on the speaker. Slide it to the "OFF" position to power off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode. The speaker will typically enter pairing mode automatically when powered on for the first time or if no device is connected.
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices and select "F3" from the list.
4. Once paired, the speaker will indicate a successful connection (e.g., an audible prompt or LED indicator change).
5. The speaker is compatible with all Bluetooth 5.0 devices.

Bluetooth 5.0

Compatible with all Bluetooth 5.0 enabled devices



Image: A user connecting their smartphone to the MAS CARNEY F3 speaker via Bluetooth, illustrating wireless connectivity.

OPERATING INSTRUCTIONS

Button Functions

The speaker features several control buttons on its side:

Powerful Function

Built-in 52mm Powerful Speaker and Microphone
Super Clear Voice for Travel Outdoor, 8 Hour Playtime



Single Click :Pause or answer a call.
Double Click : Ring up last call.
Long Press: Cancel bluetooth pairing.

Single Click :Turn up volume.
Long Press : For next song.

Click:Decrease volume.
Long press: Previous song.

Single Click:Switch bluetooth,
USB, TF card connection.

Image: Diagram illustrating the functions of the control buttons on the side of the MAS CARNEY F3 speaker.

- **Play/Pause Button (▶ ||):**

- Single Click: Pause or answer a call.
- Double Click: Ring up last call.
- Long Press: Cancel Bluetooth pairing.

- **Volume Up / Next Track Button (+):**

- Single Click: Turn up volume.
- Long Press: For next song.

- **Volume Down / Previous Track Button (-):**

- Single Click: Decrease volume.
- Long Press: Previous song.

- **Mode Button (M):**

- Single Click: Switch between Bluetooth, USB, and TF card connection modes.

Playing Audio

The F3 speaker supports multiple audio input methods:

- **Bluetooth Mode:** After successful pairing, audio from your connected device will play through the speaker.
- **Micro SD Card Mode:** Insert a Micro SD card (TF card) with audio files into the TF card slot. The speaker will automatically switch to TF card mode and begin playback.
- **USB Disk Mode:** Insert a USB flash drive with audio files into the USB port. The speaker will automatically switch to USB mode and begin playback.
- **AUX Mode:** Connect an audio device using a 3.5mm AUX cable (not included) to the speaker's AUX input. The speaker should automatically switch to AUX mode.

Hands-Free Calling

When connected via Bluetooth to a smartphone, you can use the speaker for hands-free calls:

- **Answer Call:** Single click the Play/Pause button.
- **End Call:** Single click the Play/Pause button.
- **Redial Last Number:** Double click the Play/Pause button.

MAINTENANCE

To ensure the longevity and optimal performance of your MAS CARNEY F3 speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners, alcohol, or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The speaker is indicated as waterproof. However, avoid submerging it in water for extended periods or exposing it to high-pressure water jets. Ensure all ports are securely covered if applicable before exposure to water.
- **Battery Care:** To preserve battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for prolonged periods.

TROUBLESHOOTING

If you encounter issues with your speaker, refer to the following common problems and solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Speaker does not power on.	• Ensure the battery is charged. Connect the speaker to a power source using the Micro USB cable. • Verify the ON/OFF switch is in the "ON" position.
Cannot pair with Bluetooth device.	• Ensure the speaker is in Bluetooth pairing mode. • Make sure Bluetooth is enabled on your device. • Move the speaker closer to your device (maximum range 5 meters). • Turn off and on both the speaker and your Bluetooth device. • Clear previous Bluetooth connections on your device and try pairing again. • Long press the Play/Pause button on the speaker to cancel current Bluetooth pairing and re-enter pairing mode.
No sound or low volume.	• Increase the volume on both the speaker and your connected device. • Ensure the speaker is correctly paired via Bluetooth or the Micro SD/USB/AUX source is properly connected. • Check if the audio file format is supported.
Micro SD card or USB disk not recognized.	• Ensure the Micro SD card or USB disk is inserted correctly. • Verify that the audio files are in a compatible format. • Try switching modes using the 'M' button to ensure the speaker is in the correct playback mode.

SPECIFICATIONS

Detailed technical specifications for the MAS CARNEY F3 Portable Bluetooth Speaker:

Feature	Detail
Model Number	F3
Brand	MAS CARNEY
Speaker Size	52 Millimeters
Output Wattage	3 Watts
Impedance	4 Ohms
Frequency Response	20000 Hz
Wireless Technology	Bluetooth 5.0
Compatible Devices	All Bluetooth 5.0 devices (Smartphones, Tablets)

Feature	Detail
Connectivity Technology	Bluetooth, Auxiliary, USB
Special Features	TF Card support, USB Disk support
Power Source	Battery Powered
Battery Type	Lithium Ion (1 Lithium Metal battery included)
Battery Capacity	950mAh
Playtime	Up to 8 Hours
Charging Time	8 Hours
Item Weight	270 g
Dimensions (D x W x H)	9D x 9.2W x 9.2H centimeters
Maximum Range	5 Meters (Bluetooth)
Waterproof	Yes
Material Type	Copper (internal components)
Color	Black

Portable Bluetooth Speaker

Compatible with all Bluetooth 5.0 enabled devices



Image: Detailed view of the MAS CARNEY F3 speaker with its dimensions (9.2cm x 9.2cm x 4.6cm) and weight (218g) indicated.

WARRANTY AND SUPPORT

The MAS CARNEY F3 Portable Bluetooth Speaker comes with a user guide and friendly customer service. For specific warranty details or support inquiries, please refer to the contact information provided with your purchase or visit the official MAS CARNEY website.

Included Components: Micro USB Charging Cable, Portable Bluetooth Speaker F3 *1, User Guide.

