

[manuals.plus](#) /› [APPASO](#) /› **APPASO Matte Black Kitchen Faucet with Pull-Down Sprayer and Soap Dispenser (Model AP-APS135BS) User Manual**

APPASO AP-APS135BS

APPASO Matte Black Kitchen Faucet with Pull-Down Sprayer and Soap Dispenser (Model AP-APS135BS) User Manual

1. INTRODUCTION

Thank you for choosing the APPASO Matte Black Kitchen Faucet with Pull-Down Sprayer and Soap Dispenser. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new kitchen faucet. Please read these instructions thoroughly before installation and retain them for future reference.



Image: The complete APPASO Matte Black Kitchen Faucet and Soap Dispenser set.

2. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Kitchen Faucet Assembly
- Soap Dispenser
- Deck Plate (for 2-hole or 4-hole sinks)
- Installation Hardware
- Hot and Cold Water Supply Lines
- Weight Ball for Pull-Down Sprayer
- Instruction Manual (this document)

APPASO

PACKAGE



Image: All components included in the APPASO kitchen faucet package.

3. SPECIFICATIONS

Brand	APPASO
Model Number	AP-APS135BS
Color	Matte Black
Finish Type	Matt
Material	Stainless Steel
Mounting Type	Deck Mount
Hole Count	2 (suitable for 2-hole or 4-hole sinks with deck plate)
Number of Handles	1
Spout Height	8 Inches
Spout Reach	7.8 Inches
Maximum Flow Rate	1.8 Gallons Per Minute

Special Features	360° Swivel, Dual Function Sprayer, Leak Resistant, Pull Down Sprayer
Product Dimensions	13.78 x 2.76 x 17.72 inches
Item Weight	0.95 Pounds (15.2 ounces)



Image: Detailed dimensions and mounting requirements for the APPASO kitchen faucet.

4. SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance.
- Wear appropriate safety gear, such as safety glasses, during installation.
- Ensure all connections are tightened securely to prevent leaks, but do not overtighten.
- If you are unsure about any step, consult a qualified plumber.

5. SETUP & INSTALLATION

This deck-mount kitchen faucet is designed for easy installation, suitable for 2-hole or 4-hole sinks. No professional plumber is typically required, and installation can often be completed in approximately 20 minutes by following these steps:

- 1. Prepare the Sink Area:** Turn off the water supply to your sink. Clear the area under the sink and ensure the mounting surface is clean and dry.

2. **Install the Faucet:** Insert the faucet body through the main hole in your sink or deck plate. Secure it from underneath with the provided mounting hardware.
3. **Connect Water Supply Lines:** Attach the hot and cold water supply lines to the corresponding connections on the faucet body and to your home's water supply valves. Ensure a tight seal.
4. **Install Pull-Down Sprayer Hose:** Connect the pull-down sprayer hose to the designated port on the faucet. Attach the weight ball to the hose underneath the sink to ensure smooth retraction.
5. **Install Soap Dispenser:**
 - a. Install the soap dispenser escutcheon and gasket into the designated mounting hole (typically 1-1/2 inches).
 - b. Install the soap bottle to the sink and fill it with liquid soap (bottle capacity: 11 oz).
 - c. Secure the flat end of the tube to the pump, then attach the pump to the soap bottle.



Image: Step-by-step guide for installing the soap dispenser.

6. **Test for Leaks:** Once all connections are secure, slowly turn on the main water supply and check for any leaks. Tighten connections as needed.

6. OPERATING INSTRUCTIONS

Your APPASO kitchen faucet is designed for ease of use and versatility:

- **Water Flow Activation:** Lift the single handle to turn on the water flow. Move the handle left for hot water and right for cold water.
- **360° Swivel Spout:** The faucet spout can rotate 360 degrees, providing flexibility for various sink configurations and

tasks.

- **Pull-Down Sprayer:** The sprayer head features a 20-inch extended retractable hose, allowing you to reach all areas of your sink for efficient cleaning. The weight ball ensures smooth retraction after use.
- **Dual-Function Sprayhead:** The sprayhead offers two distinct water modes:
 - **Stream Mode:** Provides a steady, aerated flow for filling pots and general washing.
 - **Spray Mode:** Delivers a powerful spray for rinsing dishes and removing stubborn food debris.

2-Function WATER MODES



Stream

Spray



Image: Illustration of the stream and spray water modes available on the faucet's pull-down sprayer.

20" Flexible Pull-Down Sprayer



Weight Ball Achieves Retraction Effect

Image: The flexible 20-inch pull-down sprayer hose and the weight ball mechanism for smooth retraction.

- **Soap Dispenser:** Press the top of the soap dispenser pump to dispense liquid soap directly into your sink.

7. MAINTENANCE & CARE

Proper care will ensure the longevity and appearance of your APPASO faucet:

- **Cleaning the Finish:** The matte black finish is designed to resist fingerprints and spots. Clean regularly with a soft, damp cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- **Aerator Maintenance:** The faucet features a honeycomb-shaped aerator with multiple filters. Periodically unscrew the aerator from the sprayhead and rinse it under running water to remove any mineral buildup or debris. This helps maintain optimal water flow and quality.
- **Ceramic Cartridge:** The faucet is equipped with a no-leaking ceramic cartridge, which generally requires no maintenance. If persistent drips occur, consult the troubleshooting section.
- **Soap Dispenser Refill:** To refill the soap dispenser, simply lift the pump head and pour liquid soap directly into the reservoir from the top.



5-Layer Matte Black Finish



Anti-Fingerprint

Image: Illustration of the 5-layer matte black finish, highlighting its anti-fingerprint and anti-corrosion properties.

8. TROUBLESHOOTING

If you encounter any issues with your faucet, refer to the following common problems and solutions:

- **Low Water Flow:** Check if the aerator is clogged with debris. Clean the aerator as described in the Maintenance section. Ensure water supply valves are fully open.
- **Leaking from Spout:** A persistent drip from the spout may indicate an issue with the ceramic cartridge. While designed to be leak-resistant, extreme water pressure or debris can sometimes affect it. Contact customer support if cleaning the aerator does not resolve the issue.
- **Sprayer Not Retracting Properly:** Ensure the weight ball on the pull-down hose underneath the sink is positioned correctly and not obstructed. Clear any items that might be interfering with the hose's movement.
- **No Water from Soap Dispenser:** Check if the soap reservoir is empty and refill if necessary. Ensure the pump tube is securely attached to the pump head and extends into the soap.

9. WARRANTY INFORMATION

The APPASO Matte Black Kitchen Faucet (Model AP-APS135BS) comes with a **5-Year Limited Warranty**. This warranty covers defects in material and manufacturing under normal use and service. Please retain your proof of purchase for warranty claims. For specific terms and conditions, or to initiate a warranty claim, please contact APPASO customer support.

10. SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please visit the official APPASO store or contact our customer service team. You can find more information at the [APPASO Store on Amazon](#).