

[manuals.plus](#) /

› [Portronics](#) /

› [Portronics Toad 24 Wireless Mouse User Manual](#)

## Portronics Toad 24 (POR-1611)

# Portronics Toad 24 Wireless Mouse User Manual

Model: POR-1611 | Brand: Portronics


## 1. INTRODUCTION

Thank you for choosing the Portronics Toad 24 Wireless Mouse. This device offers a reliable and lag-free wireless connection, adjustable DPI settings, and an ergonomic design for comfortable use. This manual will guide you through the setup, operation, and maintenance of your new wireless mouse.

# LOW POWER CONSUMPTION

Turns off automatically to save power

2 x AAA Battery  
Required



Battery Not Included

The Portronics Toad 24 Wireless Mouse features an ergonomic design for comfortable handling during extended use.

## 2. PACKAGE CONTENTS

- Portronics Toad 24 Wireless Mouse
- USB Nano Receiver
- User Manual

## 3. SETUP INSTRUCTIONS

### 3.1 Battery Installation

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert two AAA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Close the battery compartment cover.

# NANO DONGLE FOR EASY PAIRING

Easy wireless connectivity with the  
2.4 GHz band



The underside of the mouse reveals the battery compartment for two AAA batteries, the USB Nano Dongle storage slot, and the On/Off switch.

## 3.2 Connecting the USB Nano Receiver

1. Remove the USB Nano Receiver from its storage slot on the underside of the mouse.
2. Plug the USB Nano Receiver into an available USB port on your computer (laptop, Mac, or PC).
3. Turn on the mouse using the On/Off switch located on the underside.
4. The mouse is plug-and-play; no additional drivers or software installation is required. It will automatically connect to your computer system.

# ERGONOMIC DESIGN

Designed for your comfort with a click wheel  
and side buttons for easy usage



The 2.4 GHz USB Nano Dongle provides a hassle-free wireless connection to your device.

# TOAD 24

## Wireless Optical Mouse



2.4GHz Wireless  
Technology



Adjustable  
DPI



Optical  
Orientation



Low Energy  
Consumption



Works Over  
30 Lacs Clicks

MRP  
**₹ 599/-**

POR 1611 - Black

The compact USB Nano Dongle ensures easy wireless connectivity.

## 4. OPERATING INSTRUCTIONS

### 4.1 Basic Functions

- **Left Click Button:** Primary button for selecting items and executing commands.
- **Right Click Button:** Secondary button for accessing context menus and additional options.
- **Scroll Wheel:** Use for smooth scrolling through documents and web pages. It also functions as a middle click button.
- **Previous & Next Page Buttons:** Located on the side of the mouse, these buttons allow for quick navigation in web browsers and file explorers.

# MULTIFUNCTION BUTTON

Easy to use mouse with buttons for multiple functions



The Portronics Toad 24 features multiple buttons for enhanced functionality, including dedicated previous and next page buttons.

## 4.2 Adjusting DPI (Sensitivity)

The Portronics Toad 24 Wireless Mouse features an adjustable DPI switch, allowing you to change the cursor sensitivity to match your preference or task. The available DPI settings are 800, 1000, 1200, and 1600.

1. Locate the DPI Switch Button, usually positioned below the scroll wheel.
2. Press the DPI button to cycle through the available sensitivity settings. The cursor speed will change with each press.

# 2.4 GHz CONNECTIVITY

---

Hassle-free connections with USB  
nano dongle



Adjust the mouse sensitivity with the DPI switch, offering settings from 800 to 1600 DPI.

## 5. MAINTENANCE

---

### 5.1 Cleaning

- To clean the mouse, use a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- Do not use harsh chemicals or abrasive materials, as these can damage the mouse surface.

### 5.2 Battery Replacement

When the mouse performance degrades or it stops responding, it's likely time to replace the batteries. Follow the battery installation steps in Section 3.1.

### 5.3 Power Saving

The Portronics Toad 24 Wireless Mouse is designed with low power consumption and will automatically turn off after a period of inactivity to conserve battery life. To reactivate, simply move the mouse or click a button.

## 6. TROUBLESHOOTING

- **Mouse not responding:**

- Ensure the mouse is turned on using the On/Off switch.
- Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
- Verify that the USB Nano Receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- Move the mouse closer to the USB receiver to rule out range issues (effective range is up to 10 meters).

- **Lag or intermittent connection:**

- Ensure there are no large metallic objects or other wireless devices operating on the 2.4 GHz band that might cause interference between the mouse and the receiver.
- Try moving the receiver to a different USB port, preferably one closer to the mouse.

- **Cursor movement is erratic or imprecise:**

- Clean the optical sensor on the underside of the mouse.
- Ensure you are using the mouse on a suitable surface. Highly reflective or transparent surfaces may affect tracking.
- Adjust the DPI setting to a level that suits your preference (refer to Section 4.2).

## 7. SPECIFICATIONS

|                                       |   |
|---------------------------------------|---|
| <b>Brand</b>                          | Portronics                              |
| <b>Model Name</b>                     | Toad 24                                 |
| <b>Item Model Number</b>              | POR-1611                                |
| <b>Connectivity Technology</b>        | 2.4 GHz Wireless (USB Nano Receiver)    |
| <b>Movement Detection</b>             | Optical                                 |
| <b>Adjustable DPI</b>                 | 800 / 1000 / 1200 / 1600                |
| <b>Operating System Compatibility</b> | Windows 7/8/10/11, macOS                |
| <b>Power Source</b>                   | Battery Powered (2 x AAA, not included) |
| <b>Average Battery Life</b>           | Up to 12 Months                         |
| <b>Product Dimensions (LxWxH)</b>     | 14 x 8.5 x 4.8 cm                       |
| <b>Item Weight</b>                    | 90 g                                    |
| <b>Color</b>                          | Black                                   |

## 8. WARRANTY AND SUPPORT

### 8.1 Warranty Information

For specific warranty terms and conditions, please refer to the warranty card included with your product or contact Portronics customer support. Warranty coverage typically begins from the date of purchase.

### 8.2 Customer Support

If you encounter any issues or have questions regarding your Portronics Toad 24 Wireless Mouse, please contact Portronics

customer support:

- **Phone:** 9555-245-245
- **Manufacturer:** Portronics Digital Pvt Ltd.

© 2026 Portronics. All rights reserved.