

Laurastar Lift Xtra 1980

Laurastar Lift Xtra 1980 Steam Iron User Manual

Swiss Engineered 3-in-1 Steam Generator

1. PRODUCT OVERVIEW

The Laurastar Lift Xtra 1980 is a portable 3-in-1 steam generator designed for ironing, steaming, and purifying clothing. This system features a professional iron with a 3D soleplate, eliminating the need for temperature adjustments and preventing creases. Its unique design and powerful steam simplify garment care.

Key Features:

- **Versatile Use:** Easily iron on a traditional board or steam fabrics directly on a hanger.
- **Professional Results:** Achieves perfect results in a single movement for all fabrics and colors with its professional iron and steam.
- **Crease Prevention:** Features an exclusive 3D soleplate to effectively prevent creases.
- **Automatic Temperature:** Pre-set optimal temperature for all fabrics, eliminating manual adjustments.
- **Fabric Purification:** Utilizes Laurastar DMS (Dry Microfine Steam) to eliminate dust mites, bacteria, and fungi resistant to lower temperature washing cycles.
- **Dual Shut-Off Mode:** Offers a 10-minute auto-shut-off or a continuous-on mode for convenience.
- **Included Accessories:** Comes with a Universal Steam Cord Holder, an anti-scale filter, and a protective soleplate for delicate fabrics.



Figure 1: The Laurastar Lift Xtra 1980 Steam Iron set up with an ironing board in a home environment.



Figure 2: Detailed view of the Laurastar Lift Xtra 1980 steam generator unit.

2. SETUP INSTRUCTIONS

Follow these steps for the initial setup of your Laurastar Lift Xtra 1980 Steam Iron.

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure all included accessories (anti-scale filter, steam cord holder, protective soleplate) are present.
2. **Position the Unit:** Place the steam generator on a stable, flat surface or its dedicated stand. Ensure adequate ventilation around the unit.
3. **Fill Water Tank:** Remove the water tank and fill it with tap water up to the maximum fill line. For optimal performance and longevity, use Laurastar's recommended water or demineralized water. Insert the anti-scale filter into the tank if not already installed.
4. **Connect Iron:** Ensure the iron is securely connected to the steam generator unit.
5. **Plug In:** Connect the power cord to a grounded electrical outlet.

6. **Initial Heating:** Press the power button. The unit will begin heating, indicated by a light. Wait for the light to stabilize, indicating the unit is ready for use. This typically takes a few minutes.



Figure 3: The Laurastar Lift Xtra 1980 steam iron with its steam cord holder and other accessories.

3. OPERATING INSTRUCTIONS

The Laurastar Lift Xtra 1980 is designed for ease of use across various fabric types.

3.1 Power On/Off

- **To Power On:** Press the main power button located on the unit. The indicator light will illuminate and flash during heating. It will become steady when ready.
- **To Power Off:** Press and hold the main power button for a few seconds until the unit shuts down. The unit also features a 10-minute auto-shut-off for safety, or it can be set to continuous-on mode by holding the steam button for 15 seconds.

3.2 Ironing and Steaming

- **Traditional Ironing:** Place the garment on an ironing board. Glide the iron over the fabric while pressing the steam button for continuous steam. The 3D soleplate ensures even heat distribution and prevents creases. No temperature adjustment is needed for different fabrics.
- **Vertical Steaming:** Hang the garment on a hanger. Hold the iron a few centimeters away from the fabric and press the steam button. Move the iron downwards along the fabric to remove wrinkles. This method is ideal for delicate items, suits, and curtains.
- **DMS Purification:** The Dry Microfine Steam (DMS) purifies fabrics by eliminating microorganisms. Use the steam function as described above to benefit from this feature.

- **Protective Soleplate:** For very delicate fabrics, attach the included protective soleplate to the iron. This reduces direct heat contact and prevents shine marks.



Figure 4: A user demonstrating vertical steaming of a jacket.



Figure 5: Detailed view of the iron's 3D soleplate.





Figure 6: A user steaming curtains with the Laurastar Lift Xtra 1980.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Laurastar Lift Xtra 1980.

4.1 Anti-Scale Filter Replacement

The anti-scale filter helps prevent mineral buildup. Replace the filter when indicated by the unit or approximately every 3 months, depending on water hardness and usage frequency.

1. Ensure the unit is unplugged and cooled down.
2. Remove the water tank.
3. Remove the old anti-scale filter and dispose of it.
4. Insert a new Laurastar anti-scale filter into the water tank.

5. Refill the tank with water and reinsert it into the unit.

4.2 Cleaning the Iron Soleplate

If the soleplate becomes dirty, clean it gently when the iron is cool.

- Use a damp cloth and a mild, non-abrasive cleaner.
- Wipe the soleplate clean, then dry thoroughly with a clean cloth.
- Do not use abrasive pads or harsh chemicals, as these can damage the soleplate.

4.3 Storing the Unit

When not in use, ensure the unit is unplugged and cooled. Wrap the steam cord around the designated storage area on the unit. Store in a dry, safe place.



Figure 7: The Laurastar Lift Xtra 1980 stored on its portable stand.

5. TROUBLESHOOTING

If you encounter issues with your Laurastar Lift Xtra 1980, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No steam or insufficient steam	Water tank empty; unit not heated; anti-scale filter clogged; steam button not pressed.	Refill water tank; wait for indicator light to stabilize; replace anti-scale filter; ensure steam button is pressed firmly.
Iron not heating up	Unit not plugged in; power button not pressed; internal fault.	Check power connection; ensure power button is pressed; if problem persists, contact customer support.
Water leaking from iron	Iron not hot enough; steam button pressed too frequently without sufficient heat; condensation.	Allow unit to fully heat up before use; avoid excessive pressing of the steam button; ensure iron is held horizontally when not steaming.
Unit automatically shuts off	10-minute auto-shut-off activated.	This is a safety feature. To continue use, press the power button to restart. For continuous operation, hold the steam button for 15 seconds to activate continuous-on mode.

If you experience any issues not listed here or if the suggested solutions do not resolve the problem, please contact Laurastar customer support for assistance.

6. SPECIFICATIONS

Brand	Laurastar
Model Name	Lift Xtra 1980
Model Number	000.0636.545
UPC / GTIN	790776022923
Wattage	1800 watts
Frequency	50 Hz
Color	Gold
Base Material	Exclusive 3D soleplate
Special Features	Auto Shutoff, Travel-ready
Recommended Uses	Steam Iron

7. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the official Laurastar website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Laurastar Official Website: www.laurastar.com

Contact details for customer support can typically be found on the Laurastar website or within the product packaging.

© 2024 Laurastar. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question