

## BEPER P102GEL100

# BEPER P102GEL100 Electric Ice Crusher User Manual

Model: P102GEL100

Brand: BEPER

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance and keep them for future reference. Incorrect use can lead to electric shock, fire, or serious injury.

- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not immerse the motor unit in water or any other liquid.
- Keep hands and utensils out of the ice basket while operating to prevent injury and damage to the appliance.
- Ensure all components are correctly assembled and the safety lid is securely in place before operation. The appliance will not operate if components are not properly positioned.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Use only ice cubes. Do not use frozen fruit or other hard items, as this may damage the blades and motor.
- Do not overfill the ice basket beyond the MAX level indicated.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

## 2. PRODUCT OVERVIEW

The BEPER P102GEL100 Electric Ice Crusher is designed for quickly preparing crushed ice for granitas, cocktails, and sorbets. It features durable stainless steel blades and a safety locking system.



Figure 2.1: Assembled BEPER P102GEL100 Electric Ice Crusher.

### Components:



Figure 2.2: Disassembled components of the ice crusher.

- **Motor Unit/Base:** The main body containing the motor and power connection.
- **Ice Basket:** The transparent container where ice cubes are placed for crushing. It has a MAX fill line.
- **Stainless Steel Blades:** Located within the ice basket, responsible for crushing the ice.
- **Lid with Safety System:** The top cover that activates the motor when correctly positioned and turned.
- **Collection Tray:** Integrated into the base to catch any drips or spills.

### 3. SETUP

Before first use, ensure all packaging materials are removed and clean all removable parts according to the "Maintenance and Cleaning" section.

1. Place the motor unit/base on a stable, flat, and dry surface.
2. Insert the transparent ice basket onto the motor unit, ensuring it is seated correctly.
3. Prepare your ice cubes. For best results, use standard ice cubes.
4. Place a glass or container directly under the ice dispensing spout on the base to collect the crushed ice.

## 4. OPERATING INSTRUCTIONS

Follow these steps to operate your BEPER P102GEL100 Electric Ice Crusher:

1. Ensure the appliance is unplugged before adding ice.
2. Insert ice cubes into the ice basket. **Do not fill beyond the MAX level indicated on the basket.** Overfilling can cause the machine to jam or operate inefficiently.
3. Place the lid onto the ice basket. Align the flap on the lid with the corresponding seat on the main unit.
4. Plug the appliance into a suitable power outlet.
5. To start crushing, turn the lid counter-clockwise. The flap on the lid will engage with the body of the machine, activating the motor and starting the rotation of the blades.
6. **Important:** The lid must be held down firmly with your hand during operation to maintain contact and ensure continuous crushing.
7. The crushed ice will fall directly into the glass or container placed underneath.
8. To stop crushing, turn the lid clockwise. This will disengage the flap from the machine body and stop the motor.
9. Unplug the appliance from the power outlet once you have finished.



Figure 4.1: Crushed ice being dispensed into a glass.





Figure 4.2: Examples of beverages made with crushed ice.

## 5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your ice crusher. Always unplug the appliance before cleaning.

1. **Disassembly:** Turn the lid clockwise to unlock it and remove it from the ice basket. Carefully lift the ice basket from the motor unit.
2. **Cleaning Removable Parts:** The lid, ice basket, and collection tray are easily detachable. Wash these parts with warm, soapy water. Rinse thoroughly and dry completely before reassembling or storing.
3. **Cleaning Motor Unit:** Wipe the motor unit and base with a damp cloth. Do not immerse the motor unit in water or any other liquid.
4. **Blades:** Exercise extreme caution when cleaning the blades as they are sharp. Use a brush if necessary to remove any ice residue.
5. **Drying:** Ensure all parts are completely dry before storing the appliance to prevent mold or mildew.
6. **Storage:** Store the appliance in a cool, dry place, away from direct sunlight and out of reach of children.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Lid not properly engaged. Power outage.	Ensure the power cord is securely plugged into a working outlet. Ensure the lid is correctly aligned and turned counter-clockwise to engage the safety mechanism. Check your household's power supply.
Ice is not crushing or blades are stuck.	Ice basket overfilled. Ice cubes are too large or frozen together. Foreign object in the basket.	Unplug, remove excess ice, and try again. Do not exceed the MAX fill line. Use smaller, individual ice cubes. Break apart any clumped ice. Unplug and carefully inspect the basket for any obstructions.
Crushed ice consistency is too coarse.	Insufficient crushing time. Type of ice used.	Continue crushing for a longer duration while holding the lid down. Ensure ice cubes are not too large. Smaller ice cubes generally yield finer results.

## 7. SPECIFICATIONS

- **Model:** P102GEL100
- **Brand:** BEPER
- **Dimensions (L x W x H):** 23 x 16 x 28 cm
- **Weight:** 1.18 Kilograms
- **Power:** 30 Watts
- **Voltage:** 230 Volts
- **Material:** Alloy Steel (Blades)
- **Included Components:** Ice crusher unit (bowl not included)

## 8. WARRANTY AND SUPPORT

This BEPER appliance comes with a standard manufacturer's warranty. Please refer to the warranty





card included in your product packaging for specific terms and conditions, including warranty period and coverage details.



For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact BEPER customer service. Contact information can typically be found on the BEPER official website or on the product packaging.

When contacting support, please have your product model number (P102GEL100) and purchase date available.

© 2025 BEPER. All rights reserved.

## Related Documents - P102GEL100

	<p><a href="#">Beper P102GEL100 Ice Shaver User Manual and Instructions</a></p> <p>Comprehensive user manual for the Beper P102GEL100 Ice Shaver, providing detailed instructions for use, safety precautions, cleaning, and technical specifications.</p>
	<p><a href="#">Beper BP.690 Drink Mixer User Manual and Instructions</a></p> <p>Official user manual and instructions for the Beper BP.690 Drink Mixer. Learn about safety warnings, product features, usage, cleaning, technical specifications, and warranty information.</p>
	<p><a href="#">Beper P203TER350 Pocket Heater - Manuale di istruzioni</a></p> <p>Manuale di istruzioni completo per il riscaldatore tascabile Beper P203TER350. Include informazioni su sicurezza, funzionamento, manutenzione e garanzia per un uso ottimale.</p>
	<p><a href="#">Beper P302MAS001: Manuale d'uso del Massaggiatore a Percussione Ricaricabile</a></p> <p>Guida completa per il massaggiatore a percussione ricaricabile Beper P302MAS001. Scopri come utilizzare in sicurezza ed efficacia questo dispositivo per il sollievo muscolare e il recupero.</p>

	<p><a href="#">Beper 23008 Stick Waffle Maker - User Manual and Safety Guide</a></p> <p>Comprehensive guide for the Beper 23008 stick waffle maker, including safety precautions, operating instructions, cleaning, maintenance, and warranty details.</p>
	<p><a href="#">Manuale di istruzioni Beper P101FRI012: Friggitrice ad Aria Calda Digitale Multifunzione</a></p> <p>Guida completa all'uso della friggitrice ad aria digitale multifunzione Beper P101FRI012. Include istruzioni di sicurezza, funzionamento, accessori e risoluzione dei problemi.</p>