

Manuals.plus /

› Braun /

› Braun Charging Stand User Manual for Beard Trimmer Types 5542, 5544

Braun BR-81695627

Braun Charging Stand User Manual

For Beard Trimmer Types 5542, 5544

INTRODUCTION

This manual provides comprehensive instructions for the Braun Charging Stand, designed for use with specific Braun Beard Trimmer models. Please read this manual thoroughly before initial use to ensure proper setup and operation. This charging stand is compatible with Braun Beard Trimmer types 5542 and 5544, including models MGK 5080, MGK 5280, MGK 7020, MGK 7021, MGK 7220, MGK 7221, MGK 7320, MGK 7321, MGK 7330, MGK 7331, MGK 7920, MGK 7921, MGK 7, BG 5340, and BG 5350.

PACKAGE CONTENTS

- 1 x Braun Charging Stand

Note: This product does not include a power cord. It is designed for use with your existing Braun trimmer power cord.

SETUP

1. **Connect Power Cord:** Locate the power cord that came with your Braun beard trimmer. Insert the small end of the power cord into the designated port on the back or bottom of the charging stand.
2. **Plug into Outlet:** Plug the larger end of the power cord into a standard electrical outlet.
3. **Place Trimmer:** Carefully place your compatible Braun beard trimmer onto the charging stand. Ensure the trimmer's charging contacts align with the pins on the stand. The trimmer should sit securely in the stand.



Image: The Braun Charging Stand, a circular black base with a central two-pin connector for the trimmer.

OPERATING INSTRUCTIONS

Once the charging stand is set up and connected to power, simply place your Braun beard trimmer onto the stand. The trimmer will begin charging automatically. Refer to your trimmer's instruction manual for specific charging indicators (e.g., LED lights) and recommended charging times.

- Ensure the trimmer is dry before placing it on the charging stand.
- Do not force the trimmer onto the stand; it should fit easily.
- Always use the original power cord supplied with your Braun trimmer.

MAINTENANCE

To ensure the longevity and proper function of your Braun Charging Stand, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the charging stand from the power outlet before cleaning. Wipe the stand with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the charging stand in a dry environment when not in use.
- **Inspection:** Periodically inspect the charging pins for any debris or damage.

TROUBLESHOOTING

If your trimmer is not charging when placed on the stand, consider the following:

- **Power Connection:** Ensure the power cord is securely connected to both the charging stand and the electrical outlet.
- **Outlet Functionality:** Test the electrical outlet with another device to confirm it is working.
- **Trimmer Placement:** Verify that the trimmer is correctly seated on the stand and that its charging contacts align with the stand's pins.
- **Compatibility:** Confirm that your trimmer model is listed as compatible with this charging stand.
- **Power Cord:** Ensure you are using the original power cord that came with your Braun trimmer.

If issues persist, consult the instruction manual for your specific Braun beard trimmer or contact Braun customer

support.

SPECIFICATIONS

Brand	Braun
Model Number	BR-81695627
Compatible Trimmer Types	5542, 5544
Compatible Trimmer Models	MGK 5080, MGK 5280, MGK 7020, MGK 7021, MGK 7220, MGK 7221, MGK 7320, MGK 7321, MGK 7330, MGK 7331, MGK 7920, MGK 7921, MGK 7, BG 5340, BG 5350
Connector Type	3-pin
Item Weight	1.13 ounces (0.03 Kilograms)
Package Dimensions	3.19 x 2.32 x 1.85 inches
Power Source	Corded Electric (requires existing power cord)
Wattage	10 watts
Frequency Range	50 Hz

WARRANTY INFORMATION

Specific warranty details for this Braun Charging Stand may vary by region and retailer. Please refer to the warranty information provided with your original Braun trimmer or visit the official Braun website for current warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, product inquiries, or technical support, please visit the official Braun website or contact their customer service department. Contact information can typically be found on the Braun website or in the documentation included with your Braun trimmer.

You can also visit the Braun Store on Amazon for more product information.