

GEEZER Cat001

GEEZER 2.4GHz Wireless Keyboard and Mouse Combo (Model Cat001) User Manual

1. INTRODUCTION

Thank you for choosing the GEEZER 2.4GHz Wireless Keyboard and Mouse Combo. This product is designed to provide a comfortable and efficient typing and navigation experience with its retro-inspired design and wireless convenience. This manual will guide you through the setup, operation, and maintenance of your new device.

2. PRODUCT OVERVIEW

The GEEZER Wireless Keyboard and Mouse Combo features a unique design with detachable keycaps and a quiet mouse, offering broad compatibility with various operating systems.

2.1 Components

- Wireless Keyboard
- Wireless Mouse
- 2-in-1 Nano USB Receiver
- AA & AAA Batteries (pre-installed or included)
- Cleaning Brush

2.2 Key Features

- **2.4GHz Wireless Technology:** Provides a stable connection with a working range of up to 35 feet.
- **Retro Round & Detachable Keycaps:** Easy to clean and offers a unique typing feel.
- **Quiet Operation:** Bottom sealing film technology for the keyboard and silent mouse clicks.
- **Ergonomic Design:** Inclination angle for comfortable typing and reduced wrist pressure.
- **Long Battery Life:** Automatic sleep mode extends battery life up to 12 months.
- **Wide Compatibility:** Compatible with Windows 10/8/7/XP/Vista, PC, Mac, Desktop, Laptop, Notebook, Chrome-Book, Smart TVs, and more.



Image 2.1: The GEEZER 2.4GHz Wireless Keyboard and Mouse Combo in Pink, showcasing its design and included USB receiver.

84 KEYS 2.4G WIRELESS COMPACT KEYBOARD MOUSE COMBO

2 in 1 USB nano receiver, plug and play

- Cute Cat Model
- 2.4GHz Wireless technology
- 1Mbps High-speed transmission
- 10M transmission distance
- 1200 DPI
- Suspension retro round keycap
- III levels Smart stay

Image 2.2: Detailed view of the keyboard and mouse highlighting the cat-themed design, including paw prints, cat ears, and whiskers.

3. SETUP INSTRUCTIONS

Follow these steps to set up your GEEZER Wireless Keyboard and Mouse Combo:

1. Install Batteries:

- Locate the battery compartments on the underside of both the keyboard and the mouse.
- Insert the provided AA battery into the keyboard and AAA batteries into the mouse, ensuring correct polarity.

2. Locate USB Receiver: The 2-in-1 Nano USB receiver is typically stored in a compartment on the underside of the mouse for safekeeping. Gently remove it.

3. Connect Receiver: Plug the Nano USB receiver into an available USB 2.0 port on your computer, PC, laptop, or compatible device.

4. Power On Devices: Turn on the keyboard and mouse using their respective ON/OFF switches, usually located on the underside.

5. Automatic Connection: The keyboard and mouse should automatically connect to your device. No additional software or drivers are typically required for basic functionality.



Image 3.1: Illustration of the 2-in-1 Nano USB receiver being plugged into a laptop, enabling wireless connection for both keyboard and mouse.

4. OPERATING INSTRUCTIONS

4.1 Keyboard Usage

- **Typing:** The keyboard features a standard QWERTY layout with 84 keys. The retro round keycaps provide a distinct tactile experience.
- **Multimedia Hotkeys:** Use the function (Fn) key in combination with the F1-F12 keys for multimedia controls such as volume, playback, and web browser shortcuts. Refer to the keycap legends for specific functions.



Image 4.1: The keyboard layout, indicating the location and function of the 13 multimedia hotkeys (F1-F12 and Esc).

4.2 Mouse Usage

- **Navigation:** The mouse provides precise and quiet cursor control.
- **Buttons:** Standard left-click, right-click, and scroll wheel functionality.

4.3 Power Saving Mode

Both the keyboard and mouse are equipped with an automatic sleep function. If idle for approximately 5 minutes, they will enter sleep mode to conserve battery. To wake them up, simply click any button on either device.

5. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your wireless combo.

- **Cleaning Keycaps:** The individual keycaps are detachable. You can carefully remove them for thorough cleaning. They can be washed with water. Use the provided brush to remove dust and debris from between the keys. Ensure keycaps are completely dry before reattaching.
- **General Cleaning:** Wipe the surfaces of the keyboard and mouse with a soft, damp cloth. Avoid using

harsh chemicals or abrasive materials.

- **Battery Replacement:** When performance degrades, replace the batteries. The keyboard uses one AA battery, and the mouse uses two AAA batteries.
- **Storage:** When not in use for extended periods, turn off both devices using their ON/OFF switches to further conserve battery life. Store the USB receiver in the mouse's compartment.



Image 5.1: Illustration demonstrating the detachable nature of the keycaps, allowing for easy cleaning and maintenance.

6. TROUBLESHOOTING

If you encounter issues with your GEEZER Wireless Keyboard and Mouse Combo, refer to the following common solutions:

Problem	Possible Solution
Keyboard/Mouse not responding	Ensure both devices are turned ON. Check battery levels and replace if necessary. Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port. Move the devices closer to the USB receiver to rule out range issues. Restart your computer.
Mouse disconnects intermittently	This may be the auto-sleep function. Click any button to wake it up. Check battery levels. Ensure no strong wireless interference (e.g., other 2.4GHz devices) is nearby.
Keys are sticky or unresponsive	Clean the keycaps and the area beneath them using the provided brush or by detaching and washing the keycaps. Ensure no debris is lodged under the keys.

7. SPECIFICATIONS

Feature	Detail
Model Number	Cat001
Connectivity	2.4GHz Wireless (USB Receiver)
Keyboard Dimensions	13.54 x 5.91 x 1.06 inches
Item Weight	1.1 pounds (Keyboard & Mouse combined)
Keyboard Battery	1 x AA battery (included)
Mouse Battery	2 x AAA batteries (included)
Compatible Devices	Windows 10/8/7/XP/Vista, Android, Linux, iMac, PC, Desktop, Laptop, Notebook, Chrome-Book, Smart TVs
Special Feature	Ergonomic Design, Detachable Keycaps

84 KEYS COMPACT WIRELESS KEYBOARD



Image 7.1: Technical diagram illustrating the dimensions of the GEEZER wireless keyboard and mouse.

8. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact GEEZER customer support. If you require further assistance or have questions not covered in this manual, please reach out to the seller or manufacturer's support channels.