

Edifier s3

Edifier STAX Spirit S3 Wireless Planar Magnetic Headphone User Manual

Model: s3 | Brand: Edifier

PRODUCT OVERVIEW

The Edifier STAX Spirit S3 is a flagship wireless planar magnetic headphone designed for audiophiles, offering stunning Hi-Res audio performance. It integrates advanced audio engineering with premium components to deliver a pure, detailed sound experience.

Key features include:

- Wireless & Wired Hi-Res Audio Support: Experience audio quality up to 24bit/96kHz.
- Planar Magnetic Drivers: Provides cleaner sound, greater resolution, and improved imaging compared to traditional dynamic drivers.
- Snapdragon Sound Technology: Ensures lossless audio experience with all details preserved.
- Clear Call Functionality: Qualcomm QCC5141 solution for ultra-low latency and clear voice quality.
- All-Day Comfort: Lightweight design with carbon-fiber materials, foldable hinges, and genuine lamb leather earpads. Includes an additional set of cooling-mesh earpads.
- Extended Playtime: Up to 80 hours of music playback, with 11 hours from a 10-minute charge.
- Edifier Connect App: Access classic STAX sound effects, low-latency game modes, and additional EQ options.



Figure 1: Edifier STAX Spirit S3 Wireless Planar Magnetic Headphone.

WHAT'S IN THE BOX

Upon unboxing your Edifier STAX Spirit S3 headphones, you should find the following items:

- Edifier STAX Spirit S3 Headphones
- Protective Case
- Audio Cable (3.5mm Jack)
- USB Charging Cable
- Additional Cooling-Mesh Earpads
- User Manual (this document)




Figure 2: The Edifier STAX Spirit S3 headphones shown with both the standard lambskin leather earpads and the included cooling-mesh

earpads, highlighting the comfort options.

SETUP

Charging the Headphones

Before initial use, fully charge your Edifier STAX Spirit S3 headphones. Connect the provided USB charging cable to the headphone's charging port and a compatible USB power source. The LED indicator will show charging status and turn off when fully charged. A full charge takes approximately 1.5 hours and provides up to 80 hours of playback time. A quick 10-minute charge can provide 11 hours of playback.




Figure 3: Visual representation of the impressive battery life and fast charging capability of the STAX Spirit S3 headphones.

Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the power button for approximately 3-5 seconds until the LED indicator flashes rapidly, indicating pairing mode.
3. On your device (smartphone, laptop, etc.), enable Bluetooth and search for available devices.
4. Select "EDIFIER STAX SPIRIT S3" from the list of found devices.
5. Once connected, the LED indicator will stop flashing and remain solid.

The headphones can connect to two different devices simultaneously, allowing for seamless switching between music, games, or phone calls.




Figure 4: The Edifier STAX Spirit S3 headphones demonstrating multi-device Bluetooth connectivity, allowing easy switching between a laptop and a smartphone.

Wired Connection

For a wired connection, use the provided 3.5mm audio cable. Plug one end into the headphone's audio jack and the other end into your audio source's 3.5mm output.

OPERATING INSTRUCTIONS

Controls

The Edifier STAX Spirit S3 headphones feature intuitive controls located on the earcups:

- **Power Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls.
- **Volume Up/Down:** Adjust audio volume.
- **Multi-function Button:** (Specific functions may vary, refer to app for customization) Typically used for track skipping, voice assistant activation, or mode switching.

Edifier Connect App

Enhance your listening experience by downloading the Edifier Connect App from your device's app store. The app allows you to:

- Access classic STAX sound effects.
- Activate low-latency game modes.
- Customize EQ settings.
- Update firmware.

- View battery status.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Edifier STAX Spirit S3 headphones, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the headphones in their protective case to prevent damage. Avoid exposing them to extreme temperatures or humidity.
- **Earpad Replacement:** The earpads are designed for easy replacement. Gently twist and pull to remove the existing earpads, then align and press the new earpads into place until they click securely.
- **Water Resistance:** These headphones are not water resistant. Avoid exposure to water or excessive moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; interference.	Ensure headphones are in pairing mode (flashing LED). Turn device Bluetooth off and on. Move closer to the device. Clear previous pairings on both devices.
No sound or low volume.	Volume too low; incorrect audio source; loose cable (wired).	Increase volume on headphones and device. Check audio source selection. Ensure audio cable is securely connected.
Poor call quality.	Environmental noise; microphone obstruction.	Move to a quieter environment. Ensure microphone is not covered.

If you continue to experience issues, please refer to the Edifier support website or contact customer service.

SPECIFICATIONS

Feature	Detail
Model Name	edifier-s3-black
Connectivity Technology	Wired, Bluetooth
Wireless Communication Technology	Bluetooth 5.2
Audio Driver Type	Planar Magnetic Driver
Audio Driver Size	89 Millimeters
Frequency Range	20Hz~40KHz
Charging Time	1.5 Hours

Feature	Detail
---------	--------

Playtime	Up to 80 hours
Material	Carbon Fiber, Lamb Leather, Mesh
Item Weight	2.9 pounds
Product Dimensions	12.44 x 10.79 x 6.73 inches
Control Method	App
Included Components	Protective Case

WARRANTY AND SUPPORT

Edifier products are designed and manufactured to the highest quality standards. For detailed warranty information specific to your region and product, please visit the official Edifier website or contact their customer support. For technical assistance, troubleshooting, or service inquiries, please reach out to Edifier customer support through their official channels. Keep your proof of purchase for warranty claims.

Official Edifier Store: [Visit the Edifier Store on Amazon](#)