

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PERFASCIN](#) /

› [PERFASCIN Replacement Voice Remote Control for Realme TV Stick and Smart TVs User Manual](#)

## PERFASCIN ANG-RELME-NYP-MIC-US

# PERFASCIN Replacement Voice Remote Control

MODEL: ANG-RELME-NYP-MIC-US

## Introduction

This manual provides comprehensive instructions for the PERFASCIN Replacement Voice Remote Control. This remote is designed to function as a direct replacement for various Realme TV Stick and Smart TV models, offering voice control and dedicated app access. Please read this manual carefully before use to ensure proper setup and operation.

### Compatible Models:

- Realme TV Stick
- Realme TV Stick 4K RMV2105
- Realme Smart TV 32 RMV2101 RMV2004
- Realme SLED RMV2001
- Realme Smart TV SLED 4K
- Realme Smart TV 4K
- Realme Smart TV Full HD RMV2003
- Realme Smart TV Neo
- Realme 4K Smart Google TV Stick Global Version
- Realme 4K Smart TV Stick

## Setup

### 1. Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Back of the remote control with the battery compartment open, illustrating the correct orientation for AAA battery insertion.

## 2. Pairing the Remote Control

This remote control requires pairing with your Realme TV Stick or Smart TV before use. The pairing process may vary slightly depending on your specific TV model. Generally, follow these steps:

1. Ensure your Realme TV Stick or Smart TV is powered on.
2. Navigate to the **Settings** menu on your TV using your existing remote or the physical buttons on the TV.
3. Look for options such as **Remotes & Accessories**, **Bluetooth Settings**, or **Add Device**.
4. Select the option to add a new device or pair a new remote control.
5. On the PERFASCIN remote, press and hold the **Back** button and the **Home** button simultaneously for a few seconds until an indicator light on the remote (if present) flashes or a pairing message appears on your TV screen.
6. Once the remote appears in the list of available devices on your TV, select it to complete the pairing process.
7. A confirmation message should appear on your TV screen once pairing is successful.

*Note: If you encounter difficulties, refer to your Realme TV's user manual for specific pairing instructions.*

## Operating the Remote Control

The PERFASCIN remote control features several buttons for navigating your Realme TV Stick or Smart TV. Below is a description of the primary functions:





Image: Front view of the remote control, highlighting the layout of all functional buttons.

- **Power Button (○):** Turns the TV on or off.
- **Mute Button (⊞):** Mutes or unmutes the TV audio.
- **Voice Assistant Button (Google Assistant logo):** Activates the voice assistant for commands and searches.
- **Navigation Ring and OK Button:** Use the ring to navigate menus (Up, Down, Left, Right) and the center button to confirm selections.
- **Back Button (↶):** Returns to the previous screen or menu.

- **Home Button** (⏪): Returns to the main home screen of your TV.
- **Menu Button** (≡): Opens context-sensitive menus or settings.
- **Volume Up/Down Buttons** (+ / -): Adjusts the TV volume.
- **Dedicated App Buttons (Netflix, YouTube, Prime Video)**: Provides direct access to these streaming applications.

## Maintenance

### Battery Replacement

Replace batteries when the remote's performance degrades or it stops responding. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

### Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the remote's surface or internal components.

## Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
  - Ensure there are no obstructions between the remote and the TV.
  - Re-pair the remote control with your TV (refer to the "Pairing the Remote Control" section).
- **Voice control not working:**
  - Ensure the remote is properly paired and within range of the TV.
  - Check your TV's internet connection, as voice commands often require online processing.
  - Verify that the voice assistant feature is enabled in your TV's settings.
- **App buttons not launching:**
  - Confirm that the respective applications (Netflix, YouTube, Prime Video) are installed and updated on your TV.
  - Ensure your TV has an active internet connection.

## Specifications

- **Model Number:** ANG-RELME-NYP-MIC-US
- **Product Dimensions:** 7 x 2 x 0.65 inches (approximately)
- **Item Weight:** 2.3 ounces (without batteries)
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Compatible Devices:** Realme TV Stick, Realme Smart TV models
- **Special Feature:** Ergonomic design, Voice Control

## Warranty and Support

For any questions, technical support, or warranty inquiries regarding your PERFASCIN Replacement Voice Remote Control, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific contact information.

