

E-YIIVIII 58-000219

E-YIIVIII Replacement Battery 58-000219 User Manual

For Fire HD 8 7th Gen SX034QT

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your E-YIIVIII replacement battery, model 58-000219. This battery is specifically designed for compatibility with the Fire HD 8 7th Gen (model SX034QT).

Please read this manual thoroughly before attempting installation or use to ensure proper function and safety.

2. IMPORTANT SAFETY INFORMATION

- **Danger of Explosion:** Incorrect replacement of the battery carries a risk of explosion. Replace only with the same or equivalent type recommended by the manufacturer.
- **Professional Installation Recommended:** This product requires professional installation technology. The manufacturer is not responsible for any damage due to improper operation during installation.
- **Charger Compatibility:** Do not use low-quality third-party adapter chargers, as this can shorten the battery's lifespan and pose safety risks.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of in fire or directly short circuit.

3. PACKAGE CONTENTS

Verify that your package contains the following items:

- 1 x E-YIIVIII Replacement Battery (Part No: 58-000219)
- 1 x Repair Tool Kit

4. SETUP AND INSTALLATION

This replacement battery is intended for the Fire HD 8 7th Gen (SX034QT). Please confirm your device model before proceeding.

Note: This product does not include detailed installation instructions. Professional installation is strongly recommended due to the delicate nature of tablet components. The manufacturer is not liable for damages resulting from improper installation.

If you choose to proceed with self-installation, consider consulting online resources such as video tutorials for guidance. Search for videos specific to 'Fire HD 8 7th Gen battery replacement'.

Installation Steps (General Guidance):

1. Power off your device completely before beginning.
2. Carefully open your device using appropriate tools from the repair kit.
3. Gently disconnect the old battery's cable from the mainboard.
4. Remove the old battery.
5. Connect the new E-YIIVIL battery's cable properly to the mainboard. Ensure a secure connection.
6. Carefully reassemble your device.

Warning: All batteries are tested before shipping. If your device does not power on after installation, re-check the cable connection to ensure it is properly seated.

For Fire HD 8 7th Gen SX034QT






Image 2: Back view of the E-YIIVIII Replacement Battery 58-000219.

DETAIL



Image 3: Detailed view of the battery label, showing model number and specifications.

5. OPERATING AND INITIAL USE

- **First Use:** A new Li-ion battery will achieve its best performance after 2 or 3 complete charge and discharge cycles.
- **Charging:** Use only high-quality, compatible chargers. Avoid using low-quality third-party adapters, as they can negatively impact battery life and performance.
- **Proper Connection:** Always ensure the battery connector is properly and securely connected to your device's mainboard for optimal performance and safety.

6. MAINTENANCE

- **Temperature:** Avoid exposing the battery to extreme temperatures (very hot or very cold), as this can degrade performance and shorten its lifespan.
- **Storage:** If storing the device for an extended period, ensure the battery is charged to approximately 50% to

prevent deep discharge.

- **Cleaning:** Keep the battery and device free from dust and debris. Do not use liquid cleaners directly on the battery.

7. TROUBLESHOOTING

- **Device Not Powering On:** If your device does not power on after battery replacement, carefully re-open the device and ensure the battery cable is properly and securely connected to the mainboard. A loose connection is a common cause.
- **Battery Not Charging:** Verify that you are using a compatible and functional charger. Check the charging port for any obstructions or damage. Ensure the battery connection inside the device is secure.
- **Shortened Battery Life:** Ensure you are using a quality charger. Allow the battery to complete 2-3 full charge/discharge cycles to optimize performance. Avoid extreme temperatures.

8. SPECIFICATIONS

Part Number	58-000219, 26S1014
Capacity	4750mAh / 17.57Wh
Nominal Voltage	3.7V
Battery Type	Lithium Polymer
Compatibility	Fire HD 8 7th Gen (SX034QT)
Product Dimensions	7.87 x 1.97 x 1 inches
Item Weight	5.6 ounces
Manufacturer	Shenzhen DeRui Trading Limited Company

9. SUPPORT

For any questions or issues encountered while using this product, please contact us. We aim to respond to all inquiries within 24 hours.

While no explicit warranty period is stated, customer satisfaction is important. Please reach out if you experience any problems.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question