



Manuals.plus /

- › AMZASA /
- › AMZASA AS9009-5 5-Light Rectangular Kitchen Island Chandelier User Manual

AMZASA AS9009-5

AMZASA AS9009-5 5-Light Rectangular Kitchen Island Chandelier User Manual

Model: AS9009-5 | Brand: AMZASA

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your AMZASA AS9009-5 5-Light Rectangular Kitchen Island Chandelier. Please read this manual thoroughly before installation and retain it for future reference.



Image: The AMZASA AS9009-5 5-Light Rectangular Kitchen Island Chandelier, featuring a black metal frame and five exposed bulb sockets.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: Risk of Electric Shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.

- Read all instructions carefully before beginning installation.
- Consult a qualified electrician if you are not familiar with electrical wiring.
- Ensure the mounting surface can support the weight of the fixture.
- Use only the specified bulb type and wattage (E26 base, max 60W per bulb, bulbs not included).
- Do not connect this fixture to an ungrounded electrical system.

- Do not attempt to alter the fixture in any way.
- Keep flammable materials away from light bulbs.
- This fixture is intended for indoor use only.

WHAT'S IN THE BOX

Verify that all components are present before beginning installation:

- Light Fixture (Rectangular Frame with 5 Sockets)
- Mounting Canopy
- Chain (47.24 inches)
- Rods (8.7 inches, quantity as needed for hanging)
- Installation Hardware (screws, wire nuts, etc.)



Image: Detailed view of the chandelier's components, including the ceiling canopy, hanging chain, bulb socket, and the corner joint of the metal frame.

INSTALLATION INSTRUCTIONS

- 1. Turn Off Power:** Before starting, ensure the power supply to the installation area is completely turned off at the circuit breaker or fuse box.
- 2. Prepare the Fixture Frame:** The fixture frame may come in a loose pack. Secure the four rods (if provided separately) to form the rectangular frame.
- 3. Determine Hanging Height:** Adjust the length of the chain and rods to achieve your desired hanging height. The maximum height is 66.7 inches (including 8.7-inch rods and 47.24-inch chains).
- 4. Mount the Canopy:** Attach the mounting bracket to the junction box in the ceiling. Then, connect the rods and chains to the canopy.
- 5. Wire Connections:**
 - Connect the fixture's ground wire (usually bare copper or green) to the house ground wire.
 - Connect the fixture's hot wire (usually black) to the house hot wire (black).
 - Connect the fixture's neutral wire (usually white) to the house neutral wire (white).
 - Secure all connections with wire nuts and electrical tape.
- 6. Secure the Fixture:** Carefully lift the fixture and attach the canopy to the mounting bracket, securing it with the provided screws.
- 7. Install Bulbs:** Screw five E26 base bulbs (max 60W each, not included) into the sockets.
- 8. Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Image: Diagram illustrating the dimensions of the AMZASA AS9009-5 chandelier, including length (32.7"), width (8.7"), frame height (9.85"), and maximum hanging height (66.7").

OPERATING INSTRUCTIONS

The AMZASA AS9009-5 chandelier operates via a standard wall switch. Ensure appropriate E26 base bulbs are installed before operation.

- **Bulb Requirements:** This fixture requires five E26 base bulbs, with a maximum wattage of 60 watts per bulb. Bulbs are not included.
- **Power On/Off:** Use your existing wall switch to turn the chandelier on or off.
- **Dimming Capability:** If you wish to use dimmable bulbs, ensure they are compatible with your dimmer switch.



ON



OFF

Image: Comparison showing the AMZASA AS9009-5 chandelier with lights on and lights off, demonstrating its appearance in both states.

CARE AND MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

- **Cleaning:** Always disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, polishes, or solvents, as these may damage the finish.
- **Bulb Replacement:** Ensure the fixture is off and bulbs have cooled before replacing them. Screw in new E26 base bulbs carefully.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Defective bulb(s). Wall switch is off.	Check circuit breaker/fuse. Verify all wire connections are secure (power off first). Replace bulb(s). Ensure wall switch is in the "ON" position.
Flickering lights.	Loose bulb. Incompatible dimmer switch. Loose wire connection.	Tighten bulb(s). Ensure bulbs are dimmable and compatible with your dimmer. Check wire connections (power off first).

PRODUCT SPECIFICATIONS

Brand	AMZASA
Model Name	AS9009-5
ASIN	B0B2LMVDRG
Style	Modern Industrial Farmhouse Rectangular Linear Chandelier
Material	Iron
Color	Black
Product Dimensions (L x W x H)	32.7" x 8.7" x 66.7" (Max Height)
Frame Height	9.85"
Number of Lights	5
Bulb Base	E26
Max Wattage per Bulb	60 Watts
Voltage	110 Volts
Power Source	AC
Installation Type	Ceiling Mount
Indoor/Outdoor Usage	Indoor
Item Weight	9.2 Pounds
Certification	UL Listed

WARRANTY AND SUPPORT

AMZASA provides a **3-year product maintenance** period for this fixture. If you encounter any issues or have

questions regarding your AMZASA AS9009-5 chandelier, please contact our customer support.

Our online service is available 24 hours to assist you.

For support, please visit the AMZASA Store on Amazon or refer to your purchase documentation for direct contact information.

