

Lynnoland T3476

Lynnoland T3476 Touch Control Table Lamps User Manual

Model: T3476

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Lynnoland T3476 Touch Control Table Lamps. Please read this manual thoroughly before installation and operation, and retain it for future reference.



Image: Set of two Lynnoland T3476 Touch Control Table Lamps.

PACKAGE CONTENTS

- 2 x Lynnoland T3476 Table Lamp Bases (Beige & Wood)
- 2 x Fabric Lampshades (Beige)
- 2 x E26 LED Bulbs (2700K Warm Light, 800 Lumens)
- User Manual

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the "Package Contents" section are present.
2. **Assemble Lampshade:** The fabric lampshade is designed for easy assembly. Follow the instructions provided with the lampshade to secure it to the lamp harp.
3. **Install Bulb:** Screw the provided E26 LED bulb into the lamp socket until secure. Do not overtighten.
4. **Connect Power:** Plug the lamp's power cord into a standard 120V AC electrical outlet.



The image compares two table lamps. On the left is the 'Perfect lamp' (17.5in), which has a beige fabric shade with a 7-inch diameter and a 150-degree light range. On the right is the 'Mini lamp' (15.2in), which has a white fabric shade with a 4-inch diameter and a 45-degree light range. A 'Vs' logo is placed between the two lamps. A 'Like Us!' badge is in the top left corner.

40" Wide illumination area	10" Narrow illumination area
♥ Perfect lamp (17.5in)	♥ Mini lamp (15.2in)
♥ Increase light range up to 150°	♥ Light range: 45°
♥ Touch control & 3-way dimmable	♥ Pull chain & non-dimmable
♥ \$12 , 800 LM dimmable bulb	♥ Bulb not included
♥ Pre-assembled shade	♥ Non-assembled shade

Image: Lamp dimensions and illumination area.

OPERATING INSTRUCTIONS

Touch Control and Dimming:

The Lynnoland T3476 lamp features a 3-way dimmable touch control system. To operate:

- **First Touch:** Activates the low brightness setting (25%).
- **Second Touch:** Switches to medium brightness (60%).
- **Third Touch:** Switches to high brightness (100%).
- **Fourth Touch:** Turns the lamp off.

You can touch any metal part of the lamp base or stem to cycle through the brightness settings and turn the lamp on/off.

USB and AC Outlets:

The lamp base is equipped with 2 USB charging ports (USB-A and USB-C) and 1 AC outlet (120V). These outlets function independently of the lamp's light, allowing you to charge devices even when the lamp is off.

- Connect your electronic devices to the USB ports or AC outlet for convenient charging.
- Ensure devices are compatible with the provided voltage and current.



Image: Lamp base with USB and AC outlets.

Official Product Video:

Your browser does not support the video tag.

Video: Demonstration of the Lynnoland T3476 table lamp's touch control and wide illumination.

MAINTENANCE

- **Cleaning:** Disconnect the lamp from the power outlet before cleaning. Use a soft, dry cloth to wipe the lamp base and shade. Avoid using abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled before attempting to replace it. Use only E26 base LED bulbs with a maximum wattage of 60W (or equivalent LED).
- **Shade Care:** The fabric shade can be gently dusted with a soft brush or vacuumed with a low-power setting.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose bulb, faulty bulb.	Check power connection. Ensure bulb is screwed in tightly. Replace bulb if necessary.
Touch control is unresponsive.	Loose connection, electrical interference.	Ensure all connections are secure. Try plugging the lamp into a different outlet. Avoid placing near other electronic devices that may cause interference.
USB/AC outlets not working.	No power, device incompatibility.	Check power connection. Ensure device is properly connected and compatible with the outlet specifications.

SPECIFICATIONS

Feature	Detail
Brand	Lynnoland
Model Number	T3476
Dimensions (each)	6.89"D x 6.89"W x 17.32"H
Item Weight (each)	4 Pounds
Base Material	Wood
Shade Material	Fabric (Beige)
Switch Type	Touch Control
Dimmable	3-Way (Low, Medium, High)
Light Source Type	LED
Bulb Base	E26
Included Bulb Color Temperature	2700K Warm Light
Included Bulb Brightness	800 Lumens
USB Ports	2 (USB-A, USB-C)
AC Outlet	1 (120V)
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor Only

SAFETY INFORMATION

- Always unplug the lamp before cleaning or replacing the bulb.
- Do not use the lamp in wet or damp locations.

- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Do not exceed the maximum wattage for the bulb (60W equivalent LED).
- Keep out of reach of children and pets.
- If any part of the lamp is damaged, discontinue use and contact customer support.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Lynnloland customer service directly. Refer to your purchase documentation for specific warranty terms and contact details.

Lynnloland is committed to providing quality products and support. For further assistance, please visit the [Lynnloland Store on Amazon](#).