

## Shark HD101

# Shark HyperAIR HD101 Fast-Drying Hair Blow Dryer

## USER MANUAL

### Important Safety Instructions

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER** – As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:
  - Always unplug this appliance immediately after using.
  - Do not use while bathing or in a shower.
  - Do not place or store appliance where it can fall or be pulled into a tub or sink.
  - Do not place in or drop into water or other liquid.
  - If an appliance falls into water, unplug it immediately. Do not reach into the water.
- **WARNING** – To reduce the risk of burns, electrocution, fire, or injury to persons:
  - An appliance should never be left unattended when plugged in.
  - Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
  - Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
  - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water.
  - Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
  - Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
  - Never use while sleeping.
  - Never drop or insert any object into any opening.
  - Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being

administered.

- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.

## What's in the Box

---

Your Shark HyperAIR HD101 package includes the following components:

- Shark HyperAIR HD101 Hair Blow Dryer Unit
- IQ Styling Concentrator Attachment
- Diffuser Attachment



Image: The Shark HyperAIR HD101 hair blow dryer shown with its two primary attachments, the IQ Styling Concentrator and the Diffuser. The main unit is silver, and the attachments are black.

## Setup

---

1. **Unpack the Unit:** Carefully remove all components from the packaging. Retain packaging materials for future storage or transport.
2. **Attach Styling Accessories:**
  - To attach the IQ Styling Concentrator or Diffuser, align the attachment with the nozzle of the hair dryer.
  - Push the attachment firmly onto the nozzle until it clicks into place. The magnetic connection ensures a secure fit.

- To remove, simply pull the attachment away from the nozzle.
3. **Connect to Power:** Plug the power cord into a standard 120-volt electrical outlet. Ensure your hands are dry before plugging in the appliance.

## Operating Instructions

---

The Shark HyperAIR HD101 features HyperAIR IQ Technology for intelligent styling. The dryer automatically adjusts heat and airflow settings when certain IQ attachments are used.

1. **Power On/Off:** Press the power button located on the handle to turn the dryer on or off.
2. **Adjusting Settings:**
  - The dryer has 4 distinct settings for heat and airflow.
  - Use the dedicated buttons on the handle to cycle through the available heat and airflow options.
  - When an IQ attachment (Concentrator or Diffuser) is connected, the dryer may automatically optimize settings for that attachment.
3. **Using the IQ Styling Concentrator:**
  - Attach the concentrator for precise drying and styling.
  - Direct the airflow to specific sections of hair for smoothing or shaping.
  - Ideal for straight and wavy hair types to achieve sleek results.
4. **Using the Diffuser Attachment:**
  - Attach the diffuser for gentle drying and enhancing natural curls or waves.
  - Place sections of hair into the diffuser bowl and lift towards the scalp.
  - Use a low heat and speed setting for best results to minimize frizz.
5. **Cool Shot Function:** Press and hold the cool shot button to set your style with a burst of cool air.

## Maintenance

---

Regular maintenance ensures optimal performance and extends the life of your Shark HyperAIR HD101.

1. **Cleaning the Air Filter:**
  - Ensure the dryer is unplugged and completely cool before cleaning.
  - Locate the air intake filter at the rear of the dryer.
  - Gently twist or pull to remove the filter cover (refer to diagrams in a full manual if available).
  - Remove any accumulated lint, dust, or hair from the filter screen using a soft brush or cloth.
  - Reattach the filter cover securely.
  - *Clean the filter regularly, especially if you notice reduced airflow.*
2. **Cleaning the Dryer Body and Attachments:**
  - Wipe the exterior of the dryer and attachments with a soft, damp cloth.
  - Do not use abrasive cleaners or solvents.
  - Ensure all parts are completely dry before storing or using again.
3. **Storage:**
  - Unplug the appliance and allow it to cool completely.

- Store the dryer and its attachments in a dry, safe place, away from moisture and direct sunlight.
- Do not wrap the power cord tightly around the appliance, as this can damage the cord.

## Troubleshooting

If you encounter issues with your Shark HyperAIR HD101, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dryer does not turn on.	Not plugged in; power outlet issue; internal safety shut-off activated.	Ensure the power cord is securely plugged into a working outlet. Check your circuit breaker. Unplug the dryer, wait 5 minutes, then plug it back in.
Low airflow or reduced drying power.	Air intake filter is blocked with lint or hair.	Unplug the dryer and clean the air intake filter as described in the Maintenance section.
Dryer overheats and shuts off.	Blocked air intake/outlet; prolonged use; internal safety mechanism.	This unit has an auto shut-off and heat protection feature. Unplug the dryer and allow it to cool down for at least 30 minutes. Clean the air filter. Ensure air vents are not blocked during use.
Hair is frizzy after drying.	Incorrect heat/speed setting; improper technique; lack of ionic benefit.	Ensure you are using appropriate heat and speed settings for your hair type. For curly hair, use the diffuser on a low heat setting. The ionic feature helps reduce frizz; ensure the dryer is functioning correctly.

## Specifications

Feature	Detail
<b>Model Name</b>	HyperAIR
<b>Model Number</b>	HD101
<b>Brand</b>	Shark
<b>Manufacturer</b>	SHARKNINJA OPERATING LLC
<b>Power Source</b>	Corded Electric
<b>Voltage</b>	120 Volts
<b>Number of Settings</b>	4
<b>Product Dimensions (D x W x H)</b>	4.92"D x 2.95"W x 11.02"H
<b>Weight</b>	3.37 Pounds
<b>Included Components</b>	Concentrator, Diffuser
<b>Hair Type Compatibility</b>	Curly, Frizzy (also suitable for Straight, Wavy)

## Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Shark website. Keep your purchase receipt as proof of purchase.

If you require further assistance, have questions about your product, or need to claim warranty service, please contact Shark customer support. Contact details can typically be found on the manufacturer's website or in the product packaging.

**Online Resources:** For additional tips, styling guides, and FAQs, visit the official Shark website: [www.sharkclean.com](http://www.sharkclean.com)