

QPLAY Nova+ Rubber

QPLAY Nova+ Rubber Tricycle Instruction Manual

Model: Nova+ Rubber | Brand: QPLAY

1. INTRODUCTION

Thank you for choosing the QPLAY Nova+ Rubber Tricycle. This manual provides essential information for the safe assembly, operation, and maintenance of your new tricycle. Please read it thoroughly before use and retain it for future reference.

The QPLAY Nova+ Rubber Tricycle features a modern aluminum structure, designed for stability and safety. It boasts a quick folding system for easy storage and transport, requiring no tools for assembly. Equipped with a protective barrier, five-point safety harness, and footrests, it ensures your child's security. This versatile tricycle can also be converted into a classic tricycle by removing certain components as your child grows.

2. SAFETY INFORMATION

Your child's safety is paramount. Always adhere to the following guidelines:

- **Recommended Age:** Suitable for children aged 18 months and older.
- **Maximum Weight Capacity:** Do not exceed 9.4 kilograms (approximately 20.7 lbs).
- **Adult Supervision:** Always ensure an adult supervises the child during use. Never leave a child unattended on the tricycle.
- **Safety Harness:** Always secure your child with the five-point safety harness and the protective barrier to prevent falls.
- **Footrests:** Ensure footrests are properly engaged or folded away depending on the child's age and ability.
- **Pre-Ride Check:** Before each use, check that all components are securely fastened, and there are no loose or damaged parts.
- **Hazard Avoidance:** Do not use the tricycle near stairs, hills, roads, or swimming pools. Avoid uneven surfaces.
- **Protective Gear:** Encourage your child to wear a helmet and other protective gear, especially when transitioning to a classic tricycle.

3. PACKAGE CONTENTS

Please verify that all components are present and undamaged before assembly. If any parts are missing or damaged,

contact customer support.

- Tricycle Frame (with folding mechanism)
- Seat with Cover and Five-Point Safety Harness
- Adjustable Canopy
- Front Wheel Assembly (with pedals)
- Rear Wheel Assemblies (x2)
- Parent Handlebar
- Child Handlebar
- Protective Barrier
- Foldable Footrests
- Storage Bag/Backpack

4. ASSEMBLY INSTRUCTIONS

The QPLAY Nova+ Rubber Tricycle features a tool-free, quick-fold assembly system. Follow these steps for initial setup:

1. **Unfold the Frame:** Release the folding mechanism and extend the main frame until it locks securely into place.
2. **Attach Rear Wheels:** Insert the rear wheel assemblies into their designated slots on the frame until they click.
3. **Install Front Wheel:** Attach the front wheel assembly, ensuring the pedals are correctly oriented.
4. **Mount Seat and Canopy:** Secure the seat onto the frame. Attach the canopy to the seat back supports.
5. **Attach Handlebars:** Install the child's handlebar and the parent's push handle. Ensure they are firmly in place.
6. **Secure Barrier and Footrests:** Attach the protective barrier around the seat. Deploy or fold the footrests as needed.
7. **Final Check:** Verify all connections are secure and the tricycle is stable before allowing a child to use it.



Figure 1: Fully assembled QPLAY Nova+ Rubber Tricycle, showcasing its golden black design and key features.

Converting to a Classic Tricycle:

As your child grows and develops more independence, the Nova+ Rubber Tricycle can be transformed into a classic tricycle. This involves removing certain components:

1. **Remove Parent Handlebar:** Detach the rear parent push handle.
2. **Remove Protective Barrier:** Unlatch and remove the child's protective barrier.
3. **Remove Canopy:** Detach the adjustable canopy from the seat.
4. **Remove Seat Cover (Optional):** The seat cover can be removed for a simpler look or for cleaning.
5. **Engage Pedals:** Ensure the pedals are unlocked and ready for the child to use independently.

5. OPERATING INSTRUCTIONS

For Younger Children (with Parent Control):

- **Securing the Child:** Place the child in the seat, fasten the five-point safety harness, and close the protective barrier.
- **Using Footrests:** Ensure the child's feet are comfortably placed on the foldable footrests.
- **Parent Steering:** Use the rear parent handlebar to steer and push the tricycle. The child's handlebar may be locked to prevent independent steering if desired.

For Older Children (Classic Tricycle Mode):

- **Independent Pedaling:** Ensure the pedals are engaged and the child can reach them comfortably.
- **Steering:** The child will steer using the front handlebar.
- **Braking:** Instruct the child on how to use the foot brake (if present) or to stop by slowing down pedaling.

Folding the Tricycle:

The quick folding system allows for compact storage. Locate the folding mechanism (usually a latch or button on the frame) and follow the instructions to collapse the tricycle. Ensure all components are clear of the folding parts to prevent damage or injury.

6. MAINTENANCE

- **Cleaning:** Wipe down the frame and plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners. The seat cover may be removable for hand washing.
- **Lubrication:** Periodically check moving parts (wheels, pedals) for smooth operation. Apply a small amount of silicone-based lubricant if necessary, avoiding contact with rubber tires.
- **Inspection:** Regularly inspect all bolts, nuts, and fasteners to ensure they are tight. Check for any signs of wear, cracks, or damage to the frame, wheels, harness, or canopy. Replace damaged parts immediately.
- **Storage:** Store the tricycle in a dry, cool place, away from direct sunlight and extreme temperatures, to prolong its lifespan.

7. TROUBLESHOOTING

- **Tricycle does not fold easily:** Ensure all components are correctly aligned and no parts are obstructing the folding mechanism. Refer to the assembly instructions for the folding process.
- **Wheels are stiff or noisy:** Check for debris caught in the wheels. If clear, a small amount of lubricant on the axle may help.
- **Loose parts:** Regularly check and tighten all screws and fasteners. Do not overtighten.
- **Child's feet slip off pedals:** Ensure the child is old enough and has sufficient coordination for independent pedaling. In parent-controlled mode, use the footrests.

If you encounter issues not listed here or require further assistance, please contact QPLAY customer support.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	QPLAY
Model	Nova+ Rubber
Product Dimensions (L x W x H)	50 x 50 x 28 cm (approximately 19.7 x 19.7 x 11 inches)
Product Weight	9.4 Kilograms (approximately 20.7 lbs)
Recommended Age	18 months and up
Maximum Supported Weight	9.4 Kilograms (approximately 20.7 lbs)
Educational Value	Develops motor skills, balance, and coordination safely
Main Material	Alloy Steel
Assembly Required	Yes (tool-free assembly)
Manufacturer Reference	7290115246339

9. WARRANTY AND SUPPORT

For specific warranty details, please refer to the documentation provided at the time of purchase or contact your retailer. QPLAY products are designed for durability and safety, but in the event of a manufacturing defect, warranty terms typically cover repair or replacement.

For technical support, spare parts, or any inquiries regarding your QPLAY Nova+ Rubber Tricycle, please contact QPLAY customer service through their official website or the contact information provided with your product.

© 2023 QPLAY. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question