

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HOMCOM](#) /

› [HOMCOM 91L Compact Reversible Door Refrigerator with Freezer, Model 800-129V90WT](#)

## HOMCOM 800-129V90WT

# HOMCOM 91L Compact Refrigerator with Freezer Instruction Manual

Model: 800-129V90WT

[Overview](#) [Setup](#) [Operation](#) [Safety Instructions](#) [Product](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. SAFETY INSTRUCTIONS

Please read these instructions carefully before using your HOMCOM refrigerator. Keep this manual for future reference.

- Ensure the appliance is properly grounded.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Keep ventilation openings clear of obstruction.
- Before cleaning or maintenance, always unplug the appliance from the power supply.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

## 2. PRODUCT OVERVIEW

The HOMCOM 91L Compact Refrigerator with Freezer (Model 800-129V90WT) is designed for efficient and quiet cooling in smaller spaces. It features a reversible door, adjustable temperature control, and multiple storage options.



*Figure 2.1: Front view of the HOMCOM 91L Compact Refrigerator.*

**Key Features:**

- **Compact Design:** Ideal for small apartments, offices, or dorm rooms.
- **Reversible Door:** Allows for flexible placement by changing the door's opening direction.
- **Low Noise Operation:** Operates at a quiet 41 dB.
- **Adjustable Temperature:** Thermostat with 5 levels, ranging from 0°C to 10°C.
- **Integrated Freezer Compartment:** A 10L top freezer section for frozen items.
- **Ample Storage:** Includes adjustable internal shelves, door shelves, and a crisper drawer.



*Figure 2.2: The compact refrigerator seamlessly integrated into a kitchen environment.*



Figure 2.3: Visual representation of key features including low noise, energy saving, compact size, and adjustable temperature.

# COMPARTI MULTIPLI



Figure 2.4: Interior layout with adjustable shelves, crisper drawer, and door shelves for organized storage.

# SCATOLA REFRIGERANTE

Progettato con una scatola refrigerata da 10L per raffreddare rapidamente il cibo



Figure 2.5: Detail of the 10L freezer compartment, designed for rapid cooling.

## 3. SETUP

### 3.1 Unpacking and Placement

- Remove all packaging materials, including foam and adhesive tape.
- Place the refrigerator on a firm, level surface. Ensure there is adequate ventilation space around the appliance (at least 10 cm on sides and back, 30 cm above).
- Avoid placing the refrigerator in direct sunlight or near heat sources like stoves or heaters.
- Allow the appliance to stand upright for at least 2-4 hours before connecting it to power. This allows the refrigerant to settle.

### 3.2 Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and a mild detergent. Rinse with clean water and dry thoroughly.

### 3.3 Power Connection

Connect the refrigerator to a dedicated, properly grounded electrical outlet (240V). Do not use extension cords or adapters.

### 3.4 Reversible Door Installation

The door of this refrigerator can be reversed to open from either the left or right side, depending on your space requirements. This procedure should be performed by a qualified technician or by carefully following the detailed instructions provided in a separate guide (if applicable) or by contacting customer support. Ensure the appliance is unplugged before attempting to reverse the door.



## PORTA REVERSIBILE

Si adatta alla disposizione della stanza e alle abitudini personali

Figure 3.1: The reversible door feature allows for flexible placement in any room layout.

## 4. OPERATING INSTRUCTIONS

### 4.1 Temperature Control

The refrigerator features an adjustable thermostat with 5 settings, allowing you to control the internal temperature

between 0°C and 10°C. The dial is typically located inside the refrigerator compartment, near the freezer section.

- Turn the thermostat dial to the desired setting. Higher numbers (e.g., 5) indicate colder temperatures, while lower numbers (e.g., 1) indicate warmer temperatures.
- Setting "0" will turn off the cooling function.
- Adjust the temperature based on the ambient room temperature and the amount of food stored.

# SCATOLA REFRIGERANTE

Progettato con una scatola refrigerata da 10L per raffreddare rapidamente il cibo



Figure 4.1: The thermostat dial for adjusting the refrigerator's internal temperature.

## 4.2 Food Storage Guidelines

- Store fresh foods in sealed containers or wrapped to prevent drying out and odor transfer.
- The crisper drawer is ideal for fruits and vegetables.
- The freezer compartment is suitable for short-term storage of pre-frozen items or making ice.
- Do not place hot food directly into the refrigerator; allow it to cool to room temperature first.
- Avoid overloading the shelves to ensure proper air circulation.

## 5. MAINTENANCE

## 5.1 Defrosting

This refrigerator features manual defrosting. Frost will accumulate on the inner walls of the freezer compartment. When the frost layer reaches about 3-5 mm thick, it should be defrosted.

1. Unplug the refrigerator from the power outlet.
2. Remove all food items from the freezer and refrigerator compartments and store them in a cool place.
3. Leave the door open to allow the frost to melt naturally. You can place towels at the bottom to absorb water.
4. Do not use sharp objects or heating devices to speed up defrosting, as this can damage the appliance.
5. Once defrosted, clean and dry the interior thoroughly before plugging the appliance back in and returning food.



*Figure 5.1: Manual defrosting of the freezer compartment using the provided ice scraper.*

## 5.2 Cleaning

- Regularly clean the interior and exterior surfaces with a mild detergent and warm water.
- Wipe down door seals to ensure they remain clean and maintain a tight seal.
- Clean the condenser coils at the back of the refrigerator periodically (e.g., every 6-12 months) to maintain

efficiency. Use a soft brush or vacuum cleaner.

- Always unplug the appliance before cleaning.

## 6. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate.	No power, plug loose, circuit breaker tripped.	Check power supply, ensure plug is secure, reset circuit breaker.
Refrigerator is not cold enough.	Temperature setting too high, door opened frequently, warm food placed inside, poor ventilation.	Adjust thermostat to a colder setting, minimize door openings, allow hot food to cool, ensure adequate space around the unit.
Excessive noise.	Appliance not level, objects touching the back, normal compressor operation.	Adjust leveling feet, move objects away from the unit, some noise from compressor is normal.
Water dripping from freezer.	Ice buildup in freezer, drain hole blocked, tray not positioned correctly.	Perform manual defrosting. Check if the drip tray (if present) is correctly aligned to catch melting ice. Ensure the drain hole is clear.
Door does not close properly.	Door gasket dirty or damaged, appliance not level, food obstructing closure.	Clean or replace door gasket, level the appliance, rearrange food items.

## 7. SPECIFICATIONS

Feature	Detail
Brand	HOMCOM
Model Number	800-129V90WT
Capacity	91 Liters
Configuration	Compact with top freezer
Color	White
Product Dimensions (D x W x H)	44.2 x 47.5 x 84 cm
Weight	18 kg
Special Features	Low noise, Compact, Adjustable shelves
Installation Type	Freestanding
Number of Doors	1
Defrost System	Manual

Feature	Detail
Voltage	240 Volt



Figure 7.1: Detailed dimensions of the refrigerator (Depth: 44.2 cm, Width: 47.5 cm, Height: 84 cm).

### What's in the Box:

- Compact Refrigerator

- Ice Tray
- Ice Scraper

## 8. WARRANTY AND SUPPORT

---

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the HOMCOM official website. For technical support, spare parts, or any inquiries, please contact HOMCOM customer service.

**Contact Information:** Please refer to your purchase receipt or the HOMCOM website for the most up-to-date contact details.

## 9. PRODUCT VIDEO

---

Your browser does not support the video tag.

*Video 9.1: A short demonstration of the HOMCOM compact refrigerator's features, including its interior layout, freezer compartment, and reversible door.*